


OPERATION MANUAL

Dakota NDT

FX80 Series

Material & Coating Thickness Gauges

(Manual 1 of 2)



CONTENTS

CHAPTER ONE INTRODUCTION	1
1.1 GENERAL DISCLAIMER	1
CHAPTER TWO QUICK STARTUP GUIDE	2
2.1 FX80 OVERVIEW	2
2.2 GAUGE TYPE	5
2.3 TOP & SUBMENU REFERENCE	5
2.4 AUTO PROBE RECOGNITION	6
2.5 SELECTING THE TRANSDUCER TYPE	8
2.6 PROBE ZERO & CALIBRATION	9
ONE POINT MATERIAL CALIBRATION	12
2.7 ZERO COATING	14
2.8 COATING CALIBRATION	16
KNOWN COATING VELOCITY	16
KNOWN COATING THICKNESS	17
2.9 MEASURE	20
CHAPTER THREE KEYBOARD, MENU, & CONNECTOR REFERENCE	25
3.1 MENU KEY (OPERATION & SUB MENUS)	25
3.2 PROBE – MENU	27
3.3 CAL – MENU	27
3.4 DISP (DISPLAY) – MENU	28
3.5 TUNE – MENU	29
3.6 GT1 – MENU	30
3.7 GT2 – MENU	30
3.8 GT3 – MENU	31
3.9 SETUP – MENU	31
3.10 DATA – MENU	32
3.11 UTIL (UTILITIES) – MENU	32
3.12 XFER (TRANSFER) – MENU	33
3.13 CLR (CLEAR) KEY	34
3.14 HOME (MEASUREMENT MODE) KEY	34
3.15 OK KEY	34
3.16 ESC KEY	35
3.17 WHEEL KEYS	35
3.18 ENTER KEY	35
3.19 MULTI MODE KEY	35
3.20 DATA KEY	35

3.21 STORE KEY.....	35
3.22 PEAK KEY	36
3.23 FREEZE KEY	36
3.24 ON/OFF KEY	36
3.25 NAVIGATING THE HOT MENUS	36
3.26 TOP & BOTTOM END CAPS	38

CHAPTER FOUR PRINCIPALS OF ULTRASONIC MEASUREMENT..... 40

4.1 TIME VERSUS THICKNESS RELATIONSHIP.....	40
4.2 SUITABILITY OF MATERIALS	40
4.3 RANGE OF MEASUREMENT AND ACCURACY	40
4.4 COUPLANT.....	40
4.5 TEMPERATURE.....	41
4.6 MEASUREMENT MODES	41

CHAPTER FIVE SELECTING THE MEASUREMENT MODE 44

5.1 THE SETUP LIBRARY	44
5.2 WHICH MODE & TRANSDUCER DO I USE FOR MY APPLICATION?	44
5.3 FACTORY SETUP CHART.....	46

CHAPTER SIX MAKING MEASUREMENTS 47

6.1 AUTO PROBE RECOGNITION & SELECTING THE TRANSDUCER TYPE	47
6.2 PROBE ZERO	50
6.3 MATERIAL CALIBRATION	53

CHAPTER SEVEN USING THE DISPLAY OPTIONS 62

7.1 DISPLAY VIEWS.....	63
7.2 CHANGING DISPLAY OPTIONS	71
7.3 ADJUSTING THE DISPLAY	72
7.4 GAIN & STEP INCREMENT	77
7.5 THRESHOLD.....	81
7.6 UNDERSTANDING THE FEATURES OF THE GATE	86
7.7 GATES	89

CHAPTER EIGHT THRU PAINT MEASUREMENT TECHNIQUE 96

8.1 INTRODUCTION TO THRU PAINT MEASUREMENT	96
8.2 USING THRU PAINT MODE	96

CHAPTER NINE PULSE-ECHO COATING & COATING TECHNIQUES..... 99

9.1 INTRODUCTION TO PULSE-ECHO COATING MEASUREMENT (PECT)	99
9.2 ENABLING PULSE-ECHO COATING MODE (PECT) & COATING (CT).....	99
9.3 ZERO COATING	103

9.4 COATING CALIBRATION (PECT)	105
9.5 INTRODUCTION TO COATING MEASUREMENT (CT)	109
9.6 TWO POINT COATING CALIBRATION (CT)	109

CHAPTER TEN ADDITIONAL FEATURES OF THE FX80..... 115

10.1 AUTO FIND	115
10.2 HIGH SPEED SCAN	116
10.3 ALARM MODE	117
10.4 DIFFERENTIAL MODE	119
10.5 BRIGHTNESS	121
10.6 COLOR	122
10.7 DIM.....	124
10.8 DAMPING	125
10.9 GRAPHICS OPTIONS (LOOK & FEEL)	126
10.10 POLARITY.....	128
10.11 PULSE WIDTH	132
10.12 PULSER VOLTAGE	133
10.13 GAIN SLOPE (TDG)	134
10.14 ANALOG OUTPUT.....	136
10.15 SERIAL OUTPUT	137
10.16 KEY CLICK	138
10.17 DATE & TIME.....	139
10.18 FREEZE & CAPTURE	141
10.19 CAPTURE VIEWER	143

CHAPTER ELEVEN DATA STORAGE – SETUP, EDIT, & VIEW FILES 145

11.1 INTRODUCTION TO GRID AND SEQUENTIAL FILE FORMATS	145
11.2 CREATING A NEW GRID OR SEQUENTIAL LOG (FILE).....	146
11.3 STORING A READING	157
11.4 VIEWING STORED READINGS.....	159
11.5 DELETING GRIDS (FILES)	160
11.6 EDITING A GRID (FILE)	163
11.7 CHANGING THE ACTIVE FILE - OPEN.....	165
11.8 CLOSING AN ACTIVE FILE - CLOSE	167

CHAPTER TWELVE SETUPS – CREATE, STORE, EDIT, & RECALL..... 169

12.1 INTRODUCTION TO SETUPS	169
12.2 OPENING A SETUP.....	169
12.3 SAVING A SETUP	171
12.4 DELETING A SAVED SETUP.....	174
12.5 USING THE DEFAULT SETUP	176
12.6 SELECTING A LANGUAGE	178

CHAPTER THIRTEEN SOFTWARE, FILE TRANSFER, & UPGRADES 179

13.1 COMPUTER SYSTEM REQUIREMENTS	179
USB TYPE1 TO TYPE 2 CABLE	179
13.2 INSTALLING DAKVIEW	179
13.3 COMMUNICATING WITH FX80	179
13.4 USING THE XFER MENU (FX80).....	180
13.5 SELECTING STORAGE DEVICE	180
13.6 COPYING FILES (SETUPS, DATA, & SCREENSHOTS)	181
13.7 UPGRADING THE FX80	183

APPENDIX A - VELOCITY TABLE 185

APPENDIX B - SETUP LIBRARY 187

CHAPTER ONE INTRODUCTION

The Dakota NDT model **FX80** is both, an ultrasonic thickness gauge, as well as a flaw detector. Since the **FX80** is basically two gauges in a single package, we split the manual into two manuals, one for each gauge type. This manual will focus only on the thickness gauge portion of the gauge. The **FX80** has the ability to simultaneously measure coatings and material thicknesses while maintaining the ability to locate pits, flaws and defects in the material. Based on the same operating principles as SONAR, the **FX80** is capable of measuring the thickness of various materials with accuracy as high as ± 0.001 inches, or ± 0.01 millimeters. The principle advantage of ultrasonic measurement over traditional methods is that ultrasonic measurements can be performed with access to only one side of the material being measured.

Dakota NDT maintains a customer support resource in order to assist users with questions or difficulties not covered in this manual. Customer support may be reached at any of the following:

Dakota NDT
1500 Green Hills Road, #107
Scotts Valley, CA 95066 USA
Telephone: (831) 431-9722
Facsimile: (831) 431-9723
www.dakotandt.com

1.1 General Disclaimer


The manual should be read and understood prior to using the **FX80**. This operating manual provides the user with all the general information necessary to use and adjust the designed features. However, this manual is not a certified NDT training course, nor is it intended to be one. Training, according to company requirements, is recommended.

Inherent in ultrasonic thickness measurement is the possibility that the instrument will use the second rather than the first echo from the back surface of the material being measured. This may result in a thickness reading that is TWICE what it should be. Responsibility for proper use of the instrument and recognition of this phenomenon rest solely with the user of the instrument. Other errors may occur from measuring coated materials where the coating is insufficiently bonded to the material surface. Irregular and inaccurate readings may result. Again, the user is responsible for proper use and interpretation of the measurements acquired.

CHAPTER TWO QUICK STARTUP GUIDE

Turn the **FX80** on and off using the switch located on the bottom right corner of the keypad. When **FX80** is initially turned on, a flash logo and blinking lights will be displayed, followed by attempting to identify the transducer (probe) currently plugged into the gauge. The **FX80** is equipped with an “Auto Probe Recognition” feature that attempts to identify special transducers with this built in feature. If the **FX80** doesn't find a transducer equipped with this feature, the user will be advanced to a list of transducers requiring the user to select a specific transducer type. The following sections outline each scenario. Note: This section is primarily written as a basic startup guide only.

2.1 FX80 Overview



In order to understand how to operate the **FX80**, it's best to start off with an understanding of what it is we're looking at exactly. The **FX80** has a lot of great features and tools that will prove to be a huge benefit for the variety of applications you're constantly facing on a continual basis. Let's have a brief look at the screens you'll be looking at most often:

- A. **Repeatability/Stability Indicator** – This indicator should be commonly used in conjunction with the digital thickness values displayed. When all the vertical bars are fully illuminated and the last digit on the digital thickness value is stable, the **FX80** is reliably measuring the same value 3 to 200 times per second, depending on which measurement mode and features are enabled.
- B. **Battery Icon** – Indicates the amount of battery life the **FX80** has remaining.
- C. **Velocity** – The material velocity value the **FX80** is currently using or calibrated for. Displayed in both English or Metric units, depending on the what units the gauge is set for.
- D. **Feature Status Bar** – Indicates the features currently enabled and in use in the following order:
 - Measurement Mode
 - Differential Mode
 - High Speed Scan Mode
 - Alarm Mode
 - Gain Setting
- E. **Digital Material Thickness Values** – Depending on the measurement mode selected, the base material and coating thicknesses are displayed. If the scan feature is enabled, the minimum and maximum thickness value of the base material is displayed and updated simultaneously during the scan .
- F. **Scan Bar** – Another view of material thickness in a deflection style horizontal bar. This is a visual tool that would enable the user the ability to see thickness changes during high speed scans from flaws and pits.
- G. **Units** – The current measurement units being used (English, Metric).
- H. **Hot Menu items** – We call this menu section our “hot menu”, as these items are the most commonly adjusted features, requiring quick access from the

user. They can be displayed and scrolled by pressing the  key at any time. The  key advances forward and the  key backwards to

the next hot menu item. Alternatively, the , , and 



arrow keys on the left button wheel can be used to either scroll through the sub menu items, or advance to the next HOT MENU items list. There are 8 HOT MENU lists, that contain the most commonly adjusted items from the tabbed menus, and in the same order as the tabbed menus. Note: Some of the lists contain multiple tabbed menus in order to condense the number of HOT MENU lists.

- I. **B-Scan Display** – Cross section view of the material. Provides the user with graphical view of the opposite/blind surface (i.e. inside pipe wall surface), to give the user some idea of the condition, or integrity of the material being tested.

- J. **Gain & Step Size** – The gain and increment step size can be continuously

used and adjusted at any time using the



and




arrow keys

on the right button wheel to scroll the value, and the  key to activate the **Digit Edit** screen to adjust the step size.

- K. **Rectified A-Scan Display** – The actual sound wave reflection that is returned from the detection of the opposite surface of the material being measured. In this view, only half of the sine wave is being displayed (positive or negative). This view is commonly referred and used as a “flaw detection” mode.
- L. **Reference Note** – When a full screen sound wave is being displayed, the material thickness value is displayed here.
- M. **Reference Note** – In a split screen mode the material velocity is displayed here.
- N. **Split Screen Display** – This display option ‘splits’ the screen in half, displaying the waveform/B-Scan and the thickness values concurrently.

2.2 Gauge Type



Power up the **FX80**, by pressing the on/off key located in the bottom right corner of the keypad. During initial boot up, a flash screen and lights will be displayed, followed by a **GAUGE TYPE** selection screen. Since this manual will focus on the

thickness gauge portion of the **FX80**, use the  /  arrow keys to

select “thickness gauge”, followed by pressing the  key start the **FX80** in thickness mode.

2.3 Top & Submenu Reference

The following table is a quick menu reference guide. The **FX80** has 15 top level menu titles, and multiple submenu items as illustrated below. The **FX80** also has 8 ‘hot menu’ subsets of the same menu structure. These are the most commonly adjusted submenu items from each of the top level menus. They can be quickly

accessed from the main measurement screen by pressing the  and  arrow

keys multiple times using the left button wheel, and pressing the  and

 arrow keys on the left button wheel to select the appropriate submenu item. Refer to Chapter Three for additional definitions and information on the keypad and menu items.

1 st Main Hot Menu	
Additional Hot Menus	

Note: “Log” is also listed in the 1st main Hot Menu, and is used to access data storage if no log file is currently open, or display log or grid file if open.

Start >>

PRB	CAL	DISP	TUNE	GT1	GT2	GT3	SETUP
-----	-----	------	------	-----	-----	-----	-------

ZERO PROBE	MAT	VIEW	MEASURE MODE	START	GATE2 WIDTH	GATE3 WIDTH	OPEN
ZERO COATING	MATL 1PT	DELAY	POLARITY	GATE1 WIDTH	HOLDOFF 2	HOLDOFF 3	SAVE
TYPE	MATL 2PT	RANGE	PULSE	THRESHOLD 1	THRESHOLD 2	THRESHOLD 3	DELETE
	VELOCITY	B-SCAN SPEED	PULSER VOLTAGE				DEFAULT SETUP
	COATING 1PT	UNITS	DAMPING				
	COATING 2PT	BRIGHTNESS	GAIN				LANGUAGE
	COATING VEL	COLORS	AGC				
		DIM	TDG SLOPE				
		RECT WAVE	TDG START				
		DETECT MARK					
		GRATICULE					

>> End

DATA	UTILS	XFER
NEW	AUTO FIND	BACKUP SETUPS
EDIT	SCAN MODE	COPY DATA
OPEN	ALARM	COPY SCREENS
CLOSE	ALARM HIGH	UPGRADE GAUGE
DELETE ONE FILE	ALARM LOW	CAPTURE TO FILE
DELETE ALL DATA	DIFFERENTIAL	CAPTURE VIEWER
	GAUGE	STORAGE
	ANALOG OUTPUT	ABOUT
	SERIAL OUTPUT	
	DIGITIZER	
	KEY CLICK	
	SET DATE	
	SHOW DATE	

Note: **FX81** only

2.4 Auto Probe Recognition

When the **FX80** is initially powered up, the gauge will automatically check to see if the transducer plugged into the gauge can be recognized. The steps that follow assume the **FX80** recognized the probe type:

Probe Automatically Recognized

CONFIRM	
1/4IN - 5.0MHZ COAT PROBE IDENTIFIED.	
USE THIS PROBE?	
OK	ESC

- 1) Press the  key once to use the identified probe, or  to display a list of optional transducers. **Note:** if the **FX80** recognizes a specific transducer, the user should always select  to use the identified probe. The only time an alternative probe should be selected from a list is if the user switched probes following initial power up and recognition.

- 2) Assuming the **FX80** recognized the probe and the  key was pressed, the **FX80** will advance to a Zero Probe menu. If the transducer was identified as a special transducer capable of measuring coating thickness, a menu will be displayed allowing the user the ability to toggle the coating thickness display on/off as follows:

ZERO PROBE	
COATING:	ON
COATING:	OFF
SELECT COATING ON/OFF - REMOVE COUPLANT FROM PROBE AND PRESS OK KEY TO PERFORM THE ZERO	
OK	ESC

- 3) Press the  and  arrow keys on the left button wheel to toggle the coating option on/off.

- 4) Wipe all couplant from the transducer face and advance to the **Probe Zero & Calibration** section outlined below.

2.5 Selecting the Transducer Type

If the **FX80** does not identify a specific transducer type on initial power up, the user will be required to select a type from a predefined list of types by diameter and frequency. By selecting a transducer type from a predefined list, the **FX80** can recall specific properties about the transducer. **Note:** Once the transducer has been selected, the **FX80** will store and recall this transducer type every time the **FX80** is powered on/off. The type will only change if the user physically selects another transducer type from the list, or selects a previously saved setup. However, the **FX80** will continue to take you through these steps each time the gauge is powered up. You'll notice that the probe type previously selected will be highlighted every time the probe type screen is displayed. Use the following steps to select your transducer type:

Selecting the Transducer Type

CONFIRM	
UNIDENTIFIED PROBE TYPE - SELECT A PROBE FROM LIST	
?	
OK	ESC

- 1) Press the  or  keys to display the factory list of transducer types (by diameter and frequency).

PROBE TYPE	
1.	3/16IN - 5.0MHZ
2.	3/16IN - 7.5MHZ
3.	3/16IN - 10.0MHZ
4.	3/16IN - 5.0MHZ HD
5.	3/16IN - 7.5MHZ HD
6.	3/16IN - 5.0MHZ COAT
7.	3/16IN - 7.5MHZ COAT
8.	1/4IN - 2.25MHZ
9.	1/4IN - 5.0MHZ
10.	1/4IN - 5.0MHZ HD
11.	1/4IN - 5.0MHZ COAT
12.	1/4IN - 7.5MHZ

2) Press the  and  arrow keys on the left button wheel to scroll through the transducer list until the appropriate type is highlighted.

3) Press the  key to select the transducer type and display overwrite existing probe screen.

4) Press the  key to overwrite the existing probe type with the newly selected probe type. The zero probe screen will be displayed. Proceed to the zero probe section that follows.

2.6 Probe Zero & Calibration

The next steps are to perform a probe zero and calibrate the **FX80** to the material and transducer being used. If the sound velocity is unknown, the **FX80** can be calibrated to a known thickness sample. This demo will briefly explain both of these techniques.

The **FX80** is equipped with two zero options:

- 1) **Off Block Zero (Automatic Probe Zero)** – When this feature is enabled the **FX80** will do an electronic zero automatically, eliminating the need for a zero disk or block.
- 2) **On Block Zero (Manual Probe Zero)** – When this feature is enabled the transducer must be placed on the probe zero disk (battery cover located on the top of the unit).

Note: *Transducers of the same type will have very slight mechanical and electrical variations. If it's discovered that the linearity is off following an initial auto probe zero and extreme accuracy is required, a manual zero should be performed followed by an auto zero. This will adjust and eliminate any error. This is only required if it's discovered the transducer is non-linear following an initial auto probe zero.*

The procedures are outlined as follows:

Performing an Auto Probe Zero (Off Block)

ZERO PROBE	
COATING:	ON
COATING:	OFF
SELECT COATING ON/OFF - REMOVE COUPLANT FROM PROBE AND PRESS OK KEY TO PERFORM THE ZERO	
OK	ESC

Coating Probe Identified

ZERO PROBE	
REMOVE COUPLANT FROM PROBE. PRESS OK KEY TO PERFORM THE ZERO	
OK	ESC

Coating Probe Not Identified

- 1) Be sure all couplant has been removed from the face of the transducer.
- 2) Press the  key to perform the automatic probe zero, or  key to cancel the zero operation.
- 3) The screens illustrated above will be briefly displayed followed by the main measurement screen. The **FX80** is ready to be calibrated.

Performing a Manual Probe Zero (On Block)

WARNING!	
BE SURE TO DO A PROBE ZERO BEFORE MEASURING	
OK	ESC

Note: When the zero probe option is set to manual, the probe zero disk (battery cap) located on the top of the gauge, will be used as a zero standard and the warning screen illustrated above will be displayed.


1) Press the  or  keys to enter the main measurement screen and begin the manual zero process.

2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the probe zero disk, and obtain a steady reading.


3) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **PRB** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel to scroll the tabbed menus.

4) Press the  and  arrow keys on the left button wheel to scroll through the sub menu items until **ZERO PROBE** is highlighted.



Coating Probe Identified



Coating Probe Not Identified

5) Press the  key to display the confirmation screen.

6) If a coating transducer was identified use the  and  arrow keys on the left button wheel to toggle coating on/off.

7) Press the  key to complete the probe zero function, or  key to cancel the probe zero function.

- 8) Remove the transducer from the probe zero disk, and proceed to the calibration section.

Note: *The value that is displayed will change depending on the current velocity setting in the **FX80**. Disregard the number that is displayed. **It is not important.** What is important is accurately performing the steps outlined above to insure reliability of the probe zero calculation.*

One Point Material Calibration

For the purposes of this quick start section, we'll only be covering the most common one point calibration option to determine the sound velocity of the test material. It would be very handy to carry a set of mechanical calipers to use in conjunction with the **FX80** for calibration in the field:

Using a Known Thickness


CALIBRATE			
MAT	CUSTOM		
MATL 1PT	0.500		
MATL 2PT	UNCAL		
VELOCITY	0.2342		
COATING 1PT	UNCAL		
COATING 2PT	UNCAL		
COATING VEL	0.0850		
PRB	CAL	DISP	TUNE

Note: *Be sure that the probe zero procedure has been performed prior to performing this calibration procedure.*

- 1) Physically measure an exact sample of the material or a location directly on the material to be measured using a set of calipers or a digital micrometer.
- 2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the sample or actual test material. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the

display, is fully lit and stable. Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 3) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **MATL 1PT** is highlighted.



- 4) Press the  key to display the **Digits Edit Box**.

- 5) Press the  and  arrow keys on the left button wheel to scroll the highlighted value.

- 6) Press the  and  arrow keys on the left button wheel to scroll the digit locations.

- 7) Repeat steps **5 & 6** until the known thickness value is correctly displayed.

- 8) Press the  key to calculate the velocity and return to the menu screen, or  to cancel the one point calibration.

- 9) Finally, press the  key to return to the measurement screen and begin taking readings.

Note: ***CHECK YOUR CALIBRATION!** Place the transducer back on the calibration point. The thickness reading should now match the known thickness. If the thickness is not correct, repeat the steps above.*

2.7 Zero Coating

In order to account for very slight electronic differences in transducers of the same type, frequency, and diameter, the **FX80** has been equipped with a “zero coating” feature. This enables the **FX80** to obtain very accurate readings on coatings, eliminating potential errors incurred from slight differences in the manufacturing processes. The procedure is outlined below:

Performing a Coating Zero

MEASURE MODE	
COATING OFF	P-E
COATING ON	PECT
TEMP COMP	PETP
THRU COAT	E-E
THRU VERIFY	E-EV
COATING ONLY	CT

- 1) Press the  key once to activate the measurement mode options.
- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **Coating Only (CT)** mode is highlighted.
- 3) Press the  key to select the measurement mode and return to the measurement screen.

- 4) Apply a drop of couplant on the transducer and place the transducer in steady contact with one of the probe zero disks (emergency battery covers) and obtain a steady reading.

Note: *The coating measurement displayed will potentially be a value greater or less than 0.*

- 5) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **PRB** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

SETUP PROBE			
ZERO PROBE	AUTO		
ZERO COATING			
TYPE	11		
PRB	CAL	DISP	TUNE

- 6) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **ZERO COATING** is highlighted.
- 7) Press the  key to display the confirmation screen.
- 8) Press the  key to zero the coating and return to the **PRB** menu, or  to cancel the coating zero process.
- 9) Press the  key once to activate the measurement mode options.

10) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **Coating On (PECT)** is highlighted.

11) Press the  key to select the measurement mode and return to the measurement screen, and begin taking readings.

2.8 Coating Calibration


The **FX80** has been preset to a default coating velocity of 0.0850 in/μsec (2159 m/sec). This will be very close to the most common coating material velocities used in the field. If the velocity of the coating is known, and different than the above default setting, the user can simply enter the coating velocity into the **FX80**. However, if the velocity is unknown, the **FX80** can also be calibrated to a specific coating sample/type using the 1pt calibration option in PECT (pulse-echo coating) mode, or a two point calibration is **CT (coating only)** mode. For the purpose of this quick start section only the 1pt option **PECT (pulse-echo coating)** mode will be covered. Refer to the calibration section of the manual for a complete explanation on the coating calibration options. The following steps below outline the necessary steps to either set the velocity of the coating, or perform a one point calibration to calculate the coating velocity:

Known Coating Velocity

If the coating velocity is known, the user may wish to simply enter the velocity number into the **FX80**, rather than have the **FX80** calculate the velocity value using a known thickness on a coating sample. The steps for entering the velocity are outlined below:

Using a Known Coating Velocity

CALIBRATE	
MAT	CUSTOM
MATL 1PT	0.500
MATL 2PT	UNCAL
VELOCITY	0.2342
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0850
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items.
- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **COATING VEL** is highlighted.
- 3) Press the  key to display the **Digits Edit Box**.
- 4) Press the  and  arrow keys to scroll the highlighted value.
- 5) Press the  and  arrow keys on the left button wheel to scroll the digit locations.
- 6) Repeat steps **4 & 5** until the velocity number is correctly displayed.
- 7) Press the  key to set the coating velocity and return to the menu screen, or  to cancel entering the coating velocity.
- 8) Finally, press the  key to return to the measurement screen and begin taking readings.

Known Coating Thickness

When the exact velocity of a coating is unknown, the user has the option of performing a one point calibration on a sample of the coating with a known thickness to determine the sound velocity. It would be very handy to carry a set of mechanical calipers to use in conjunction with the **FX80** for calibration in the field:

Using a Coating Sample to Calibrate

CALIBRATE	
MAT	CUSTOM
MATL 1PT	0.500
MATL 2PT	UNCAL
VELOCITY	0.2342
COATING 1PT	0.020
COATING 2PT	UNCAL
COATING VEL	0.0823
PRB	CAL DISP TUNE

- 1) Physically measure a location on a coating sample using a set of calipers or a digital micrometer.


Note: In **PECT** (pulse-echo coating) mode, the coating sample must be coupled to metal in order to calibrate successfully. Simply place a drop of couplant on a piece of metal, lay the coating sample over the couplant on the metal and proceed to step 2.

- 2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the coating (on metal) sample or actual test material. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable. Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is

highlighted and displaying the submenu items. Alternatively, press the

and  arrow keys multiple times using the left button wheel.

- 3) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **COATING 1PT** is highlighted.



- 4) Press the  key to display the **Digits Edit Box**.
- 5) Press the  and  arrow keys on the left button wheel to scroll the highlighted value.
- 6) Press the  and  arrow keys on the left button wheel to scroll the digit locations.
- 7) Repeat steps **5 & 6** until the known thickness value is correctly displayed.
- 8) Press the  key to calculate the coating velocity and return to the menu screen, or  to cancel the one point calibration.
- 9) Finally, press the  key to return to the measurement screen and begin taking readings.

Note: CHECK YOUR CALIBRATION! Place the transducer back on the calibration point. The coating thickness reading should now match the known coating thickness sample. If the thickness is not correct, repeat the steps above.

2.9 Measure

The **FX80** is now ready to measure. There are four different measurement view options, each with a specific purpose – Digits, RF, RECT, & B-Scan. The steps below outline how to toggle between the different view mode options:

Selecting the Measurement View Option

SET DISPLAY	
VIEW	+RECT
DELAY	-0.240
RANGE	0.305
B-SCAN SPEED	6
UNITS	IN
BRIGHTNESS	15
COLORS	GREEN 2
<MORE>	
PRB	CAL DISP TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **DISP** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys on the left button wheel to scroll the sub menu items until **VIEW** is highlighted.

- 3) Use the  and  arrow keys on the right button wheel to scroll the view options.

- 4) Once the view is displayed, press the  key to return to measurement mode.

DIGITS: Displays the digital thickness value using a large font size. This view is useful when the **FX80** is being used as a basic thickness gauge.

RF: Displays the actual waveform signal, much like an oscilloscope, from the reflection of the opposite surface, pit, flaw, crack or void. This view shows both the positive and negative peaks, and is often used to fine tune the scope settings, prior to inspection.


RECT: Displays a half waveform signal, either positive or negative, from the reflection of the opposite surface, pit, flaw, crack or void. The user can select the polarity or “phase” displayed. This is typically determined by first using RF view to select the most optimal polarity “phase”, to fine tune the scopes settings. The RECT view is commonly used as the primary “flaw detection” view.

BSCAN: The Time Based B-Scan provides the user with a cross sectional view of the material being tested. This mode is useful when there is concern regarding the profile of the blind surface. This can also be a useful view when scanning for pits and flaws.


Once the view has been selected according to the application requirements, the **Delay** and **Range** of the screen will potentially need to be adjusted, if the view has been set to **RF** or **RECT**. Alternatively, if **BSCAN** was selected, the **B-Start** and **B-Depth** settings will need to be adjusted. These settings serve the same purpose, with only differences in terminology. The **Delay** the same as **B-Start**, and the **Range** is the same as **B-Depth**. Therefore, these items will be grouped together for the duration of this manual, as follows: **Delay (B-Start)** and **Range (B-Depth)**. Use the following steps to adjust these settings directly from the measurement screen as follows:

Note: *The **Delay (B-Start)** and **Range (B-Depth)** are also used to adjust the parameters of **Scan Bar**.*

Adjusting Delay (B-Start) & Range (B-DEPTH)




- 1) Press the  key once to activate the measure menu items. Press the  key multiple times to move right and the  key multiple times to move left, until the either the **DELAY (START)** or **RANGE (DEPTH)** cell is highlighted. Alternatively, use the  and  arrow keys on the left button wheel.



- 2) Use the  and  arrow keys on the right button wheel to scroll the **DELAY (START)** and **RANGE (DEPTH)** values.
- 3) Repeat steps 1 & 2 until the range is correctly being displayed.


Alternatively, the **DELAY (START)** and **RANGE (DEPTH)** values can be changed using the **Digit Edit Box** as follows:

- 4) Press the  key once to activate measure menu items. Press the  key multiple times to move right and the  key multiple times to move left, until the either the **DELAY (START)** or **RANGE (DEPTH)** cell is highlighted. Alternatively, use the  and  arrow keys on the left button wheel.




- 1) Press the  key to display the digits edit box.
- 2) Press the  and  arrow keys to scroll the highlighted value.
- 3) Press the  and  arrow keys on the left button wheel to scroll the digit locations.
- 4) Repeat steps **2 & 3** until the **DELAY (START)** or **RANGE (DEPTH)** value is correctly displayed.
- 5) Press the  key to set the **DELAY (START)** and **WIDTH (DEPTH)** value and return to the measure screen, or  to cancel entering the **DELAY (START)** or **WIDTH (DEPTH)** value.
- 6) Finally, press the  key to return to the measurement screen and begin taking readings.


Note: The **DELAY (START)** & **WIDTH (DEPTH)** can also be adjusted from the tabbed menu item **DISP**. However, using the hot menu keys is the easiest method.




RF View



Rectified (RECT) View



Digits View



B-Scan View

In the upper left corner of each of the display photos above, is the repeatability indicator. The repeatability indicator is represented by six vertical bars and represents how repeatable the measurements are. In regular measurement mode, the **FX80** makes 8 measurements a second. In scan mode, the **FX80** makes 200 measurements a second. If the coating mode option is activated, the **FX80** makes 3 measurements a second in regular measurement mode and 65 measurements a second in scan mode. When the **FX80** is idle, only the left vertical bar will be displayed. However, when the **FX80** is making a measurement, four or five of the bars should be displayed on the repeatability indicator. If fewer than four bars are showing, the **FX80** is having difficulty achieving a stable measurement and the thickness value displayed is potentially unstable.

CHAPTER THREE KEYBOARD, MENU, & CONNECTOR REFERENCE




3.1 Menu Key (Operation & Sub Menus)



The **Menu** key activates the primary menu structure containing 10 menu tab groups. These tab groups then contain sub menu items, or functions. The sub menu items have been organized in tab groups according to how closely they are related to the individual tab group names. Let's first get familiar with how to move around in these tabs before continuing on to the sub menu functions. This procedure is outlined below:

Activating and Getting Around in the Menu Items



- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left until the desired tab group is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel. The tab groups are illustrated above **(A)**.

Now that you're familiar with activating and moving amongst the tab groups, let's have a look at how to move around in the sub menu items as follows:

Getting Around in the Sub Menu Items

- 1) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until the desired function is highlighted. The sub menu items are illustrated in the diagram above **(B)**.
- 2) Depending on which function is highlighted, use the  and  arrow keys on the right button wheel to scroll the options, or the  key to activate the **Digit Edit** and **List Box** options.

The sections to follow will provide the user with an explanation of the sub menu functions:

SETUP PROBE	
ZERO PROBE	MANUAL
ZERO COATING	
TYPE	11
PRB	CAL DISP TUNE

3.2 Probe – Menu

ZERO PROBE: The **FX80** is zeroed in much the same way that a mechanical micrometer is zeroed. If the **FX80** is not zeroed correctly, all of the measurements made using the **FX80** may be in error by some fixed value. The **FX80** is equipped with an optional automatic or manual zero feature. Refer to the section on page 50, for an explanation of this important procedure.

ZERO COATING: In order to account for very slight electronic differences in transducers of the same type, frequency, and diameter, the **FX80** has been equipped with a “zero coating” feature. This enables the **FX80** to obtain very accurate readings on coatings, eliminating potential errors incurred from slight differences in the manufacturing processes. Refer to the section on page 50, for a detailed explanation.

TYPE: Enables the user to select the type of transducer being used from a chart of transducer types. This provides increased linearity between transducers. Refer to page 47 for a further explanation.

CALIBRATE	
MAT	CUSTOM
MATL 1PT	0.500
MATL 2PT	0.100
VELOCITY	0.2329
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0850
PRB	CAL DISP TUNE

3.3 CAL – Menu

MAT: Select the material velocity from a chart of basic material types when a known sample thickness, or material velocity cannot be obtained. Refer to page 60 for further info.

MATL 1PT: Performs a single point calibration. This option allows the user to automatically calculate the velocity by entering a known sample thickness. Refer to page 56 for further info.

MATL 2PT: Performs a two-point calibration. This option allows the user to automatically calculate the velocity by entering a second known sample thickness. Refer to page 58 for further info.

VELOCITY: Function to calibrate the **FX80** by setting the velocity to a known material velocity. Refer to page 54 for further info.

COATING 1PT: Performs a single point coating calibration. This option allows the user to automatically calculate the velocity by measuring a known coating sample thickness. Refer to page 109 for further info.

COATING 2PT: Performs a two-point coating calibration. This option allows the user to automatically calculate the velocity by entering a second known coating sample thickness. Refer to page 109 for further info.

COATING VEL: Function to calibrate the **FX80** to a specific coating material type by entering a coating velocity. Refer to page 16 or page 103 for further info.

SET DISPLAY	
VIEW	+RECT
DELAY	0.775
RANGE	1.516
B-SCAN SPEED	6
UNITS	IN
BRIGHTNESS	15
SCREEN UPDATE	60HZ
<MORE>	
PRB	CAL
DISP	TUNE

3.4 DISP (display) – Menu

VIEW: Selectable **BSCAN** (cross section), and **DIGITS** (large digits) views. Refer to page 63 for further info.

DELAY (B-START): Provides the user the ability to change the start position of the B-SCAN view. Refer to page 72 for further info.

RANGE (B-DEPTH): Provides the user the ability to change the overall depth of the viewable measurement area. It functions a lot like a zoom on a camera. Refer to page 74 for further info.

B-SCAN SPEED: Controls the speed of the time based B-Scan with an arbitrary scale of 0-10, with 10 being the fastest scrolling speed. Default speed set at 6. Refer to page 76 for further info.

UNITS: Toggle between English or Metric units. The readout will change from inches to millimeters.

BRIGHTNESS: Blankview high speed color display. An arbitrary scale of 1-20 has been implemented, with the brightest setting at 20. Refer to page 121 for further info.

COLOR: Provides the user with 12 different color schemes to select from. There are two schemes for each main color option. Refer to page 122 for further info.

DIM: Allows the user to conserve battery life by diming the display after idle for a specific amount of time – OFF, 30, 60, 90, 120 seconds. Once dimmed, a single press of any key will restore the screen brightness. Refer to page 124 for further info.

RECT WAVE: This option provides the user an outlined or filled view option when the display setting is in RECT (rectified) wave mode only. Refer to page 126 for further info.

DETECT MARK: Selectable graphics option for the point of detection on the waveform: Line, Box, Dots, None. Offers the user a graphics preference on how they prefer to view the detection on the waveform.

GRATICULE: Selectable graphics option for the A-Scan background (grid/segments) used as references to depth/thickness versus amplitude. The options are: Point, Line, Dots, Mix. Offers the user a graphics preference on how they prefer to view the A-Scan waveform area. Refer to page 128 for further info.

TUNE SIGNAL	
MEASURE MODE	P-E
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
GAIN	46.0
AGC	21
PRB	CAL
DISP	TUNE

3.5 TUNE – Menu

MEASURE MODE: Toggles a variety of unique measurement modes for different application requirements: Coating Off (P-E), Coating On (PECT), Temp Comp (PETP), Thru Coat (E-E), Thru Verify (E-EV), Coating Only (CT). Refer to page 41 for further info.

POLARITY: The **FX80** operates on a zero crossing detection principle. This feature toggles which stroke of the cycle the crossing detection uses, either positive or negative. Refer to page 130 for further info.

PULSE: The **FX80** has an adjustable pulse width for both high penetration and resolution applications. The pulse width refers to the duration of time the pulser is on. The options are **Spike**, **Thin**, and **Wide**. Refer to page 132 for a further explanation.

PULSER VOLTAGE: This feature offers a 50 volt cut/boost to the pulser. The standard setting is 150 volts. This enables the **FX80** to offer greater penetration for difficult material types, or increased resolution on noisy materials. Refer to page 133 for a further explanation.

DAMPING: Provides the user with multiple input impedances to match the impedance of the transducer, and optimized overall transducer performance. Refer to page 125 for further info.

GAIN: The **FX80** has 100dB gain range from (-30 to 70 dB), used in conjunction with the attenuator feature above. This feature is used to increase/decrease the power or amplitude of the signal. This might easily be considered as similar to turning the volume up or down on a stereo receiver. Refer to page 77 for further info.

AGC: This an automatic gain control used in E-E (echo-echo), and E-EV (echo-echo verify). The **FX80** is equipped with an automatic gain control when operating in -E

(echo-echo), and E-EV (echo-echo verify) modes only. This feature automatically increases/decreases the power or amplitude of the signal, to an optimal input to output signal ratio. This might easily be considered as similar to turning the volume up or down on a stereo receiver. Alternatively, the AGC can be manually controlled. The **FX80** is equipped with manual override, using an arbitrary range of 1-20 clicks. The higher the number the better the dynamic gain range, and visa versa. Refer to page 77 for further info.

GAIN SLOPE (TIME DEPENDENT GAIN): Similar to ‘time corrected gain’ but a linear gain ramp that increases the output of the **FX80** at a constant rate over time (dB per microsecond). Can be used in both pulse-echo (P-E) and echo-echo (E-E) modes to overcome attenuative materials. Refer to page 134 for further info.

3.6 GT1 – Menu

GATE ONE					
START					
0.588					
GATE1 WIDTH					
OFF					
THRESHOLD1					
6					
GT1	GT2	GT3	SFT		

GATE1: Gates allow the user to view a specific measurement range, or sections of the waveform, and ignore others. The Gate1 feature adjusts the start of the gate, according to time/distance. Gate 1 can be used in all pulse-echo and echo-echo measurement modes. Refer to page 86 for further info.

GATE1 WIDTH: This feature allows the user to set the overall width of the gate, in terms of distance, from the starting value of Gate1. Refer to page 86 for further info.

THRESHOLD1: Enables the user to set the sensitivity level of Gate1. The amplitude of the signal must reach or exceed the threshold level before a measurement is detected. Refer to page 86 for further info.

3.7 GT2 – Menu

GATE TWO			
GATE2 WIDTH			OFF
HOLD OFF 2			OFF
THRESHOLD2			4
GT1	GT2	GT3	SET

GATE2 WIDTH: This feature allows the user to set the overall width of the gate, in terms of distance, from the starting value of HoldOff2. Refer to page 86 for further info.

HOLDOFF 2: Provides the user with the ability to delay the starting point of Gate2, a specific distance from the first detection point found inside of the boundaries of the

Gate 1 settings. If no detection is found, the Gate1 width value is used as a starting value for Gate2. Refer to page 86 for further info.

THRESHOLD2: Enables the user to set the sensitivity level of Gate2. The amplitude of the signal must reach or exceed the threshold level before a measurement is detected. Refer to page 86 for further info.

GATE THREE			
GATE3 WIDTH		OFF	
HOLDOFF 3		OFF	
THRESHOLD3		3	
GT1	GT2	GT3	SET

3.8 GT3 – Menu

GATE3 WIDTH: This feature allows the user to set the overall width of the gate, in terms of distance, from the starting value of HoldOff3. Refer to page 86 for further info.

HOLDOFF 3: Provides the user with the ability to delay the starting point of Gate3, a specific distance from the first detection point found inside of the boundaries of the Gate 2 settings. If no detection is found, the Gate2 width value is used as a starting value for Gate3. Refer to page 86 for further info.

THRESHOLD3: Enables the user to set the sensitivity level of Gate3. The amplitude of the signal must reach or exceed the threshold level before a measurement is detected. Refer to page 86 for further info.

SETUP OPTIONS			
OPEN			
SAVE			
DELETE			
DEFAULT SETUP			
LANGUAGE		ENGLISH	
GT1	GT2	GT3	SET

3.9 SETUP – Menu

OPEN: Displays a list of factory and user defined setups currently stored in memory. These setups can be recalled and used at any time. Refer to page 169 for further info.

SAVE: Provides the user with the ability to save a custom setup that has been modified or created by the user. Refer to page 171 for further info.

DELETE: Provides the user with the ability to delete specific setups previously save in memory. Refer to page 174 for further info.

DEFAULT SETUP: Loads a basic default setup. Use only as a last resort when the setups in the **FX80** have been corrupted and a computer is not accessible. Refer to page 176 for further info.

LANGUAGE: Provides the user the ability to select different languages for the **FX80**. Refer to page 178 for further info.

STORE DATA	
NEW	SEQ LOG
EDIT	
OPEN	
CLOSE	
DELETE ONE FILE	
DELETE ALL DATA	
DATA	UTIL XFER

3.10 DATA – Menu

NEW: Allows the user the ability to create a new alpha numeric grid, or sequential log file with auto identifiers. It is equipped with custom parameters, rows, and columns depending on the user's application reporting requirements. Refer to page 146 for further info.

EDIT: Gives the user the ability to change parameters of grid or sequential file previously saved. Note: Pre-defined coordinates cannot be changed once they have been created. Refer to page 163 for further info.

OPEN: This function provides the user with the ability to recall grids or sequential log files that currently exist in memory, from a list of grids. Refer to page 165 for further info.

CLOSE: Provides the user the ability to close a currently opened grid or sequential log file. Refer to page 167 for further info.

DELETE ONE FILE: This function provides the user with the ability to delete one individual grid or sequential log file from a list of multiple grids/files previously saved in memory. Refer to page 160 for further info.

DELETE ALL DATA: This function provides the user with the ability to delete all files currently stored in memory. Refer to page 162 for further info.

UTILITIES	
AUTO FIND	
SCAN MODE	ON
ALARM	OFF
ALARM HIGH	1.000
ALARM LOW	0.000
DIFFERENTIAL	0.000
GAUGE	THICKNESS
DATA	UTIL XFER

3.11 UTIL (utilities) – Menu

AUTO FIND: Automatically locates the detection point if the measurement is out of the viewable display area. Refer to page 115 for further info.

SCAN MODE: This function enables a hi speed scan mode that increases the overall sample rate from 65 to 200 measurements per second, depending on the current measurement mode used. Refer to page 115 for further info.

ALARM: Toggles alarm mode on, off, or audible. Refer to page 117 for further info.

ALARM HIGH: Gives the user the ability to set the HI limit parameter. If the measurement exceeds this value, a red light will illuminate and sound the internal beeper. Refer to page 117 for further info.

ALARM LOW: Gives the user the ability to set the LO limit parameter. If the measurement falls below this value, a red light will illuminate and sound the internal beeper. Refer to page 117 for further info.

DIFFERENTIAL: Gives the user the ability to set a nominal value and the **FX80** will display +/- the difference from the nominal value entered. Refer to page 119 for further info.

GAUGE: Gives the user the ability to select between the two gauge types included in the **FX80**, thickness gauge or flaw detector. Refer to page 5 for further info.

ANALOG OUTPUT: Proportional output (thickness), 0-10 volts. Speed is determined by the **PRF** setting. Refer to page 136 for further info.

SERIAL OUTPUT: Proportional outputs (thickness), 0-10 volts. Speed is determined by the **PRF** setting. Refer to page 137 for further info.

KEY CLICK: Gives the user the ability to set the level of the key press beeper OFF, QUIET, or LOUD. Refer to page 138 for further info.

SET DATE: Gives the user the ability to set the internal date and time stamp in the **FX80**. Refer to page 139 for further info.

SHOW DATE: Gives the user the ability to display the date and time in the waveform area of the **FX80**. The options are OFF, DATE, TIME, BOTH. Refer to page 141 for further info.

DATA TRANSFER	
COPY SETUPS	
COPY DATA	
COPY SCREENS	
UPGRADE GAUGE	
CAPTURE TO FILE	YES
STORAGE	EXTERNAL
ABOUT	DEV 0.03G
DATA UTIL	XFER

3.12 XFER (transfer) – Menu

COPY SETUPS: Copies setup files from either the internal or external SD memory card to the other memory card, depending on the current internal/external setting of **Storage** (current device being used to store data), located in the XFER menu. Refer to page 181 for further info.

COPY DATA: Enables the user to copy all, or individual grid/log files from either the internal or external SD memory card to the other memory card, depending on the current internal/external setting of **Storage** (current device being used to store data), located in the XFER menu. Refer to page 181 for further info.

COPY SCREENS: Copies screen capture (.tif's) files from either the internal or external SD memory card to the other memory card, depending on the current internal/external setting of **Storage** (current device being used to store data), located in the XFER menu. Refer to page 181 for further info.

UPGRADE GAUGE: Enables the user the ability to upgrade the **FX80** to the most current firmware revision. Refer to page 183 for further info.

CAPTURE TO FILE: Enables the user the ability to enable screen captures to .tiff files, and used in conjunction with the  key. Refer to page 141 for further info.

CAPTURE VIEWER: Enables the user to view all the captured (.tif) files stored in the **FX80** on the gauge display. Refer to page 143 for further info.

STORAGE: Enables the user to select which SD memory card to use for storage. Note: if no card exists in the external reader slot, this option will be grayed out and inactive. Refer to page 180 for further info.

ABOUT: Provides the user with Dakota NDT contact information and the **FX80** software version. Refer the Dakota NDT web site for information on the latest firmware versions available for download.

3.13 CLR (clear) Key



The primary functions of the **CLR** key, is to clear a measurement from a grid or sequential log files cell location or set obstruct, and backspace in an **Alpha Edit Box**. If a user has already saved a measurement and B-Scan to a cell location, use this key to clear the measurement at any time.

3.14 HOME (measurement mode) Key



The **HOME** key puts the **FX80** into it's primary mode of operation. In this mode, the user has a complete view of the LCD.

3.15 OK Key



The primary function of the **OK** key is confirmation of a change or selection. The **OK** key also toggles the Hot Menu area, while in measurement mode, to a large digits display area. If the **FX80** is displaying a grid log, the **OK** key toggles an advance to row number option.



3.16 ESC Key



The **ESC** key is used in conjunction with the , , and **EDIT** functions as a back or escape function. If the **FX80** is displaying a grid or sequential log, the



OK key toggles the display options: Digits, RF, RECT, and B-Scan views.



3.17 Wheel Keys

The **Wheel Keys** are used to navigate through the menus, increase/decrease values, and toggle specific function keys.



3.18 ENTER key

The **ENTER** key is used in the overall menu selection process, to activate list and edit boxes, display and save measurements to grid or sequential files locations.



3.19 MULTI MODE Key

The MULTI MODE key opens a measurement mode screen, listing all the modes that are available to the transducer specifically selected, or auto detected. The modes can be all or a combination of the entire set of modes the **FX80** offers, depending on which transducer is being used as follows: **Coating Off (P-E)**, **Coating On (PECT)**, **Temp Comp (PETP)**, **Thru Coat (E-E)**, **Thru Coat Verify (E-EV)**, and **Coating Only (CT)**.



3.20 DATA Key

The **DATA** key opens the tabbed data menu, allowing a user to efficiently create a new log/grid file for storage.



3.21 STORE Key

The **STORE** key displays the current log/grid opened in split screen mode. If no log/grid file is open, the **STORE** key will open the tabbed data menu in order create a new, or open an existing log/grid file for storage.

3.22 PEAK Key



The **PEAK** key is a feature used in the flaw detector portion of the **FX80**, and is not used in the thickness gauge.

3.23 FREEZE Key



The **FREEZE** key is used to freeze the display for evaluation/review of what's currently on the display. It is also used in conjunction with the **CAPTURE** feature to save the current display to a .tif (tagged image) graphic file that can be opened using any graphics viewer.

3.24 ON/OFF Key



The **ON/OFF** key simply powers the unit either **ON** or **OFF**. Note: Unit will automatically power off when idle for 5 minutes. All current settings are automatically saved prior to powering off.

3.25 Navigating the Hot Menus

DELAY 0.775	ZERO PROBE MANUAL	MAT STL4340	VIEW DIGITS	START 0.588	WIDTH 2 0.830	WIDTH 3 OFF
RANGE 3.337	ZERO COAT	MATL 1PT UNCAL	UNITS IN	WIDTH 1 OFF	HOLDOFF 2 0.095	HOLDOFF 3 0.012
AGC 12	TYPE 11	MATL 2PT UNCAL	MODE PECT	THRESH 1 5	THRESH 2 4	THRESH 3 2
THRESH 1 5		VELOCITY 0.2330	POLARITY POSITIVE			
START 0.881		COAT 1PT UNCAL	PULSE THIN			
WIDTH 1 OFF		COAT 2PT UNCAL	PULS VOLT 150			
HOLD2 0.095		COAT VEL 0.0850	DAMPING 100			
LOG CLOSED						
			AUTO FIND			
			SCAN MODE OFF			
			ALARM ON			
			ALARM HIGH 1.000			
			ALARM LOW 0.000			
			DIFF OFF			

The diagram above is a screenshot of all 8 “Hot Menu” in the **FX80**. The Hot Menu’s contain all the most regularly adjusted features from each tabbed menu, in the exact order of the tabbed menus themselves. Some of the menus have been combined into a single Hot Menu, in order to reduce the number of Hot Menu (i.e. GT1 & GT2 have been combined into a single Hot Menu). The primary purpose of the design was to provide the user with an efficient way to make adjustments on the fly, while continuing to have visibility of the A-Scan display. The following procedure outlines the steps to navigate and make adjustments as follows:

Navigating Hot Menu

- 1) Using the left button wheel, press the  and  arrow keys to scroll through the 8 individual **Hot Menu**, and the  and  arrow keys to scroll through the **Hot Menu** items. Alternatively, the  &  keys can be used to scroll through the **Hot Menu** items.


- 2) Press the  and  arrow keys multiple times on the right button wheel to toggle the value or status.

Note: *This is a coarse adjustment. It’s the fastest and easiest way to increment, decrement, or toggle the status however it does so in coarse steps.*

Pressing the  key will allow the user to enter a specific target value.

This procedure above is universal for navigating through and selecting all the features in the Hot Menu.

3.26 Top & Bottom End Caps



The top & bottom end panels are where all connections are made to the **FX80**. The diagram above shows the layout and description of the connectors:

Transducer Connectors

Refer to Diagram: The transducer connectors, emergency battery backup channels/probe zero disks, power connector and auxiliary connector are located on the **FX80's** top end cap. The transducer connectors are of type Lemo "00". Note: There is no polarity associated with connecting the transducer to the **FX80**.

Probe Zero Disk & Battery Cover

Refer to Diagram: The emergency battery backup disks are the large round disks shown in the diagram. **Note:** This same disk is also used as a probe zero disk. Simply remove the cover when replacing the batteries (3 AA cells) for each. When performing a manual probe zero function, simply place the transducer on disk making firm contact. **Important:** Be sure to follow the polarity label located on the back label of the **FX80**. **Note:** Rechargeable batteries can be used, however they must be recharged outside of the unit in a standalone battery charger.

USB Type B Connector

Refer to Diagram: The **USB** connector is a common type B connector found on a variety of electronic devices. This port will be used to transfer stored grid/log files, captured screen shots, etc. This connector will also be used to upgrade the **FX80** with the latest version of firmware (gauge software). The cable supplied with the **FX80** is USB type A to USB type B.

RS-232 Serial Connection (LEMO 1 – 5 pin)

Refer to Diagram: The **RS-232** connector is a 5 pin female Lemo 1 connector. It is designed to connect directly from the **FX80** to a standard AT serial port on a PC, and will be used in conjunction with our proprietary java application software called "Remote Commander". The primary purpose of the Remote Commander software, will be for use in conjunction with a projector connected to a PC for classroom training programs and demonstration purposes. An accessory 9 pin female serial to Lemo 1 - 5 pin male cable will be required to use this feature, and is not included in the standard kit.

Alarms Connection (LEMO 1 – 5 pin)

Refer to Diagram: The **RS-232** connector is a 5 pin female Lemo 1 connector. This is used for connecting each alarm directly to an external source. An accessory 9 pin female serial to Lemo 1 - 5 pin male cable will be required to use this feature, and is not included in the standard kit.

Power Connector (LEMO 1 – 2 pin)

Refer to Diagram: The Lemo 1 2 pin connector is used for direct line power and charging the Li-Ion battery pack.

CHAPTER FOUR

PRINCIPALS OF ULTRASONIC MEASUREMENT

4.1 Time versus thickness relationship

Ultrasonic thickness measurements depend on measuring the length of time it takes for sound to travel through the material being tested. The ratio of the thickness versus the time is known as the sound velocity. In order to make accurate measurements, a sound velocity must be determined and entered into the instrument.

The accuracy of a thickness measurement therefore depends on having a consistent sound velocity. Some materials are not as consistent as others and accuracy will be marginal. For example, some cast materials are very granular and porous and as a result have inconsistent sound velocities.

While there are many different ultrasonic techniques to measure thickness, which will be discussed below, all of them rely on using the sound velocity to convert from time to thickness.

4.2 Suitability of materials

Ultrasonic thickness measurements rely on passing a sound wave through the material being measured. Not all materials are good at transmitting sound. Ultrasonic thickness measurement is practical in a wide variety of materials including metals, plastics, and glass. Materials that are difficult include some cast materials, concrete, wood, fiberglass, and some rubber.

4.3 Range of measurement and accuracy

The overall measurement capabilities, based on the wide variety of materials, is determined by the consistency of the material being measured.

The range of thickness that can be measured ultrasonically depends on the material as well as the technique being used and the type of transducer. Thickness measurements can be made from a minimum of 0.010 inch to 100 feet in steel. However, the maximum attainable thickness is much less for more attenuative materials (materials that absorb sound).

Accuracy, is determined by how consistent the sound velocity is through the sound path being measured, and is a function of the overall thickness of the material. For example, the velocity in steel is typically within 0.5% while the velocity in cast iron can vary by 4%.

4.4 Couplant

All ultrasonic applications require some medium to couple the sound from the transducer to the test piece. Typically a high viscosity liquid is used as the medium. The sound frequencies used in ultrasonic thickness measurement do not travel through air efficiently. By using a liquid couplant between the transducer and test piece the amount of ultrasound entering the test piece is much greater.

4.5 Temperature

Temperature has an effect on sound velocity. The higher the temperature, the slower sound travels in a material. High temperatures can also damage transducers and present a problem for various liquid couplants.

Since the sound velocity varies with temperature it is important to calibrate at the same temperature as the material being measured.

Normal temperature range

Most standard transducers will operate from 0°F to 180°F.

High temperature measurements

Special transducers and couplants are available for temperatures above 180°F up to 900°F with intermittent contact. It is necessary to cool the transducer, by submerging the transducer in water between readings, when measuring high temperatures.

Modes and temperature errors

In addition to errors caused by velocity changing with temperature, some modes (measurement techniques) are affected more than others. For example, dual element pulse-echo mode has larger errors due to changes in the temperature of the delay line. However, multi-echo techniques offer temperature compensation help to minimize these errors.

4.6 Measurement Modes

In this section we will discuss the different measurements modes the **FX80** is capable of operating in, the transducers required, and the reasons for using specific modes:

Pulse-Echo Mode (Flaw & Pit detection) – Coating Off (P-E)

Pulse-echo mode measures from the initial pulse (sometimes referred to as an artificial zero) to the first echo (reflection). In this mode, either an automatic or manual zero can be performed depending on the zero probe function setting. If the manual mode has been selected, the transducer is placed on a reference disk, located on top of the **FX80**, and a key is pressed to establish a zero point for the particular transducer. If the Auto Zero feature is enabled, a simple key press will perform an electronic zero to establish the same zero point.

In this mode errors result from surface coatings and temperature variations.

Since pulse-echo only requires one reflection, it is the most sensitive mode for measuring weak reflections (flaws) typically found when measuring heavily corroded metals.

V-Path Correction


Dual element delay line transducers have two piezoelectric elements mounted at an angle on one end of the delay line. One element is used for transmitting sound, while the other element only receives sound. The two elements and their delay lines are packaged in a single housing but acoustically isolated from each other with a sound barrier. This allows the transducer the ability to achieve very high sensitivity for

detecting small defects. Also, the surface of the test material does not have to be as flat in order to obtain good measurements.

Dual element transducers are normally used in pulse-echo mode for finding defects, and in echo-echo mode for through coating measurements.

Dual element delay line transducers are usable over a range starting as thin as 0.025 inches and up, depending on the material, frequency, and diameter.

A limitation of dual element delay-line transducers is the V shaped sound path. Because the sound travels from one element to another, the time versus thickness relationship is non-linear. Therefore, a correction table in the instruments software is used to compensate for this error.




Searching for small defects

Dual element delay line transducers are especially useful in searching for small defects. In the pulse-echo mode with high amplifier gain, very small defects can be measured. This is very useful during corrosion inspections overall. The dual element style transducer will find wall deterioration, pits, and any porosity pockets during tank and pipeline inspections.

Echo-Echo Mode – Thru Coat (E-E)


The echo-echo mode measures between two reflections. This technique is commonly used to eliminate errors from surface coatings and also to make measurements in multiple layered materials. The disadvantage is that two echoes are needed which requires a much stronger echo (reflection).



Echo-Echo Verify Mode – Thru-Verify (E-EV)

The echo-echo verify mode measures between 3 reflections. Similar to E-E mode, this technique is commonly used to eliminate errors from surface coatings and also to make measurements in multiple layered materials. The primary benefit of this mode, is that a comparison is made, between the 2nd and 3rd echoes, to verify that a peak

jump has not occurred, providing an additional level of confidence to the measurement. The disadvantage is that 3 reflections are needed which requires the use of gates with controllable thresholds to adjust for sensitivity over a given measurement range.



Pulse Echo Coating Mode – Coating On (PECT)

A custom hybrid combination mode using properties from the basic modes along with a group of special techniques and theoretical wave phenomena's to measure coating and material thicknesses at the same time, while still retaining the ability to locate flaws and pits in materials. Therefore, the best description for this hybrid mode is Pulse-Echo Coating mode.

Coating Mode – Coating Only (CT)

Once again, this is a custom hybrid combination mode using special techniques to effectively measure the thickness of coatings that are either adhered to metallic surfaces or in standalone form. In this mode a two point calibration must be performed. If the user will be measuring coating that has been applied to a metal surface, the calibration must be performed using coating samples coupled to a metal surface when calibrating. To explain further, a drop of couplant must be applied in between the coating samples and metal surface. If the coating has not been applied to a metal surface, the calibration should be performed accordingly.

Pulse-Echo Temperature Compensated Mode – Temp Comp (PETP)

This is a custom mode that combines pulse-echo and electronic zero techniques to automatically adjust for temperature changes in the transducer as a result of an increasing/decreasing temperature gradient in the test material. Note: rough surface conditions can have an effect on the overall accuracy in this mode. If the surface condition is in question, the pulse-echo mode should be used in conjunction with performing an off block automatic zero as the temperature gradient changes.

CHAPTER FIVE

SELECTING THE MEASUREMENT MODE

5.1 The setup library

The **FX80** contains 64 user configurable preset locations to store custom setups for easy recall. These setups can be optimized for the user's specific application needs and can also be stored on a PC and transferred bi-directionally using Dakota's PC interface software included with the instrument.

The setups supplied with the instrument cover some of the more typical applications commonly used with this type of instrument. These setups can be recalled, modified, and overwritten to one of 64 setup locations. Therefore, these factory setups can also be considered a good starting point to be modified for custom applications. The PC software includes a default setup file that can be uploaded to the gauge at any time to restore factory settings. However, it is recommended that the user consider saving modified setups to an empty location rather than overwriting the factory setups in the **FX80**. Once again, these factory settings are excellent starting points for custom setups.

5.2 Which mode & transducer do I use for my application?

High penetration plastics and castings

The most common mode for these types of applications is pulse-echo. The FX80 has been optimized for cast materials. Cast iron applications require 1 - 5MHz frequencies, and cast aluminum requires a 10MHz frequency. Plastics typically require lower frequencies depending on the thickness and make-up of the material. Larger diameters offer greater penetration power because of the crystal size, for difficult to measure materials.

Corrosion & Pit Detection in steel and cast materials

Use pulse-echo mode whenever attempting to locate pits and flaws. Typically a 5MHz transducer, or higher, will be used for these types of applications. Use low frequencies for greater penetration and use higher frequencies for better resolution.

Measuring Material & Coatings

The pulse-echo coating mode should be used when both material and coating thickness are required, while still requiring the ability to detect flaws and pits. A special coating style transducer is required for use in this mode. There are a variety of coating transducers in various frequencies available from Dakota.

Thru Paint & Coatings

Often times, users will be faced with applications where the material will be coated with paint or some other type of epoxy material. Since the velocity of the coating is approximately 2.5 times slower than that of steel, pulse-echo mode will induce error if

the coating or paint is not completely removed. By using echo-echo mode, the user is able to successfully measure through both, the coating and steel, and completely eliminate the thickness of the paint or coating. Therefore, the steel can be measured without having to remove the coating prior to measuring. Users will often use pulse-echo mode and echo-echo mode in conjunction when performing inspections on coated materials.

Thru coating measurements require special high damped transducers. The most common transducers are the 3.5, 5, and 7.5MHz hi damped transducers. These transducers are suitable for use in both pulse-echo and echo-echo modes. This conveniently enables the user to accurately measure overall material thickness using the thru Coating mode, and then conveniently switch to pit detection mode without changing transducers. The 1/4" 5MHz Hi damped transducer is the most commonly used transducer for standard thru coating applications.

Coating Only

The coating only mode should be used when the application calls for coating measurements only and the user is not interested in the thickness of the material the coating has been applied to. This mode can also be used as a standalone coating thickness gauge, where the coating has not been applied to another material surface. An auto identified coating probe must be attached to the **FX80** in order to enable this mode.

Thin materials

Use pulse echo mode and a high frequency transducer for these types of applications. The most common transducers are the 7.5MHz and 10MHz models with extra resolution. The higher frequencies provide greater resolution and a lower minimum thickness rating overall.

High temperature

Use and select a special 2.25MHz and 5 MHz High temperature transducer for these types of applications. Both pulse-echo and echo-echo modes will also work for these applications. However, echo-echo mode will eliminate error caused by temperature variations in the delay line of the transducer.

Noisy Material

Materials such as titanium, stainless steel, and aluminum may have inherent surface noise issues. This is a signal that appears at the surface of the material when using a dual element delay line probe. Select a higher frequency transducer to reduce this noise – 7.5MHz and higher for better resolution.

Restricted access

Measuring materials with extreme curvatures or restricted access, higher frequencies with smaller diameters should be considered. The smallest diameter uses 3/16" crystals with a contact area of .250". Custom transducers are available on request.

5.3 Factory Setup Chart

Num	Name	Comment 1	Gn/AGC	Velocity
1	Enter Custom Name			
2	...			
3	...			
4	...			
5	...			
6	...			
...	...			

CHAPTER SIX

MAKING MEASUREMENTS

The steps involved in making measurements are detailed in this section. The following sections outline how to setup and prepare your **FX80** for field use.

An automatic or manual zero must always be performed. The auto zero is an off block electronic zero that does not require a zero reference block. This will most always be the zero option of choice, as it makes the zeroing process very easy and convenient to perform. However, If the manual zero option is enabled, the probe zero must be measured on the reference disk (battery disk) attached to the top of the instrument. The zero compensates for variations in the transducer. In all modes the sound velocity must be determined. The sound velocity is used to convert the transit time to a physical length. The sound velocity can be selected from a material chart in the manual, selected from a material list in the **FX80**, or for greater precision determined from a sample of the test material that has been mechanically measured. To enter the velocity from a table, look up the material on the chart in the appendix of this manual and refer to the section below on Calibration to a Known Velocity. To determine the velocity of a single sample, refer to the Material Calibration section on page 56.

When measuring curved materials, it is more accurate to calibrate from two test points, one at the minimum limit of the target thickness and one at the maximum limit. In this case the reference disk mounted to the **FX80** is not used. This is called two-point calibration and is described on page 58.

6.1 Auto Probe Recognition & Selecting the Transducer Type

The first step in using the **FX80** is to plug the transducer into the gauge and power the unit up. The **FX80** has a special built-in automatic probe recognition feature that will check to see if the probe plugged into the gauge is an auto recognized probe type. If so, the **FX80** will display a message indicating the transducer type and ask the user for confirmation to use the identified probe. If the transducer is not an auto recognized probe, the **FX80** will display a message indicating the transducer type has not been recognized, and force the user to select a transducer type from a list of transducers according to frequency and diameter. Whether the transducer is auto recognized or selected from a predefined list, the **FX80** will recall specific properties about the transducer. **Note:** Once the transducer has been selected, the **FX80** will store and recall this transducer type every time the **FX80** is powered on/off. The type will only change if the user physically selects another type from the list, or selects a previously saved setup. Therefore, if you have previously gone through this section and selected the transducer you are using, proceed to the next section. Use the following steps to select your transducer type. **Note:** If the transducer is not identified on power up, be sure the transducer type selected is the same as the transducer plugged into the **FX80**. **Failure to do this will result in erroneous measurements:**

In this first example the transducer was automatically identified:

Probe Automatically Recognized

CONFIRM	
1/4IN - 5.0MHZ COAT PROBE IDENTIFIED.	
USE THIS PROBE?	
OK	ESC

- 1) Press the  key once to use the identified probe, or  to display a list of optional transducers. *Note: if the **FX80** recognizes a specific transducer, the user should always select  to use the identified probe. The only time an alternative probe should be selected from a list is if the user switched probes following initial power up and recognition, or the **FX80** has somehow identified the probe in error..*

- 2) Assuming the **FX80** recognized the probe and the  key was pressed, the **FX80** will advance to a Zero Probe menu. If the transducer was identified as a special transducer capable of measuring coating thickness, a menu will be displayed allowing the user the ability to toggle the coating thickness display on/off as follows:

ZERO PROBE	
COATING:	ON
COATING:	OFF
SELECT COATING ON/OFF - REMOVE COUPLANT FROM PROBE AND PRESS OK KEY TO PERFORM THE ZERO	
OK	ESC

- 3) Press the  and  arrow keys on the left button wheel to toggle the coating option on/off.

- 4) Wipe all couplant from the transducer face and proceed to the Probe Zero section that follows.

In this second example the transducer was not identified and will force the user to select the transducer type from a predefined list of transducers:

Selecting the Transducer Type

CONFIRM	
UNIDENTIFIED PROBE TYPE - SELECT A PROBE FROM LIST	
?	
OK	ESC

- 5) Press the  or  keys to display the factory list of transducer types (by diameter and frequency).

PROBE TYPE	
1.	3/16IN - 5.0MHZ
2.	3/16IN - 7.5MHZ
3.	3/16IN - 10.0MHZ
4.	3/16IN - 5.0MHZ HD
5.	3/16IN - 7.5MHZ HD
6.	3/16IN - 5.0MHZ COAT
7.	3/16IN - 7.5MHZ COAT
8.	1/4IN - 2.25MHZ
9.	1/4IN - 5.0MHZ
10.	1/4IN - 5.0MHZ HD
11.	1/4IN - 5.0MHZ COAT
12.	1/4IN - 7.5MHZ

- 6) Press the  and  arrow keys on the left button wheel to scroll through the transducer list until the appropriate type is highlighted.

CONFIRM

OVERWRITE EXISTING
PROBE TYPE

?

OK

ESC

7) Press the  key to select the transducer type and display overwrite existing probe screen.

8) Press the  key to overwrite the existing probe type with the newly selected probe type. The zero probe screen will be displayed. Proceed to the zero probe section that follows.

6.2 Probe zero

The next step is to perform a probe zero. The zero function is a very important and necessary function that must be done prior to calibration. It should be done on a regular basis. In fact, the **FX80** has been programmed to force this issue at regular intervals during operation if it hasn't been done. If the **FX80** is not zeroed correctly, all the measurements taken may be in error by some fixed value. When the **FX80** is using the auto zero (electronic zero), the **FX80** can be in any measurement mode. However, when the manual zero is being used, the **FX80** must be in pulse-echo mode in order to perform the zero. The **FX80** will also see to it that this occurs by simply forcing the gauge into this mode when zero. Therefore, if the **FX80** is in the echo-echo measurement mode and a manual zero is being performed, the **FX80** will put the gauge into pulse-echo mode automatically before performing the zero. While this is a very convenient feature of the **FX80**, the user should be sure to check the measurement mode following calibration to be sure the **FX80** is in the desired mode. The following steps outline both of these techniques.

The **FX80** is equipped with two zero options:

- 1) **Off Block Zero (Automatic Probe Zero)** – When this feature is enabled the **FX80** will do an electronic zero automatically, eliminating the need for a zero disk or block.
- 2) **On Block Zero (Manual Probe Zero)** – When this feature is enabled the transducer must be placed on the probe zero disk (battery cover located on the top of the unit).

Both zero procedures are outlined as follows:

Performing an Auto Probe Zero (Off Block)

ZERO PROBE	
COATING:	ON
COATING:	OFF
SELECT COATING ON/OFF - REMOVE COUPLANT FROM PROBE AND PRESS OK KEY TO PERFORM THE ZERO	
OK	ESC

Coating Probe Identified

ZERO PROBE	
REMOVE COUPLANT FROM PROBE. PRESS OK KEY TO PERFORM THE ZERO	
OK	ESC

Coating Probe Not Identified

- 1) Be sure all couplant has been removed from the face of the transducer.
- 2) Press the  key to perform the automatic probe zero, or  key to cancel the zero operation.
- 3) The screens illustrated above will be briefly displayed followed by the main measurement screen. The **FX80** is ready to be calibrated.

Performing a Manual Probe Zero (On Block)




Note: When the zero probe option is set to manual, the probe zero disk (battery cap) located on the top of the gauge will be used as a zero standard and the warning screen illustrated above will be displayed.


- 1) Press the  or  keys to enter the main measurement screen and begin the manual zero process.
- 2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the probe zero disk and obtain a steady reading.
- 3) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **PRB** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 4) Press the  and  arrow keys on the left button wheel to scroll through the sub menu items until **ZERO PROBE** is highlighted.



Coating Probe Identified



Coating Probe Not Identified

- 5) Press the  key to display the confirmation screen.
- 6) If a coating transducer was identified use the  and  arrow keys on the left button wheel to toggle coating on/off.
- 7) Press the  key to complete the probe zero function, or  key to cancel the probe zero function.
- 8) Remove the transducer from the probe zero disk, and proceed to the calibration section.

Note: *The value that is displayed will change depending on the current velocity setting in the **FX80**. Disregard the number that is displayed. **It is not important.** What is important is accurately performing the steps outlined above to insure reliability of the probe zero calculation.*

6.3 Material Calibration

In order for the **FX80** to make accurate measurements, it must be set to the correct sound velocity of the material being measured. Different types of materials have different inherent sound velocities. For example, the velocity of sound through steel is about 0.233 inches per microsecond, versus that of aluminum, which is about 0.248 inches per microsecond. If the gauge is not set to the correct sound velocity, all of the measurements the gauge makes will be erroneous by some fixed percentage.

The **One Point** calibration is the simplest and most commonly used calibration method - optimizing linearity over large ranges. The **Two Point** calibration allows for

greater accuracy over small ranges by calculating the probe zero and velocity. The **FX80** provides four simple methods for setting the sound-velocity outlined below:

Known Velocity

If the material velocity is known, the user may wish to simply enter the velocity number into the **FX80**, rather than have the **FX80** calculate the velocity value using a known thickness on a material sample. The steps for entering the velocity are outlined below:


Using a Known Material Velocity

CALIBRATE	
MAT	CUSTOM
MATL 1PT	UNCAL
MATL 2PT	UNCAL
VELOCITY	0.2330
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0823
PRB	CAL DISP TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **VELOCITY** is highlighted.



- 3) Press the  key to display the **Digits Edit Box**.
- 4) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.
- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.
- 6) Repeat steps **4 & 5** until the velocity number is correctly displayed.
- 7) Press the  key to set the velocity and return to the menu screen, or  to cancel entering the velocity.
- 8) Finally, press the  key to return to the measurement screen and begin taking readings.

Known Thickness

Sometimes the sound velocity of a material is unknown. In this case a sample with one or two known thicknesses can be used to determine the sound velocity. As previously discussed, the **FX80** has a one or two point calibration option. The one point calibration option is most suited for linearity over large ranges, as noted above. The user should also consider calibrating on high side of the intended measurement range, when using the one point option, minimize overall error. For example, if the measurement range is .100" (2.54mm) to 1.0" (25.4mm), the user should calibrate on a known thickness sample close to 1.0" (25.4mm). Note: It's always handy to carry a set of mechanical calipers to use in conjunction with the **FX80** for calibration in the field:

One Point Calibration


CALIBRATE	
MAT	CUSTOM
MATL 1PT	0.500
MATL 2PT	UNCAL
VELOCITY	0.2342
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0850
PRB	CAL
DISP	TUNE

Note: Be sure that the probe zero procedure has been performed prior to performing this calibration procedure.

- 1) Physically measure an exact sample of the material or a location directly on the material to be measured using a set of calipers or a digital micrometer.
- 2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the sample or actual test material. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable. Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and

displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 3) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **MATL 1PT** is highlighted.



- 4) Press the  key to display the **Digits Edit Box**.
- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

- 6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

- 7) Repeat steps **5 & 6** until the known thickness value is correctly displayed.

- 8) Press the  key to calculate the velocity and return to the menu screen, or  to cancel the one point calibration.

- 9) Finally, press the  key to return to the measurement screen and begin taking readings.

Note: CHECK YOUR CALIBRATION! Place the transducer back on the calibration point. The thickness reading should now match the known thickness. If the thickness is not correct, repeat the steps above.

At some point there may become a requirement for improved accuracy over a smaller measurement range. In this case, a two point calibration would be most suited for the job. For example, if the measurement range was .080" (2.03mm) to .250" (6.35mm), the user would perform a one point calibration on a known thickness sample close to .250" (6.35mm), followed by a two point calibration close to .080" (2.03mm). When a two point calibration is performed, the **FX80** calculates the zero and the velocity. The following steps outline this procedure:


Two Point Calibration

CALIBRATE	
MAT	CUSTOM
MATL 1PT	0.500
MATL 2PT	0.100
VELOCITY	0.2338
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0823
PRB	CAL
DISP	TUNE

- 1) Physically measure an exact sample of the material or a location directly on the material to be measured using a set of calipers or a digital micrometer.
- 2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the sample or actual test material. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable. Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and

displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 3) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **MATL 2PT** is highlighted.



- 4) Press the  key to display the **Digits Edit Box**.
- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

- 6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

- 7) Repeat steps **5 & 6** until the known thickness value is correctly displayed.

- 8) Press the  key to calculate the velocity and return to the menu screen, or  to cancel the one point calibration.

- 9) Finally, press the  key to return to the measurement screen and begin taking readings.

Note: *CHECK YOUR CALIBRATION!* Place the transducer back on the calibration point. The thickness reading should now match the known thickness. If the thickness is not correct, repeat the steps above.

Basic Material Type

If the material velocity is unknown, and a sample thickness cannot be taken from the material, the user may opt to choose a basic material type from a list with approximate velocity values according to various material types. It's important to note that these velocities will not always be an exact representation of the material being tested. Use these values only if a close approximation is acceptable. Follow the steps below to select a basic material type:

Selecting a Basic Material Type

CALIBRATE	
MAT	CUSTOM
MATL 1PT	0.500
MATL 2PT	0.100
VELOCITY	0.2338
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0823
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **MAT** is highlighted.

MATL TYPE	
25. QUARTZ GLASS	0.2260
26. RUBBER, VULCAN	0.0910
27. SILVER	0.1420
28. STEEL <1020>	0.2320
29. STEEL <4340>	0.2330
30. STEEL, STAIN.	0.2230
31. TEFLON	0.0540
32. TIN	0.1310
33. TITANIUM	0.2400
34. TUNGSTEN	0.2040
35. URANIUM	0.1330
36. WATER	0.0580

3) Press the  key to display the list of material types.

4) Press the  and  arrow keys multiple times using the left button wheel to scroll through the material list until the appropriate material is highlighted.

CALIBRATE	
MAT	STEEL (4340)
MATL 1PT	UNCAL
MATL 2PT	UNCAL
VELOCITY	0.2330
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0823
PRB	CAL
DISP	TUNE

5) Press the  key to overwrite the material type and display the menu items with the new material type selected.

6) Finally, press the  key to return to the measurement screen and begin taking readings.

To calibrate the **FX80** for a specific type of coating using samples with known thicknesses, please refer to **chapter 9 – Pulse-Echo Coating (PECT) or Coating (CT)** for a complete explanation of using the **FX80** for coating measurements.

CHAPTER SEVEN

USING THE DISPLAY OPTIONS


A key feature of the **FX80** is the ability to toggle between four different display options; Digits, RF, RECT and B-Scan. All views provide a digital readout of base material and coating thickness measurements, while also displaying the alarm tolerances, if active. A key feature of the **FX80** is the waveform display. The waveform is a graphical representation of the sound reflections returning to the transducer. Consider standing at the base of a canyon and screaming “Hello There”. After a brief delay, you will here multiple echoes, “Hello There’s” repeated back to you. The waveform display shows the amplitude of the signal received on the vertical (Y) axis and time (shown in units of thickness) on the horizontal (X) axis. The waveform display is very useful for viewing and adjusting the location of the gates. The gates are typically used to eliminate potential surface noise by adjusting the starting point in single echo modes, for multi echo measurement modes, as well as to adjust the threshold (sensitivity) in either mode. The waveform display is also very useful for locating pits and internal flaws in materials.

The B-Scan display is also very useful when scanning surfaces and viewing the cross section of the test material. It provides a convenient way of visually profiling, or drawing a picture of, the blind surfaces during a scan. The B-Scan display is also equipped with a scan bar representing the overall thickness. The scan bar gives the user a visual indication when a flaw or defect passed over during the scan process. The scan bar will deflect off of the defect and return back to the overall thickness. Visually, this is much easier to notice than watching for changes in the digital value displayed. The scan bar has also been included in the large digits display mode for the same purpose.

Note: *The following chapter outlines some of the fine adjustment features of the **FX80**. The **FX80** has four different display options (**RF A-Scan, Rectified A-Scan, B-Scan, and Large Digits**). We’ll take a better look at these options in this chapter.*

Note: *In order to recall and use the new adjustments made to the **FX80** at a later time, the user must save the modified settings in one of the setup locations prior to powering off the unit. Refer page 169 for more information on setups.*

7.1 Display Views



DIGITS

The Digits view is a basic digital thickness gauge look and feel. The larger digits make it much easier for the operator to monitor the thickness readings. The Scan Bar has also been added to the Digits view to provide the user with yet another visual tool for easily monitoring changes in thickness readings due to internal flaws or defects.

The following is a list of the viewable features on the display:

- A. **Repeatability/Stability Indicator** – This indicator should be commonly used in conjunction with the digital thickness values displayed. When all the vertical bars are fully illuminated and the last digit on the digital thickness value is stable, the **FX80** is reliably measuring the same value 3 to 200 times per second, depending on which measurement mode and features are enabled.
- B. **Battery Icon** – Indicates the amount of battery life the **FX80** has remaining.
- C. **Velocity** – The material velocity value the **FX80** is currently using or calibrated for. Displayed in English or Metric units, depending on the what units the gauge is set for.
- D. **Feature Status Bar** – Indicates the features currently enabled and in use in the following order:
 - Measurement Mode (P-E, PECT, PETP, E-E, E-EV, COAT)
 - Differential Mode (ON/OFF)
 - High Speed Scan Mode (ON/OFF)
 - Alarm Mode (ON/OFF/AUDIBLE)
 - Gain Setting (VLOW, LOW, MED, HI, VHI)

- E. **Digital Material Thickness Value** – Extra large font size for viewing ease.
- F. **Scan Bar** – Another view of material thickness in a deflection style horizontal bar. This is another visual tool that would enable the user the ability to see thickness changes during high speed scans from flaws and pits.
- G. **Units** – The current measurement units being used (English, Metric).
- H. **Coating Thickness Value** – Displays the actual thickness of any coating adhered to a metallic material surface (PECT Mode), or a coating adhered to a non-metallic surface (CT Mode).
- I. **Minimum Material Thickness** – Part of the Alarm feature. Displays the minimum thickness value found during a scan.
- J. **Maximum Material Thickness** – Part of the Alarm feature. Displays the maximum thickness value found during a scan.
- K. **Gain & Step Size** – The gain and increment step size can be continuously

used and adjusted at any time using the



and




arrow keys

on the right button wheel to scroll the value, and the



key to activate the **Digit Edit** screen to adjust the step size.



B-Scan

The B-Scan displays a time based cross section view of test material. This view is commonly used to display the contour of the blind, or underside, surface of a pipe or tank application. It is very similar to a fish finder. If a flaw or pit is located during a scan, the B-Scan will draw the pit on the screen. The solid black rectangle in the diagram at location K represents the cross section, or side view of the material. The B-Scan view draws at a rate of 7 seconds per screen from right to left. Also notice at location K, the pits and corroded bottom surface of the material.


It's important to note that the measurement range on the display be set wide enough, so that the maximum thickness of the material can be viewed on the display. Using

the diagram above, if the material thickness was actually 1.75", the underside of the material would not be viewable according to the current range at 0.00" – 1.00". All the user would see is a black screen from 0.00" – 1.00" with no view of the bottom contour at 1.75".

The following is a list of the viewable features on the display:

- A. **Repeatability/Stability Indicator** – This indicator should be commonly used in conjunction with the digital thickness values displayed. When all the vertical bars are fully illuminated and the last digit on the digital thickness value is stable, the **FX80** is reliably measuring the same value 3 to 200 times per second, depending on which measurement mode and features are enabled.
- B. **Battery Icon** – Indicates the amount of battery life the **FX80** has remaining.
- C. **Velocity** – The material velocity value the **FX80** is currently using or calibrated for. Displayed in either English or Metric units, depending on the what units the gauge is set for.
- D. **Feature Status Bar** – Indicates the features currently enabled and in use in the following order:
 - Measurement Mode (P-E, PECT, PETP, E-E, COAT)
 - Differential Mode (ON/OFF)
 - High Speed Scan Mode (ON/OFF)
 - Alarm Mode (ON/OFF/AUDIBLE)
 - Gain Setting (VLOW, LOW, MED, HI, VHI)
- E. **Digital Material Thickness Value** – Smaller font size when the B-Scan display view is enabled.
- F. **Scan Bar** – Another view of material thickness in a deflection style horizontal bar. This is another visual tool that would enable the user the ability to see thickness changes during high speed scans from flaws and pits.
- G. **Units** – The current measurement units being used (English, Metric).
- H. **Minimum Material Thickness** – Part of the Alarm feature. Displays the minimum thickness value found during a scan.
- I. **Maximum Material Thickness** – Part of the Scan feature. Displays the maximum thickness value found during a scan.
- J. **B-Scan Display** – Cross section view of the material. Provides the user with graphical view of the opposite/blind surface (i.e. inside pipe wall surface), to give the user some idea of the condition, or integrity of the material being tested.
- K. **Gain & Step Size** – The gain and increment step size can be continuously used and adjusted at any time using the  and  arrow keys

on the right button wheel to scroll the value, and the  key to activate the **Digit Edit** screen to adjust the step size.



Radio Frequency (RF) A-Scan

The RF mode shows the waveform in a similar fashion to an oscilloscope. It shows both the positive and the negative peaks. The peak (either positive or negative) selected for measurement is shown in upper portion of the display.


It's important to note that a measurement must fall inside the displays viewable range in order to see the waveform. However, even if the waveform is outside of the viewable range of the display, a measurement can be taken and viewed on the digital readout. If the wave is outside of the display range, you can manually change the range by adjusting the **Delay** and **Width** values, or you can use the **Auto Find** feature located in the **UTIL** menu of the tabbed menu items. Refer to page 115 for additional information on the **Auto Find** feature.

The following is a list of the viewable features on the display:

- Repeatability/Stability Indicator** – This indicator should be commonly used in conjunction with the digital thickness values displayed. When all the vertical bars are fully illuminated and the last digit on the digital thickness value is stable, the **FX80** is reliably measuring the same value 3 to 200 times per second, depending on which measurement mode and features are enabled.
- Battery Icon** – Indicates the amount of battery life the **FX80** has remaining.
- Detect Indicator** – The broken vertical line displays the zero crossing detection point on the waveform where the measurement has been obtained. Notice that the digital thickness readout is the same as the location of the detect indicator according to the measurements labels F, also in the diagram.
- Baseline** - The horizontal trace across the A-scan presentation for a no signal condition. It represents time and is generally related to material distance or thickness.
- Gate** – An electronic feature that allows the user to monitor signals inside the boundaries of the gate settings. The height of the gate from the baseline is

known as the threshold, and controls the sensitivity of the reflections that trigger a detection from the opposite surface of the material.

- F. **Measurement Scale** – Represents thickness values over a defined measurement range, and labeled at the calibrated hash marks on the display (X) axis.
- G. **Digital Material Thickness Value** – The thickness of the base material.
- H. **Minimum Thickness Value** – Dynamically updates the value during a scan, and displays the minimum thickness value found. Note: Only visible when high speed scan mode is enabled.
- I. **Units** – The current measurement units being used (English, Metric).
- J. **Velocity** – The material velocity value the **FX80** is currently using or calibrated for. Displayed in either English or Metric units, depending on what units the gauge is set for.
- K. **RF waveform** – The sine wave created by the reflected sound, or oscillation, from the material being measured. The both the positive and negative half cycles (full cycles) are displayed.
- L. **Coating Thickness Value** – Displays the actual thickness of any coating adhered to a metallic material surface (PECT Mode), or a coating adhered to a non-metallic surface (CT Mode).
- M. **Minimum Thickness Value** – Dynamically updates the value during a scan, and displays the minimum thickness value found. Note: Only visible when high speed scan mode is enabled.
- N. **Feature Status Bar** - Indicates the features currently enabled and in use in the following order:
 - Measurement Mode (P-E, PECT, PETP, E-E, COAT)
 - Differential Mode (ON/OFF)
 - High Speed Scan Mode (ON/OFF)
 - Alarm Mode (ON/OFF/AUDIBLE)
 - Gain Setting (VLOW, LOW, MED, HI, VHI)
- O. **Gain & Step Size** – The gain and increment step size can be continuously used and adjusted at any time using the  and  arrow keys on the right button wheel to scroll the value, and the  key to activate the **Digit Edit** screen to adjust the step size.



Rectified (RECT) A-Scan

The RF mode shows the waveform in a similar fashion to an oscilloscope. It shows both the positive and the negative peaks. The peak (either positive or negative) selected for measurement is shown in upper portion of the display.

It's important to note that a measurement must fall inside the displays viewable range in order to see the waveform. However, even if the waveform is outside of the viewable range of the display, a measurement can be taken and viewed on the digital readout. If the wave is outside of the display range, you can manually change the range by adjusting the **Delay** and **Width** values, or you can use the **Auto Find** feature located in the **UTIL** menu of the tabbed menu items. Refer to page 115 for additional information on the **Auto Find** feature.

The following is a list of the viewable features on the display:

- A. **Repeatability/Stability Indicator** – This indicator should be commonly used in conjunction with the digital thickness values displayed. When all the vertical bars are fully illuminated and the last digit on the digital thickness value is stable, the **FX80** is reliably measuring the same value 3 to 200 times per second, depending on which measurement mode and features are enabled.
- B. **Battery Icon** – Indicates the amount of battery life the **FX80** has remaining.
- C. **Detect Indicator** – The broken vertical line displays the zero crossing detection point on the waveform where the measurement has been obtained. Notice that the digital thickness readout is the same as the location of the detect indicator according to the measurements labels F, also in the diagram.
- D. **Baseline** - The horizontal trace across the A-scan presentation for a no signal condition. It represents time and is generally related to material distance or thickness.
- E. **Gate** – An electronic feature that allows the user to monitor signals inside the boundaries of the gate settings. The height of the gate from the baseline is

known as the threshold, and controls the sensitivity of the reflections that trigger a detection from the opposite surface of the material.

- F. **Measurement Scale** – Represents thickness values over a defined measurement range, and labeled at the calibrated hash marks on the display (X) axis.
- G. **Digital Material Thickness Value** – The thickness of the base material.
- H. **Minimum Thickness Value** – Dynamically updates the value during a scan, and displays the minimum thickness value found. Note: Only visible when high speed scan mode is enabled.
- I. **Units** – The current measurement units being used (English, Metric).
- J. **Velocity** – The material velocity value the **FX80** is currently using or calibrated for. Displayed in either English or Metric units, depending on what units the gauge is set for.
- K. **RECT waveform** – The half cycle, either positive or negative, of the RF sine wave, created by the reflected sound, or oscillation, from the material being measured. This view is typically considered as “flaw” view.
- L. **Coating Thickness Value** – Displays the actual thickness of any coating adhered to a metallic material surface (PECT Mode), or a coating adhered to a non-metallic surface (CT Mode).
- M. **Minimum Thickness Value** – Dynamically updates the value during a scan, and displays the minimum thickness value found. Note: Only visible when high speed scan mode is enabled.
- N. **Feature Status Bar** - Indicates the features currently enabled and in use in the following order:
 - Measurement Mode (P-E, PECT, PETP, E-E, COAT)
 - Differential Mode (ON/OFF)
 - High Speed Scan Mode (ON/OFF)
 - Alarm Mode (ON/OFF/AUDIBLE)
 - Gain Setting (VLOW, LOW, MED, HI, VHI)
- O. **Gain & Step Size** – The gain and increment step size can be continuously used and adjusted at any time using the  and  arrow keys on the right button wheel to scroll the value, and the  key to activate the **Digit Edit** screen to adjust the step size.

7.2 Changing Display Options

The following procedure outlines how to select or toggle display options:

Changing Display Options

SET DISPLAY	
VIEW	+RECT
DELAY	0.775
RANGE	1.516
B-SCAN SPEED	6
UNITS	IN
BRIGHTNESS	15
SCREEN UPDATE	60HZ
<MORE>	
PRB	CAL
DISP	TUNE

Color VGA

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **DISP** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.
- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **VIEW** is highlighted.
- 3) Press the  and  arrow keys on the right button wheel to scroll the view options. Once the appropriate view is displayed, press the  key to return to the measurement screen and begin taking measurements.

7.3 Adjusting the display

This section will cover the procedures for adjusting the viewable range, or area, of the display, in terms of thickness. A basic overview of this section would be as follows: Suppose we had a 50" widescreen television set. Assume that you're watching the television for rest of this explanation. The left side of the television screen is considered the **Delay** for all view options other than B-Scan. In B-Scan view, it's called **B-Start**. Therefore, **Delay (B-Start)** are *identical*, with the exception of the terminology used, and represent the left side of the television screen.

The right side of the television screen is considered the **Range + Delay**, in all view options with the exception of B-Scan, once again. In B-Scan view, it would be considered **B-Depth + B-Start**. Therefore, the following should be considered: **Delay (B-Start) + Range (B-Depth) = right side of the screen**, depending on what view option is active.

Now, by adjusting the left and right side of the television screen, to control the viewable area/range, we can zoom in and out of any part of the 50" screen we'd like, and focus on only the specific areas of the screen we need to. Therefore, if I am measuring a part, and am only interested in viewing the thickness range/area from .500" – 1.0", and I'd like to zoom in a bit to get a close up look at things, I'd set my Delay (B-Start) to .500" and my Range (B-Depth) to .500". This would make the left side of my screen start at .500", and the right side of the screen at 1.0".



Setting the Delay (B-Start)

The Delay (B-Start) represents the left side of the display, and can be adjusted to start at any thickness value within the overall range of the **FX80**. The value the Delay (B-Start) is set too, is the minimum thickness value that will be displayed on the screen.


Note: Once the delay is set, it will remain the same for the views: Digits, RF, RECT. However, in B-Scan view, the B-Start is an independent setting from Delay, and allow the user to store two independent settings respectively.

The procedures to adjust the **Delay (B-Start)** are outlined below:

Adjusting Delay (B-Start) using the Hot Menus





- 1) Press the  key once to activate measure menu items. Press the  key multiple times to move right and the  key multiple times to move left, until the **DELAY** cell is highlighted. Alternatively, press the




and  arrow keys multiple times using the left button wheel.

- 2) Press the  and  arrow keys on the right button wheel to scroll the highlighted value.



- 3) **Alternatively**, press the  key to display the **Digits Edit Box**.

- 4) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.





- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.
- 6) Repeat steps **4 & 5** until the **DELAY** value is correctly displayed.
- 7) Press the  key to return to the measurement screen, or  to cancel entering the **DELAY**.
- 8) Finally, press the  key to return to the measurement screen and begin taking readings.

Adjusting the Range (B-Depth)


Once again, just to reiterate, the **Range (B-Depth) + Delay (B-Start) equals the right side of the screen**. Therefore, the Range (B-Depth) is the overall area, from the delay, that will be viewable on the screen. The **FX80** digitizer will round up from the Range (B-Depth) that's entered. Therefore, if the Range (B-Depth) is set at 1.0", the digitizer will round this value up to the next adjustment available. The procedures to adjust the overall thickness range viewed Range (B-Depth) are outlined below:

Adjusting the Range (B-Depth) using the Hot Menus




- 1) Press the  key once to activate measure menu items. Press the  key multiple times to move right and the  key multiple times



to move left, until the **WIDTH** cell is highlighted. Alternatively, press the



and arrow keys multiple times using the left button wheel.




- 2) Press the and arrow keys on the right button wheel to scroll the highlighted value.



- 3) **Alternatively**, press the  key to display the **Digits Edit Box**.

- 4) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.



- 5) Press the and arrow keys multiple times using the left button wheel to scroll the digit locations.

- 6) Repeat steps 4 & 5 until the **WIDTH** value is correctly displayed.

- 7) Press the  key to return to the measurement screen, or  to cancel entering the **RANGE**.

- 8) Finally, press the  key to return to the measurement screen and begin taking readings.

Adjusting the B-Scan Speed

The **FX80** has the capability to adjust the scrolling speed of the time based B-Scan displayed in the gauge. The procedures to adjust the speed are outlined below:

Adjusting the B-Scan Speed

SET DISPLAY	
VIEW	BSCAN
B-START	0.000
B-DEPTH	0.531
B-SCAN SPEED	6
UNITS	IN
BRIGHTNESS	15
COLORS	GREEN 2
<MORE>	
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **DISP** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **B-SCAN SPEED** is highlighted.

- 3) Use the  and  arrow keys on the right button wheel to scroll the speed from 0-10. Note: 10 representing the fastest scroll time. Once the appropriate speed is displayed, press the  key to return to the measurement screen and begin the B-Scan process.

- 4) **Alternatively**, press the  key to display the **Digits Edit Box**.

- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.
- 6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.
- 7) Repeat steps **5 & 6** until the **SPEED** is correctly displayed.
- 8) Press the  key to set the speed and return to the **DISP** menu., followed by pressing the  key to begin the B-Scan process.
- 9) Finally, press the  key to return to the measurement screen and begin the scanning process.

7.4 Gain & Step Increment

The gain, or amplification of the return echoes, can be adjusted in the **FX80** to accommodate a variety of applications. The setting of the gain is crucial in order to obtain valid readings during the measurement process. Too much gain may result in erroneous measurements, by detecting on noise rather than the actual material back wall itself. Not enough gain may result in intermittent detection. It may also result in lack of detection on internal flaws, pits, or porosity. The gain can easily be compared to the volume control of a home stereo system. If you turn it up too much, you can't hear the music clearly. If it's turned down too much, you can't hear it at all.

The **FX80** has 110dB gain range, but has been limited to a 60dB gain range (-10 to 50 dB), for thickness gauge applications. The common starting point for standard thickness gauge applications is 46dB. This feature is used to increase/decrease the power or amplitude of the signal. When used in conjunction with the attenuator feature, it has a limited overall gain range of -30dB to 70dB.

The gain can be adjusted to accommodate a variety of material types. Having this feature available, provides the user with a great deal of flexibility. Some applications may require the lower or higher gain settings. When? The low settings may be necessary for noisy or granular cast materials. How do I know when to lower the gain? If the reading becomes sporadic and won't settle down or resolve on a thickness value, the user can assume that the material is either very noisy aluminum,


or granular cast iron. This would be a good time to change the **FX80** to lower gain setting and see if the reading settles down and become stable.

How do I know when to increase the gain? Often times the user will be trying to measure a material that is hard to penetrate or pass sound through. This may be due to the material type, or overall thickness of the material. When a material is hard to pass sound through because of the thickness or general make-up, it would be a good time to consider increasing the **FX80** to a higher gain setting. Another example might be the need to increase overall sensitivity for locating fine pits or flaws. In any case, the adjustable gain feature offers the user some additional options to resolve and overcome application issues.

Note: When the echo-echo thru-paint, or echo-echo-verify measurement modes are selected, the manual gain feature is disabled and grayed out in the menu items. In this mode, the **FX80** switches to an automatic gain mode (**AGC**) that optimizes the gain setting automatically in the hardware of the **FX80**.

The procedures to adjust the **Gain** are outlined below:

Adjusting the Gain Quickly



1) Press the  and  arrow keys using the right button wheel to increase/decrease the gain value at any time.

The user can also access and adjust the gain from the tabbed menus. However, this method is more tedious than making the adjustments using the right button wheel approach. The procedure using the tabbed menu is outlined below:

Adjusting the Gain using the Tabbed Menus

TUNE SIGNAL	
MEASURE MODE	P-E
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
ATTN	0 DB
GAIN	29.0
AGC	21
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **TUNE** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until  is highlighted.

- 3) Press the  and  arrow keys multiple times using the left button wheel to scroll the value. When the correct **Gain** is being displayed, **proceed to step 8.**



4) **Alternatively**, press the  key to display the **Digits Edit Box**.

5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.


6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

7) Repeat steps **5 & 6** until the **Gain** value is correctly displayed.

8) Press the  key to set the **Gain** and return to the menu screen, or  to cancel entering the **Gain**.

9) Finally, press the  key to return to the measurement screen and begin taking readings.

Setting the Gain Increment Step Size



- 1) Press the  key once to display the **Digits Edit Box**. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **TUNE** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.



- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll the **Step** size.

- 3) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

- 4) Repeat steps 2 & 3 until the **Step** size is correctly displayed.

- 5) Press the  key to set the **Step** size and return to the measurement screen, or  to cancel entering the **Step** size.

7.5 Threshold


The **Threshold** is the level (sensitivity) of the signal amplitude required to trigger the thickness reading. This level can be used in conjunction with the gain. Example: suppose the user can visually see a potential flaw on the display, but the **FX80** is not detecting on the flaw because the **Gain** is too low, or the **Threshold** too high. The **Threshold** level can be decreased (lower sensitivity) in order to detect signals with

lower amplitudes. This will allow the amplitude from the reflection of the flaw to reach and exceed the **Threshold** level, and enable the **FX80** to detect on the flaw or defect. This can also be accomplished by increasing the **Gain**, allowing the signal to exceed the current **Threshold** level. Lowering the **Threshold** (increases sensitivity), and raising the **Threshold** decreases the sensitivity respectively.

The **FX80** is equipped with 3 independent gates, each with an adjustable threshold level. All three gates can be enabled in any of the pulse echo modes, and in echo-echo verify mode, and the thresholds set at varying levels of sensitivity. The allows the user to create a pseudo make-shift “time corrected gain” function, by increasing the sensitivity of each gate at different thickness values. A visual example would be an upside down stair case, where each step represented a separate gate, for a specific thickness range.

The procedures to adjust the **Thresholds** are outlined below:

Adjusting the Thresholds using the Hot Menu



- 1) Press the  key once to activate measure menu items. Press the  key multiple times to move right and the  key multiple times to move left, until the **THRESH(1-3)** cell is highlighted. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) If the correct **Threshold** is being displayed, press the  and  arrow keys on the right button wheel to scroll the highlighted value.

- 3) **Alternatively**, if the correct **Threshold** is not being displayed, press the  key to display the **List Box**.

THRESHOLDS	
THRESHOLD1	1
THRESHOLD2	2
THRESHOLD3	1

Note: The number of thresholds listed will depend on the current measurement mode selected.

- 4) Press the  and  arrow keys multiple times using the left button wheel to scroll and highlight a specific **Threshold (1-3)**.

- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

- 6) Press the  key to set the edited **Threshold** value, and return to the measurement screen. The **Threshold** edited will now be displayed in your **Hot Menu** items.

Note: Alternatively, the **Digit Edit Box** can be displayed, and the value edited

using the  /  and  /  arrow keys on the left button wheel by simply pressing the  key following **step 4** above.

- 7) Repeat steps **3-6** until all the **THRESH** values are correctly adjusted.

The Thresholds can also be accessed and adjusted from the tabbed menus. However, this method is more tedious than making adjustments using the **Hot Menu**. The procedure for using the tabbed menus is outlined below:

Adjusting the Thresholds using the Tabbed Menu


GATE ONE			
START			0.588
GATE1 WIDTH			OFF
THRESHOLD1			6
GT1	GT2	GT3	SET

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **GT1** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **THRESHOLD1** is highlighted.

- 3) Press the  and  arrow keys multiple times using the left button wheel to scroll the value. When the correct threshold is being displayed, **proceed to step 8.**





4) **Alternatively**, press the  key to display the **Digits Edit Box**.

5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

7) Repeat steps **5 & 6** until the **Threshold** number is correctly displayed.

8) Press the  key to set the **Threshold** and return to the menu screen, or  to cancel entering the **Threshold**.

9) Repeat steps **1-8** to set any additional **Threshold** levels.

10) Finally, press the  key to return to the measurement screen and begin taking readings.

7.6 Understanding the features of the Gate

Important: It is recommended to spend some time in this section. The sections that follow are procedures for using the features associated with the Gates, in some way. There are 3 gates in the **FX80**, and as a result, operating and setting them up can become somewhat convoluted, to say the least. However, a thorough understanding of the functionality presented in this section, will reveal how easy they actually are to operate overall. The following diagrams illustrate the features of all 3 gates, according to the measurement mode selected:

Note: This is a general overview and should be referred to in conjunction with the detailed feature sections that follow.

Modes	# Gates	Gate #	Start	HoldOff	Width	Threshold
PE	1,2,or 3	1	√		√	√
		2			√	√
		3			√	√
PECT	1,2,or 3	1	√		√	√
		2			√	√
		3			√	√
PETP	1,2,or 3	1	√		√	√
		2			√	√
		3			√	√
EE	2	1	√			√
		2		√	√	√
		3				
EEV	3	1	√			√
		2		√		√
		3		√		√
CT	None	None	None	None	None	None

Diag. 1 Gate Features vs Modes

In **diagram 1**, the gates have been associated with the measurement modes, along with the features available to every gate. For example, echo-echo mode (EE) has 2 gates available, while echo-echo verify (EEV) has 3. These gates have been designed to work in order, from 1 to 3, and cannot be used any other way.

Therefore, the user must be using gate 2 before they can activate and use gate 3.

Note: Gate 1 is on at all times, as a gate must be activated to get a measurement.

Each gate has a given set of features to fine adjust the settings of the gate. Let's have a look at the feature set:


Start (Gate1): This feature is only available to gate 1, and determines the start value of the left side of the gate. For example, if there's a great deal of noise from the initial

pulse, or in the material, the gate can be moved to the right of the noise and block the unwanted noise. Gates 2 and 3 will automatically start from the end of gate 1, or from a detection found inside of the boundaries of gate 1. Therefore, we use a hold-off delay as a start feature for gates 2 and 3. See Diagram 2.

Hold-Off: The hold-off is the starting point of the left side of gates 2 & 3, and is used only if a detection is found inside the previous gate. It should be considered a delay from the detection point of the previous gate. When the hold-off is off, or 0, the gate will start at the point of detection from the previous gate. As the value of the hold-off is increased, it is further delaying the start of the gate to the right of the detection of the previous gate. **Note:** Although we've used the terminology of hold-off for gate 3, it is actually a "hold-back" from the detection of the second echo. Therefore, as the value is increased, the "hold-back" moves closer to the second detection. It's just the opposite of the operation of gate 2 hold-off. See diagram 2.

Width: The width determines the physical length of the gate. Therefore, the width – start (hold-off) equals the length of the gate, as the start (hold-off) value is not equal to zero. If no detection is located inside the boundaries of a gate, the width value is used to start the next available gate. **Key point:** When the width is activated for a gate, giving it a value, the next available gate is also activated. Therefore, activating width1 of gate1, activates gate2, and activating width2 of gate2, activates gate3. See diagram 2.

Thresh: The threshold controls the level of sensitivity of the signal amplitude required to trigger a detection, or measurement. It is represented by the distance from the baseline, and displayed as the vertical position of a gate. The further the vertical position is from the baseline, the less sensitive the threshold is, and visa versa. This allows the user to have further control over the size of the defects considered critical, or the ability to get a detection, from the opposite surface, in very attenuative materials. This feature is used in conjunction with gain. Increasing the threshold has a similar effect of decreasing the gain, and visa versa.




Activating the gates:

- Automatically:** *The gates are automatically activated, when a measurement mode is selected. Gate1 is active in all measurement modes. These modes have been internally setup at the Dakota factory. Therefore, if the user selects the **Thru Coat (E-E)** option, an internal setup will be loaded, and 2 gates will automatically be activated. This setup will work fine for the majority of all common applications. The user has the ability to fine adjust the gates settings, which will be further explained in the sections that follow.*

MEASURE MODE	
COATING OFF	P-E
COATING ON	PECT
TEMP COMP	PETP
THRU COAT	E-E
THRU VERIFY	E-EV
COATING ONLY	CT

- Manually:** The gates can also be activated manually by using the Hot or Tabbed menus. For example: If any of the pulse echo modes (PE, PECT, PETP) had been selected in diagram 1, only gate 1 will have been activated from the factory setup. However, the user may have a requirement to activate and utilize more than one gate, depending on the application.

GATE ONE			
START			0.019
GATE1 WIDTH			OFF
THRESHOLD1			6
GT1	GT2	GT3	SET

Tabbed Menu**Hot Menu**

7.7 Gates

The **FX80** is equipped with 3 gates, as explained in the previous section. One gate is active at all times in every measurement mode, with the exception of coating mode. These gates are full featured and completely adjustable. They can be fine tuned by the user to accommodate a variety of application scenarios. Diagram 1 in the previous section outlines the gates and features available for all measurement modes. Refer to the previous section for additional information. These features are described in more detail below:


Note: *In order to adjust the gates they must be activated. The gates are automatically activated depending upon the measurement mode selected. If a gate is inactive, it will be grayed out in the hot and tabbed menus. The explanations that follow, assume that the proper measurement mode has been selected. Refer to page 44 for more information on selecting measurement modes.*

Gate 1

Is used in all measurement modes, and has the following features assigned to it; start, width, and threshold. A gate can be used to overcome a great deal of application scenarios. Surface noise, for instance, close to the initial pulse can cause the erroneous measurements as the transducer receives reflections from the noise. By adjusting the start position of the gate, the noise can be blocked and eliminated. This is typical in aluminum, stainless steel, and titanium. This can also be a function of using a low frequency transducer, which are known to be inherently noisy off the initial pulse. The start feature of the gate is also used in multiple echo modes to control measurements between 2 or more echoes. As we saw in previous section, the threshold can be used to control the sensitivity level, and used in combination with the width, control the sensitivity over a specific range.

Gate 2 & 3

These gate options will most commonly be used for multiple echo measurement modes, to measure between 2 or more echoes (E-E and E-EV). They are also handy to use in a stand pulse echo mode, to create a pseudo time corrected gain feel. As the thickness of the material increases, the signal amplitude of the reflection decreases. Why not just turn up the gain? Well, this is certainly something to consider, but is not always the best answer. As the gain is increased, the noise level is also increased. At some point, increasing the gain provides little or no benefit to the quality of the signal, and the additional noise introduced makes things worse. By activating another gate, optimizing the gain level, setting the thresholds, and adjusting the widths of the gates to cover specific thickness ranges, a tough application might not be so bad after all. These gates have the following features set assigned to them; holdoff (delay), width, and threshold.



The diagrams above illustrate a typical surface noise condition. Refer to the **Noise** diagram: **(A)** refers to the noise in front of the actual back wall signal **(C)**. Notice the start position of the gate. As a result, the **FX80** is detecting on the noise **(A)** as shown at point **(B)**. However, the true measurement should be taken at point **(C)**. Given the start, threshold, and gain levels, the amplitude from the noise is sufficient enough to cause the **FX80** to detect, or measure the noise rather than the true back wall thickness **(C)**. Therefore, the **FX80** is making an incorrect reading at point **(B)**.

Now refer to the **Block** diagram. The horizontal line at the top of **(D)**, is **GATE1**. The start of **GATE1** has been moved just beyond the noise **(A)** to block the noise and detect on the correct signal **(C)**. Note: the **FX80** will only detect on signals that are located inside the dimensions of **GATE1** **(B)**. Therefore, the **FX80** cannot see **(A)** at all, with respect to the starting point of **(B)**. Also notice, the position of the threshold level with respect to the baseline **(D)**, which represents the sensitivity setting of the threshold. Extreme sensitivity is indicated by the bottom of the range **(D)** at the baseline, and less sensitivity indicated by the top of the range at **(D)**. Therefore, the vertical height of **GATE1** from the baseline, is the threshold level. The threshold level can be increased to decrease sensitivity, or visa versa.

If the threshold level was increased in the **Noise** diagram, so that the vertical position of **GATE1** was higher than the amplitude of the noise **(A)**, the **FX80** would have detected on the true back wall **(C)**. Alternatively, if the gain level was decreased, the signal amplitude of the noise **(A)** would have decreased below the threshold level, and the **FX80** would have also detected the true back wall **(C)**. This example brings all the fine adjustments into consideration, and demonstrates the versatility of having a fully functional scope rather than a basic digital thickness gauge.

The procedures to adjust all of the features associated with the **Gates** are outlined below:

Note: This is a combined procedure that works the same for any of the features associated with the gates, regardless of which feature and gate number that is being adjusted. **Therefore (X) = Gate1, Hold-Off, and Width respectively.** Finally, the illustrations may not be applicable to the exact feature being adjusted, but the concepts relevant.

Adjusting the Features of the Gates Using the Main Hot Menu

DELAY
0.040
RANGE
1.517
GAIN
46.0
THRESH1
6
START
0.019
WIDTH1
OFF
HOLD2
OFF
LOG
CLOSED
STEP: 1.0
GN: 46.0

Gate

DELAY
0.002
RANGE
0.910
AGC
10
THRESH1
4
START
0.108
WIDTH1
OFF
HOLD2
0.095
LOG
CLOSED
STEP: 1.0
GN: 28.0

Holdoff's

DELAY
-0.019
RANGE
0.910
GAIN
31.0
THRESH1
6
START
0.019
WIDTH1
0.306
HOLD2
OFF
LOG
CLOSED
STEP: 1.0
GN: 31.0

Width's

- 1) Press the  key once to activate measure menu items. Press the  key multiple times to move right and the  key multiple times to move left, until the (X) cell is highlighted. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) If the correct (X) is displayed, press the  and  arrow keys on the right button wheel to scroll the highlighted value.

HOLDOFFS	
HOLDOFF 2	0.095
HOLDOFF 3	OFF

3) **Alternatively**, if the correct (**Ж**) is not being displayed, press the  key to display the **List Box**.

4) Use the  and  arrow keys multiple times using the left button wheel to scroll through the **List Box** items until the correct (**Ж**) is highlighted.

5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

6) Repeat steps 3-5 until all the (**Ж**) values are correctly adjusted.

Adjusting the Features of the Gates Using Multiple Hot Menus

START 0.588	WIDTH 2 0.830	WIDTH 3 OFF
WIDTH 1 OFF	HOLDOFF 2 0.095	HOLDOFF 3 0.012
THRESH 1 5	THRESH 2 4	THRESH 3 2

Gate1

Gate2

Gate3

- 1) Using the left button wheel, press the  and  arrow keys to scroll through the 8 individual **Hot Menus**, and the  and  arrow keys to scroll through the **Hot Menu** items. Alternatively, the  key can be used to scroll through the **Hot Menu** items.

- 2) Press the  and  arrow keys multiple times on the right button wheel to toggle the value or status.

Note: *This is a coarse adjustment. It's the fastest and easiest way to increment, decrement, or toggle the status however it does so in coarse steps. Pressing the  key will allow the user to enter a specific target value.*

The user can also access and adjust the **(X)** from the tabbed menus. However, this method is more tedious than making the adjustments using **the Hot Menu**. The procedure for using the tabbed menus is outlined below:

Adjusting the Features of the Gates using the Tabbed Menu

GATE ONE			
START	0.588		
GATE1 WIDTH	OFF		
THRESHOLD1	6		
GT1	GT2	GT3	SET


- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times

to tab left, until the (Ж) menu is highlighted and displaying the submenu



items. Alternatively, press the and arrow keys multiple times using the left button wheel.

- 2) Use the and arrow keys multiple times using the left button wheel to scroll through the sub menu items until (Ж) is highlighted.




- 3) Press the and arrow keys on the right button wheel to scroll the value. When the correct (Ж) is being displayed, **proceed to step 10.**

THRESHOLD1	
 6	
OK	ESC

- 4) **Alternatively**, press the  key to display the **Digits Edit Box**.

- 5) Press the and arrow keys multiple times using the left button wheel to scroll the highlighted value.



- 6) Press the and arrow keys multiple times using the left button wheel to scroll the digit locations.

- 7) Repeat steps 5 & 6 until the (Ж) number is correctly displayed.

- 8) Press the  key to set the (Ж) and return to the menu screen, or  to cancel entering the (Ж).

9) Repeat steps **1-8** to set any additional **(Ж)** level.

10) Finally, press the  key to return to the measurement screen and begin taking readings.

CHAPTER EIGHT

THRU PAINT MEASUREMENT TECHNIQUE

8.1 Introduction to Thru Paint Measurement

The principle behind thru paint measurement is by measuring the time between two backwall echoes returning from the test material. Since both of these backwall echoes travel the same path through the paint or coating, the thickness of the coating is subtracted out of the measurement so that only the actual material thickness can be measured. This feature saves the user a great deal of time scraping and removing the coating from tanks and pipes during the inspection process.

The **FX80** also has a special echo-echo verify option, or triple echo mode. This measurement mode is identical to the echo-echo mode described above, with an additional third echo measurement performed to verify the measurement between the first 2 echoes. By doing this, the **FX80** can confirm that a peak jump has not occurred, and the measurement made is stable and correct. This mode is only suitable for thin materials and coatings, as the ability to achieve 3 reflections is not always possible.

The primary purpose of thru paint measurement is to determine actual or overall material thickness by eliminating the coating thickness. Thru paint mode cannot be used for flaw or pit detection. Therefore, inspectors may need to use echo-echo thru paint mode in conjunction with the standard pulse-echo flaw detection mode for some applications. The combination of using both modes is ideal for the advanced inspectors needs.

8.2 Using Thru Paint Mode

The first thing to note in this section is by selecting the transducer type from the list of probes stored in the **FX80**, a basic echo-echo thru paint configuration is recalled from memory. Each of the transducers in the list contains pre-configured echo-echo settings. However, fine adjustments may be necessary in order to be suitable for your specific applications. These configurations are general setups only. Once the transducer has been selected, or auto detected, and the appropriate calibration procedure completed, the **FX80** can toggle between **pulse-echo** (flaw & pits), and


echo-echo (thru-paint) modes by simply pressing the  key located on the keypad. The standard transducer that will be used for common steel applications is a 1/4" 5MHz high damped transducer (**1/4IN – 5.0MHZ HD or CT**). However, any of the transducers with the **HD** label have been optimized for echo-echo thru paint applications. Any of the auto recognition coating transducers are also high damped transducers, and will work in echo-echo mode as well.

Note: When a transducer is selected for use, all of the measurement modes available for use with this transducer can easily be determined by pressing the multi-

mode button on the keypad. The **FX80** has been programmed to identify the modes available to a specific transducer.

When configuring the **FX80** for specific thru paint applications, all of the scope parameters will potentially be needed. The delay, range, gain (AGC), thresholds, gates, and hold-offs will be subject to change. For this reason, they have all been added to **Hot Menu** fields located directly beneath the A-Scan display for quick and easy access. **Note:** Once the values of the fields have been changed or modified, these changes must be saved to a setup location prior to powering the **FX80** off.

Failure to do so will result in losing your changes. Refer to page 169 for additional information on setups.



Refer to the incorrect diagram above. Point **(A)** represents the detection on the first back wall echo. The true, second back wall, reflection should be detecting at point **(D)**. However, the hold-off **(C)** is setup incorrectly and the **FX80** is detecting the ring down noise of the transducer, rather than the true second back wall reflection shown at **(D)**.

Before we look at the diagram with the correct configuration, let's consider all of our options on how to fix the problem beforehand. Our **delay** and **Range** will simply change the view options of the screen – not needed in this example. Will a **gain (AGC)** or **threshold** adjustment fix the problem? Unfortunately not. Why? Notice the amplitude of the cycle just to the left of **(B)**. If we tried to increase the threshold level above the height of the cycle, we would lose our detection for both echoes resulting in no reading at all. If we decrease our **gain (AGC)**, reducing the signal amplitudes, we would also lose our detection of both back wall echoes.

Notice that the amplitude of the cycle just to the left of **(C)**. The amplitude of the cycle, at **(C)**, is less than the amplitude of the cycle at **(B)**, in terms of overall height. If we decreased our **gain (AGC)**, we would lose the first cycle **(C)** long before losing the second cycle **(B)**. Therefore, adjusting the **gain (AGC)** or **threshold** levels will not help us in this example. Our final option is adjusting the **GATE2** hold-off, shown at point **(C)** in the incorrect diagram, to point **(B)** in the correct diagram. If we adjust

the **GATE2** hold-off further to the right of the first reflection, the ring down noise from the first back wall echo no longer interferes with the true detection (**D**), shown in the correct diagram.

The adjustment considerations in the example above will typically be used for all thru paint applications respectively. In some applications the hold-off may be sufficient, while a **gain (AGC)** or **thresholds** adjustment will solve the problem. A similar process of elimination should be considered for all thru paint applications.

CHAPTER NINE

PULSE-ECHO COATING & COATING TECHNIQUES

9.1 Introduction to Pulse-Echo Coating Measurement (PECT)

In the previous sections we've discussed the need for detecting pits and flaws (pulse-echo) in materials, along with the requirement to measure through and eliminate errors caused by coated materials (echo-echo). Until now, both modes were needed in order accomplish both tasks. Pulse-echo mode was used for flaw detection, and echo-echo mode was used to eliminate the coating thickness and provide a nominal material thickness only. With this in mind, it often became cumbersome toggling between both modes respectively.

In a majority of applications involving coated materials, inspectors are often interested in monitoring both the thickness of the material, as well as the thickness of the coating. Therefore, the **FX80** has been designed to provide the user with the ability to measure the material and coating thicknesses simultaneously, while maintaining the ability to detect flaws and pits all in a single mode called **Pulse-Echo Coating (PECT)**. This is accomplished by using a custom hybrid combination mode utilizing properties from the basic modes along with a group of special techniques and theoretical wave phenomena's.

The **FX80** is preset to a coating velocity of 0.0850 in/μsec (2159 m/sec) from the factory. This velocity is a very close approximation of the common coating velocities found in the field. However, the **FX80** also has a built-in one and two point calibration options to calibrate to coating samples with a known thicknesses.

There are two coating modes built into the **FX80**:

- 1) **Pulse-Echo Coating (PECT)** – used during inspections where both the material and coating thicknesses are required.
- 2) **Coating Only (CT)** – used during inspections where only the coating thickness is required.

9.2 Enabling Pulse-Echo Coating Mode (PECT) & Coating (CT)

When the **FX80** is initially powered up, the gauge will automatically check to see if the transducer plugged into the gauge can be recognized. All Dakota NDT coating enabled transducers are equipped with the auto recognition feature. If the **FX80** doesn't recognize that a special coating enabled transducer is plugged into the gauge, the coating feature will be disabled entirely. There are a number of coating enabled transducers available from Dakota. Please contact us with your application requirements for additional information on frequencies and diameters currently offered.

The coating modes can be enabled in three different ways:

- 1) On Power up and probe recognition.

- 2) By pressing  keypad.

3) From the tabbed menus under **TUNE, MEASURE MODE**.

The steps that follow will demonstrate all three methods in the order listed above:

Probe Automatically Recognized (PECT only)

CONFIRM	
1/4IN - 5.0MHZ COAT PROBE IDENTIFIED.	
USE THIS PROBE?	
OK	ESC

1) Press the  key once to use the identified probe, or  to display a list of optional transducers. **Note:** if the **FX80** recognizes a specific transducer, the user should always select  to use the identified probe. The only time an alternative probe should be selected from a list is if the user switched probes following initial power up and recognition.

2) Assuming the **FX80** recognized the probe and the  key was pressed, the **FX80** will advance to a Zero Probe menu. If the transducer was identified as a special transducer capable of measuring coating thickness, a menu will be displayed allowing the user the ability to toggle the coating thickness display on/off as follows:

ZERO PROBE	
COATING:	ON
COATING:	OFF
SELECT COATING ON/OFF - REMOVE COUPLANT FROM PROBE AND PRESS OK KEY TO PERFORM THE ZERO	
OK	ESC

- 3) Press the  and  arrow keys using the left button wheel to toggle the coating option on/off.

Multi Mode Key Pressed (PECT & CT)

MEASURE MODE	
COATING OFF	P-E
COATING ON	PECT
TEMP COMP	PETP
THRU COAT	E-E
THRU VERIFY	E-EV
COATING ONLY	CT

MEASURE MODE	
COATING OFF	P-E
COATING ON	PECT
TEMP COMP	PETP
THRU COAT	E-E
THRU VERIFY	E-EV
COATING ONLY	CT

Applied to Metals

Not Applied to Metals

- 1) Press the  key located on bottom left of the keypad to display the  **URE MODE** options menu.
- 2) Press the  and  arrow keys multiple times using the left button wheel to highlight the **COATING ON (PECT)** or **COATING ONLY (CT)** menu option.
- 3) Press the  key to enable the coating option and return to the main measurement screen, or  to cancel.

Measure Mode (Tabbed Menus) – (PECT & CT)

TUNE SIGNAL	
MEASURE MODE	PECT
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
ATTN	-20 DB
GAIN	8.0
AGC	14
PRB	CAL
DISP	TUNE

TUNE SIGNAL	
MEASURE MODE	CT
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
ATTN	0 DB
GAIN	46.0
AGC	21
PRB	CAL
DISP	TUNE

Applied to Metals**Not Applied to Metals**

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **TUNE** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.
- 2) Use the  and  arrow keys using the left button wheel to scroll through the sub menu items until **MEASURE MODE** is highlighted.
- 3) Press the  and  arrow keys multiple times on the right button wheel to scroll the modes.
- 4) When the correct **MODE** is being displayed, press the  key to return to the measurement screen and begin taking readings.

9.3 Zero Coating

In order to account for very slight electronic differences in transducers of the same type, frequency, and diameter, the **FX80** has been equipped with a “zero coating” feature. This enables the **FX80** to obtain very accurate readings on coatings, eliminating potential errors incurred from slight differences in the manufacturing processes. The procedure is outlined below:

Performing a Coating Zero


MEASURE MODE	
COATING OFF	P-E
COATING ON	PECT
TEMP COMP	PETP
THRU COAT	E-E
THRU VERIFY	E-EV
COATING ONLY	CT

- 1) Press the  key once to activate the measurement mode options.
- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **Coating Only (CT)** mode is highlighted.
- 3) Press the  key to select the measurement mode and return to the measurement screen.
- 4) Apply a drop of couplant on the transducer and place the transducer in steady contact with the probe zero disk (battery cover) and obtain a steady reading.

Note: The coating measurement displayed will potentially be a value greater or less than 0.

- 5) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to

tab left until the **PRB** menu is highlighted and displaying the submenu items.



Alternatively, press the and arrow keys multiple times using the left button wheel.

SETUP PROBE			
ZERO PROBE	AUTO		
ZERO COATING			
TYPE	11		
PRB	CAL	DISP	TUNE

- 6) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **ZERO COATING** is highlighted.
- 7) Press the  key to display the confirmation screen.
- 8) Press the  key to zero the coating and return to the **PRB** menu, or  to cancel the coating zero process.
- 9) Press the  key once to activate the measurement mode options.
- 10) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **Coating On (PECT)** is highlighted.
- 11) Press the  key to select the measurement mode and return to the measurement screen, and begin taking readings. Proceed to the coating calibration section.

9.4 Coating Calibration (PECT)

Known Velocity

If the coating velocity is known, the user may wish to simply enter the velocity number into the **FX80**, rather than have the **FX80** calculate the velocity value using a known thickness on a coating sample(s). The steps for entering the velocity are outlined below:


Using a Known Material Velocity

CALIBRATE	
MAT	STEEL (4340)
MATL 1PT	UNCAL
MATL 2PT	UNCAL
VELOCITY	0.2330
COATING 1PT	UNCAL
COATING 2PT	UNCAL
COATING VEL	0.0850
PRB	CAL DISP TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **COATING VEL** is highlighted.



3) Press the  key to display the **Digits Edit Box**.

4) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

5) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

6) Repeat steps **4 & 5** until the velocity number is correctly displayed.

7) Press the  key to set the velocity and return to the menu screen, or  to cancel entering the velocity.

8) Finally, press the  key to return to the measurement screen and begin taking readings.

Known Thickness

Sometimes the sound velocity of a coating material is unknown. In this case a sample with a known thickness can be used to determine the sound velocity of the coating. As previously discussed, the **FX80** offers a one point calibration option for coating in **PECT** measurement mode. It is also import to reiterate that the coating sample must be coupled to a metallic material in order to perform the calibration. The calibration should also consider calibrating on high side of the intended measurement range, when using the one point option, minimize overall error. For example, if the measurement range of the coating will be from .040" - .080" (1.0mm 2.3mm), a coating closest to .080 (2.0mm) should be used. Note: It's always handy to carry a set of mechanical calipers to use in conjunction with the **FX80** for calibration in the field:

One Point Calibration

CALIBRATE	
MAT	CUSTOM
MATL 1PT	0.500
MATL 2PT	UNCAL
VELOCITY	0.2342
COATING 1PT	0.020
COATING 2PT	UNCAL
COATING VEL	0.0823
PRB	CAL DISP TUNE

Note: Be sure that the probe zero procedure has been performed prior to performing this calibration procedure.

- 1) Physically measure an exact sample of the coating using a set of calipers or a digital micrometer.


Note: The coating sample must be coupled to a metallic material in order to be calibrated.

- 2) Apply a drop of couplant on a piece of metal and place the coating sample on the metal over the couplant. Apply a drop of couplant on the transducer and place the transducer in steady contact with the coating and sample or actual test material. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable. Press the

 key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 3) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **COATING 1PT** is highlighted.



- 4) Press the  key to display the **Digits Edit Box**.
- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

- 6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.
- 7) Repeat steps **5 & 6** until the known thickness value is correctly displayed.

- 8) Press the  key to calculate the velocity and return to the menu screen, or  to cancel the coating one point calibration.

9) Finally, press the  key to return to the measurement screen and begin taking readings.

Note: ***CHECK YOUR CALIBRATION!** Place the transducer back on the calibration point. The coating thickness reading should now match the known thickness. If the thickness is not correct, repeat the steps above.*

9.5 Introduction to Coating Measurement (CT)

In the previous sections we've discussed how to setup and use the coating feature for use in conjunction with material thickness for flaw and pit detection. The **FX80** also has the capability to be used for general coating measurements. This measurement mode is called Coating (CT) and can be enabled using the same methods as described in a previous section above.

When the Coating Only (CT) mode is enabled, a two point calibration on the coating samples **must** be performed. This is to ensure linearity over the coating measurement range will be achieved. **Important note:** If coating measurements will be made with the coating applied to a metal surface, the calibration must be done in the same manner, with the samples coupled to a metal surface. However, if the coating will be measured as a standalone material, the calibration must be performed the same way.

9.6 Two Point Coating Calibration (CT)

Known Thickness

The following section will demonstrate the two point coating calibration procedure. This example demonstrates a coating thickness range of .040" - .120" (1 – 3 mm) as follows:

Note: It's always handy to carry a set of mechanical calipers to use in conjunction with the **FX80** for calibration in the field:

One Point Calibration

CALIBRATE	
MAT	STEEL (4340)
MATL 1PT	UNCAL
MATL 2PT	UNCAL
VELOCITY	0.2330
COATING 1PT	0.025
COATING 2PT	UNCAL
COATING VEL	0.0856
PRB	CAL DISP TUNE


Note: Use the maximum coating sample for the one point calibration first.

- 1) Physically measure the thicker of the two samples of coating, as close as possible to the maximum expected coating measurement range, using a set of calipers or a digital micrometer.

Very Important: If coating measurements will be made with the coating applied to a metal surface, the calibration must be done in the same manner, with the samples coupled to a metal surface. However, if the coating will be measured as a standalone material, the calibration must be performed the same way.


- 2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the thicker of the two coating and samples fist. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable. Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 3) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **COATING 1PT** is highlighted.



- 4) Press the  key to display the **Digits Edit Box**.
- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.
- 6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.
- 7) Repeat steps **5 & 6** until the known thickness value is correctly displayed.
- 8) Press the  key to calculate the velocity and return to the menu screen, or  to cancel the coating one point calibration.
- 9) Finally, press the  key to return to the measurement screen and begin taking readings.

Two Point Calibration




Note: Use the minimum coating sample for the two point calibration.

- 1) Physically measure the thinner of the two samples of the coating, as close as possible to the minimum expected coating measurement range, using a set of calipers or a digital micrometer.


Very Important: *If coating measurements will be made with the coating applied to a metal surface, the calibration must be done in the same manner, with the samples coupled to a metal surface. However, if the coating will be measured as a stand alone material, the calibration must be performed the same way.*

- 2) Apply a drop of couplant on the transducer and place the transducer in steady contact with the thinner of the two coating and samples. Be sure that the reading is stable and the repeatability indicator, in the top left corner of the display, is fully lit and stable. Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **CAL** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 3) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **COATING 2PT** is highlighted.



- 4) Press the  key to display the **Digits Edit Box**.
- 5) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.



- 6) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.
- 7) Repeat steps **5 & 6** until the known thickness value is correctly displayed.
- 8) Press the  key to calculate the velocity and return to the menu screen, or  to cancel the coating one point calibration.
- 9) Finally, press the  key to return to the measurement screen and begin taking readings.

Note: CHECK YOUR CALIBRATION! Place the transducer back on both calibration points. The coating thickness readings should now match the known thickness values of each sample. If the thickness is not correct, repeat the steps above.

CHAPTER TEN

ADDITIONAL FEATURES OF THE FX80

10.1 Auto Find

The **FX80** is equipped with a very handy feature for locating the detection point of a back wall echo that is not currently in the viewable region of the display. Suppose the **FX80** is currently setup with a delay of 0.0" and a width of 1.0", and the user is measuring material thickness of 2.5". The **FX80** will make the correct measurement and display it digitally. However, the waveform will not show up at all in both A-Scan views, and incorrectly in the B-Scan view without adjusting the range of the **Delay** and **Width** accordingly.

The **AUTO FIND** feature is a convenient way to let the **FX80** find the detection point and bring the waveform signal into view automatically. The user can then make small adjustments to the range once the signal is displayed on the screen. The procedure to use the **AUTO FIND** feature is outlined below:

Using Auto Find

UTILITIES	
AUTO FIND	
SCAN MODE	ON
ALARM	ON
ALARM HIGH	1.000
ALARM LOW	0.000
DIFFERENTIAL	OFF
GAUGE	THICKNESS
DATA	UTIL XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **UTIL** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **AUTO FIND** is highlighted.

- 3) Place the transducer on the test material and obtain a reading.
- 4) Press the  key to display the confirmation dialog box “set delay and width values”.
- 5) Press the  key to automatically adjust the display settings and bring the waveform into view.

10.2 High Speed Scan

The High Speed Scan feature of the **FX80** increases the overall repetition rate to a maximum of 140Hz with a high speed screen refresh rate of 25 times a second. This feature enables a user to make scanned passes over an arbitrary length of the test material, while still maintaining a reasonable representation of thickness over the scanned area or region. This feature can be used in conjunction with High and Low alarm limits features to dynamically keep track of both values. The feature is typically used to provide a better representation of the area scanned, by taking more readings at a faster rate repetition rate.

The procedure to use the **SCAN MODE** feature is outlined below:

Using the Scan Mode

UTILITIES	
AUTO FIND	
SCAN MODE	ON
ALARM	ON
ALARM HIGH	1.000
ALARM LOW	0.000
DIFFERENTIAL	OFF
GAUGE	THICKNESS
DATA	UTIL XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **UTIL** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **SCAN MODE** is highlighted.

- 3) Use the  and  arrow keys multiple times on the right button wheel to toggle the **SCAN MODE** on/off.


- 4) Press the  key to return to the measurement screen.

10.3 Alarm Mode

The **Alarm Mode** feature of the **FX80** provides the user with a method of setting tolerances, or limits, for a particular application requirement. This feature may be used for a variety of applications to verify the material is within the manufacturer specifications. There are two limits, or alarm values, that can be setup in the **FX80** – **ALARM LOW** and **ALARM HIGH** limits. However, the user may choose to activate and utilize only one of the limit values, depending on their specific application requirements. The procedures to use the **ALARM MODE** feature are outlined below:

Toggle Alarm (on/off)

UTILITIES		
AUTO FIND		
SCAN MODE		ON
ALARM		ON
ALARM HIGH	1.000	
ALARM LOW	0.000	
DIFFERENTIAL		OFF
GAUGE	THICKNESS	
DATA	UTIL	XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **UTIL** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.
- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **ALARM** is highlighted.
- 3) Use the  and  arrow keys multiple times on the right button wheel to toggle the **ALARM** on/off/audible.
- 4) Continue on to the next section “**Setting the Alarm Low Limit**”.

Setting the Alarm Low Limit

UTILITIES	
AUTO FIND	
SCAN MODE	ON
ALARM	ON
ALARM HIGH	0.400
ALARM LOW	0.200
DIFFERENTIAL	OFF
GAUGE	THICKNESS
DATA	UTIL XFER

UTILITIES	
AUTO FIND	
SCAN MODE	ON
ALARM	ON
ALARM HIGH	0.400
ALARM LOW	0.200
DIFFERENTIAL	OFF
GAUGE	THICKNESS
DATA	UTIL XFER

- 1) Assuming the **ALARM** is **ON**, the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **ALARM LOW** is highlighted.

2) Press the  and  arrow keys multiple times on the right button wheel to scroll the value. When the correct alarm value is being displayed, **proceed to step 7.**

ALARM LOW

0.200

OK
ESC

ALARM HIGH

0.400

OK
ESC

3) **Alternatively**, press the  key to display the **Digits Edit Box**.

4) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

5) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

6) Repeat steps **4 & 5** until the **ALARM LOW** value is correctly displayed.

7) If only one limit will be used, press the  key to return to the measurement screen and begin taking readings. Otherwise, repeat the step outlined above to set the **ALARM HIGH** limit.

10.4 Differential Mode

The **Differential Mode** of the **FX80** provides the user with the ability to set a nominal value, according to what the expected thickness should be, and measure the +/- difference from the nominal value entered. This feature is typically used in QA


incoming inspections on pipes, plate stock, coils, etc. The steps below outline how to enable and enter the nominal value to use this feature:

Toggle Differential (on/off)

UTILITIES	
AUTO FIND	
SCAN MODE	ON
ALARM	ON
ALARM HIGH	0.400
ALARM LOW	0.200
DIFFERENTIAL	OFF
GAUGE	THICKNESS
DATA	UTIL XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **UTIL** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.
- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **DIFFERENTIAL** is highlighted.
- 3) Use the  and  arrow keys multiple times on the right button wheel to toggle the **DIFFERENTIAL** on. A value will appear to the right of **DIFFERENTIAL**.
- 4) Continue on to the next section “**Setting the Differential Value**”.

Setting the Differential Value



- 1) Assuming **DIFFERENTIAL** has been enabled and a value is being displayed to the right of the **DIFFERENTIAL** label, press the  key to display the **Digits Edit Box**.

- 2) Press the  and  arrow keys multiple times using the left button wheel to scroll the highlighted value.

- 3) Press the  and  arrow keys multiple times using the left button wheel to scroll the digit locations.

- 4) Repeat steps **2 & 3** until the **DIFFERENTIAL** value is correctly displayed.

- 5) Press the  key to set the **DIFFERENTIAL** value and return to the menu screen.

- 6) Finally, press the  key to return to the measurement screen and begin taking readings.

10.5 Brightness

The **FX80** is equipped with a brightness feature to adjust the display visibility and optimize battery life. It has an arbitrary scale with a values from 1-20, with 20 representing the brightest setting. The procedures for adjusting the brightness are outlined below:

Adjusting Brightness

SET DISPLAY	
VIEW	RF
DELAY	0.206
RANGE	0.607
B-SCAN SPEED	6
UNITS	IN
BRIGHTNESS	15
COLORS	GREEN 2
<MORE>	
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **DISP** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times on the right button wheel to scroll the **BRIGHTNESS** value.
- 3) Finally, press the  key to return to the measurement screen and begin taking readings.

10.6 Color

The **FX80** has a variety of display color options to select from. These will change the look and feel of the according to the users preference. The procedures for changing the **COLOR**, are outlined below:

Selecting a Color Scheme

SET DISPLAY	
VIEW	RF
DELAY	0.206
RANGE	0.607
B-SCAN SPEED	6
UNITS	IN
BRIGHTNESS	15
COLORS	GREEN 2
<MORE>	
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **DISP** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **COLOR** is highlighted.

SELECT COLOR	
1. GREEN 1	
2. GREEN 2	
3. RED 1	
4. RED 2	
5. BLUE 1	
6. BLUE 2	
7. ORANGE 1	
8. ORANGE 2	
9. MALLARD	
10. GRAYSCALE	
11. BLACK/WHITE	

- 3) Press the  key to display a list of the color scheme options.

- 4) Press the  and  arrow keys multiple times using the left button wheel to scroll through the material list until the appropriate material is highlighted.

- 5) Press the  key, followed by pressing the  key to overwrite the existing color scheme with the selected scheme.
- 6) Finally, press the  key to return to the measurement screen and begin taking readings.

10.7 DIM

The **FX80** has a built-in **DIM** feature to manage power more effectively. This feature has adjustable time durations, until the power of the display is dimmed and current draw reduced. The timer is constantly reset while the user is making measurements, and is only activated when the gauge is idle for the duration of time the **DIM** value is set for. This feature does not override the preset 5 min idle power off feature in any way. However, if the gauge is turned on, set for a DIM of 120sec, and then left idle for 5 minutes, the **FX80** will dim in 2 minutes, then power off in 5 minutes. The procedures for adjusting the **DIM** time are outlined below:

Setting a DIM time

SET DISPLAY	
DELAY	0.206
RANGE	0.607
B-SCAN SPEED	6
UNITS	IN
BRIGHTNESS	15
COLORS	GREEN 2
DIM	240 SEC
<MORE>	
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **DISP** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **DIM** is highlighted.
- 3) Press the  and  arrow keys multiple times on the right button wheel to scroll the **DIM** time.
- 4) Finally, press the  key to return to the measurement screen and begin taking readings.

10.8 Damping

The **FX80** has a built-in damping feature to control the impedance input of the receiver. This enables the user the ability to match and optimize the transducer for better signal quality at various frequencies. The available settings are 50, 75, 100, 300, 600 and 1500 ohms. The procedures below outline the steps for selecting an impedance setting, as follows:

Setting the Damping Value

TUNE SIGNAL	
MEASURE MODE	P-E
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
ATTN	0 DB
GAIN	46.0
AGC	21
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **TUNE** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **DAMPING** is highlighted.

- 3) Use the  and  arrow keys multiple times on the right button wheel to scroll through the **DAMPING** values until the correct value is displayed to the right of the **DAMPING** menu item.

- 4) Finally, press the  key to return to the measurement screen and begin taking readings.


10.9 Graphics Options (look & feel)

We've added a couple of graphic interface features to the **FX80**, accommodate customer requests we've received in the past. These features only serve as cosmetic items, and do not change the functionality of the **FX80** in any way.


RECT Wave:

The rectified wave feature, is only functional when using **RECT** wave view, and provides the user the following display options:

Outline – Draws the unfilled outline of the waveform.




Filled – Draws a filled version of the waveform.




Detect Mark:

The detect mark is another look and feel option for displaying the detection indicator.



10.10 Graticule (A-Scan Background)

The graticule markers in the background of the A-Scan waveform area provide measurement references for depth/thickness versus amplitude. There are multiple options for the user to select an A-Scan background grid/segments to satisfy their graphics preference or 'look and feel'. The procedure to select one of the options is outline below:



Selecting Graticule Option

SET DISPLAY	
COLORS	GREEN 1
DIM	240 SEC
RECT WAVE	FILLED
DETECT MARK	DOTS
WAVE AVERAGING	OFF
PERSISTENCE	OFF
GRATICULE	LINE
<MORE>	
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **DISP** menu is highlighted and displaying the submenu items.


- 2) Use the  and  arrow keys to scroll through the sub menu items until **GRATICULE** is highlighted.

- 3) Use the  and  arrow keys to scroll the **GRATICULE** options.

- 4) Once the desired “look & feel” is displayed, press the  key to return to the measurement screen.

10.11 Polarity

The **FX80** is equipped with an option to select the polarity, or phase +/-, for the purpose of detection. The phase can be a very valuable feature to have when the signal returning from the test material is marginal, a low frequency transducer is being used, and the user has a very weak positive or negative cycle, while trying to measure very thick materials. There is a possibility that signal will become so weak that it falls below the threshold, and peak jumps to the next cycle altogether. This peak jump represents a shift of the detection further out in time, resulting incorrect measurements. The material being measured will appear thicker than it actually is. Refer to the diagram below:



Notice the +/- positions in the diagram. The positive phase is everything above the horizontal center line, and the negative everything below the center line. The **FX80** uses a **zero crossing method for detection**. Therefore, the detect line (**A**) is represented by the broken vertical dotted line, and is currently detecting on the negative portion of the waveform (**B**) at the zero crossing (**C**). The signal amplitude (**B**) is shown as the negative vertical height at (**B**) in the diagram. Refer to the height of the second negative peak at (**G**). It's clear that the amplitude of (**G**) is much greater than that of (**B**). Therefore, if the user was measuring thick attenuative

material, and the amplitude of **(B)** decreased substantially, the **FX80** would lose the first cycle **(B)** and peak jump to the second cycle **(F)**. The detect **(A)**, would move to **(F)**, resulting in incorrect measurements.

If the user were to select the positive phase in the diagram above, the detect would measure at **(H)**. **(A)** would move to **(H)**. Notice the height of **(D)** with respect to the height of **(E)** in the diagram. If the user was measuring thick attenuative material using this phase, the signal **(E)** will certainly be lost long before **(D)**. Therefore, the positive phase is a much better choice in the diagram above.

Toggle Polarity (+/-)

TUNE SIGNAL	
MEASURE MODE	P-E
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
GAIN	46.0
AGC	21
PRB	CAL
DISP	TUNE

Note: Before toggling the **Polarity**, the **FX80** should be set to the **RF** display view option. The **RF** view will give the user the best opportunity to correctly view the positive and negative cycles of the waveform. Please refer to page 63 for information on selecting the **Display Views**.

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **TUNE** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **POLARITY** is highlighted.

- 3) Use the  and  arrow keys multiple times on the right button wheel to toggle the **POLARITY** negative or positive.

- 4) Press the  key to return to the measurement screen and begin taking readings.


Important: *Be sure to do a Probe Zero after changing the polarity!*

10.12 Pulse Width

The **FX80** has an adjustable pulse width option. Pulse width, refers to the duration of time the pulser is left on. This time results in increased energy sent into the test material. There are three width options (**SPIKE**, **THIN**, and **WIDE**). The **SPIKE** setting may be desirable for high resolution and general applications to decrease the overall noise. This can be considered the normal or standard setting. When additional energy is needed, more penetration, the **THIN** and **WIDE** options may be necessary. The procedure to change the pulse width is outlined below:

Selecting the Pulse Width

TUNE SIGNAL	
MEASURE MODE	P-E
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
GAIN	46.0
AGC	21
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **TUNE** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.
- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **PULSE** is highlighted.
- 3) Use the  and  arrow keys multiple times on the right button wheel to scroll the **Pulse** options.
- 4) Once the **Pulse** is displayed, press the  key to return to the measurement screen.

10.13 Pulser Voltage

The **FX80** has a 200 volt square wave pulser that can be adjusted for specific applications and transducers. The Pulser Volt feature offers a 50 volt cut/boost option to the user. The standard setting is 150 volts. This enables the **FX80** to offer greater penetration for difficult material types, or increased resolution on noisy materials. The procedure to change the pulser voltage is outlined below:

Changing the Pulser Voltage

TUNE SIGNAL	
MEASURE MODE	P-E
POLARITY	POSITIVE
PULSE	THIN
PULS VOLT	150
DAMPING	100
GAIN	46.0
AGC	21
PRB	CAL
DISP	TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **TUNE** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **PULSER VOLT** is highlighted.

- 3) Use the  and  arrow keys multiple times on the right button wheel to scroll the **Pulser Voltage** options.

- 4) Once the desired **Pulser Voltage** is displayed, press the  key to return to the measurement screen.

10.14 GAIN SLOPE (TDG)

The **FX80** has a gain slope feature that is similar to a basic linear time corrected gain function, or “time dependent gain” **TDG**. The slope can be adjusted from .1-20 decibels per inch depth. It can be used in both pulse-echo (PE) and echo-echo (E-E) measurement modes. In pulse-echo mode the start can be configured, and in echo-echo mode starts at the first return echo and ramps the gain at the slope setting

selected, until 'max gain' is reached. TDG has a maximum adjustable gain boost of +40 dB. A very useful feature for improving sensitivity and overall output according to depth.

The procedures below outline the steps to enable and set the gain slope, as follows:

Gain Slope

TUNE SIGNAL	
PULSE	THIN
PULSER VOLTAGE	150
DAMPING	100
GAIN	46.0
AGC	21
DETECT	Z-CROSS
TDG SLOPE	0.15
<MORE>	
PRB	CAL DISP TUNE

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **TUNE** menu is highlighted and displaying the submenu items.
- 2) Use the  and  arrow keys to scroll through the sub menu items until  **SLOPE** is highlighted.

GAIN SLOPE DB	
0.15	
OK	ESC

- 3) Use the , ,  &  arrow keys to set the target value.

- 4) Press the  key to set the value and return to the  screen.
- 5) Finally, press the  key to return to the measurement screen and begin taking readings.

10.15 Analog Output

The analog output sends a voltage proportional to the thickness of the material being measured. The minimum thickness setting corresponds to the 0 voltage reference, while the maximum thickness sets the 10 volt reference. These can be fine tuned to match the data acquisition system being used. There are three voltage calibration settings CAL (MIN, MID, MAX). Each can be used to generate an output voltage of 0, 5, 10 volts, to calibrate the data acquisition system.

Analog Output

UTILITIES	
GAUGE	THICKNESS
ANALOG OUTPUT	THICKNESS
SERIAL OUTPUT	OFF
DIGITIZER	1X
KEY CLICK	QUIET
SET DATE	MMDDYY
SHOW DATE	BOTH
<MORE>	
DATA	UTIL
	XFER

1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **UTILS** menu is highlighted and displaying the submenu items.

2) Use the  and  arrow keys to scroll through the sub menu items until **ANALOG OUTPUT** is highlighted.

3) Use the  and  arrow keys to toggle the **ANALOG OUTPUT** .

ANALOG OUTPUT	
MIN THICKNESS	0.000
MAX THICKNESS	0.000
CAL MIN	0V
CAL MID	5V
CAL MAX	10V

- 4) Press the  key to display the **ANALOG OUTPUT** menu.
- 5) Use the  and  arrow keys to scroll through the sub menu items.
- 6) Press the  key to set the desired values.
- 7) Finally, press the  key to return to the measurement screen and begin taking readings.


10.16 Serial Output

The **SERIAL OUTPUT** can be enabled to continuously send thickness measurements to the serial port for data acquisition and reporting. The baud rate is fixed at 9600.

The procedures below outline the steps to enable the serial output, as follows:

Serial Output

UTILITIES	
GAUGE	THICKNESS
ANALOG OUTPUT	OFF
SERIAL OUTPUT	THICKNESS
DIGITIZER	1X
KEY CLICK	QUIET
SET DATE	MMDDYY
SHOW DATE	BOTH
<MORE>	
DATA	UTIL XFER

1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **UTILS** menu is highlighted and displaying the submenu items.

2) Use the  and  arrow keys to scroll through the sub menu items until **SERIAL OUTPUT** is highlighted.

3) Use the  and  arrow keys to toggle the **SERIAL OUTPUT** .


4) Finally, press the  key to return to the measurement screen and begin taking readings.

10.17 Key Click

When a key is pressed on the **FX80** keypad, the user can control whether or not an audible beep is sounded and at what volume level, if any. The procedure for this feature/preference is outlined below:

Setting the Key Click

UTILITIES	
ALARM	ON
ALARM HIGH	1.000
ALARM LOW	0.000
DIFFERENTIAL	OFF
GAUGE	THICKNESS
KEY CLICK	OFF
SET DATE	01/29/04
<MORE>	
DATA	UTIL XFER

1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **UTIL** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **KEY CLICK** is highlighted.

- 3) Use the  and  arrow keys multiple times on the right button wheel to toggle the **KEY CLICK** loud/quiet/off.

- 4) Press the  key to return to the measurement screen.

10.18 Date & Time

The **FX80** is equipped with an internal clock to time and date stamp the log, setup and screen capture files for reporting/documentation purposes. The procedures for setting the time and date are outlined below:

Setting Date & Time

UTILITIES		
AUTO FIND		
SET DATE	09/01/13	
GAUGE	FLAW	
DATA	UTIL	XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **UTIL** menu is highlighted and displaying the submenu items.

Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times on the left button wheel to scroll through the sub menu items until **SET DATE** is highlighted.


ENTER DATE AND TIME	
09/01/13	
■ 4:10:15	
OK	ESC

- 3) Press the  key to display the **Digits Edit Box**.

- 4) Press the , , , &  arrow keys on the left button wheel, to scroll the field locations.

- 5) Press the  and  arrow keys multiple times on the right button wheel to scroll the value.

- 6) Repeat steps **4 & 5** until the **Time & Date** is correctly displayed.

- 7) Press the  key to set the **Time & Date** and return to the menu screen, or  to cancel entering the **Time & Date**.

- 8) Finally, press the  key to return to the measurement screen and begin taking readings.

10.19 Show Date & Time

The **FX80** can be configured to show the date & time in the active A-Scan window as needed or preferred (off/date/time/both). The procedure for activating and displaying the above options are outlined below:

Live Time & Date

UTILITIES	
GAUGE	THICKNESS
ANALOG OUTPUT	OFF
SERIAL OUTPUT	OFF
DIGITIZER	1X
KEY CLICK	QUIET
SET DATE	MMDDYY
SHOW DATE	BOTH
<MORE>	
DATA	UTIL
XFER	

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **UTIL** menu is highlighted and displaying the submenu items.
- 2) Use the  and  arrow keys to scroll through the sub menu items until **SHOW DATE** is highlighted.
- 3) Press the  and  arrow keys multiple times to scroll the options (Date, Time, Both, Off).
- 4) Finally, press the  key to return to the measurement screen and begin taking readings.

10.20 Freeze & Capture

The **FX80** freeze feature enables a user to immediately freeze what's currently being displayed on the screen for further review or analysis. The freeze feature used in conjunction with the capture feature enables a user to save the entire screen shot directly to a **.tif** (tagged image) file format that can be opened using any graphics viewer. With the storage capacity of the **FX80**, and additional external SD card

reader, the user can store as many screens shots as needed. It should also be mentioned that this feature is immediately activated on boot up, therefore all the menus items, list boxes and edit screens can also be captured for presentation or training purposes. The procedure to freeze and capture the display is outlined below:

Capturing Screen Shots

DATA TRANSFER	
COPY SETUPS	
COPY DATA	
COPY SCREENS	
UPGRADE GAUGE	
CAPTURE TO FILE	YES
STORAGE	INTERNAL
ABOUT	DEV 0.03G
DATA	UTIL
XFER	

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **XFER** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **CAPTURE TO FILE** is highlighted.

- 3) Use the  and  arrow keys multiple times on the right button wheel to toggle the **CAPTURE** on/off. Note: Capture will be displayed in a toolbar cell on the active display, indicating the feature is enabled.

- 4) Press the  key to return to the measurement screen.

- 5) To capture a file, press the  key to freeze the screen, followed by pressing it a second time to display the alpha numeric edit box to name and save the screen shot. Note: if capture is not enabled, the  key toggles freeze on/off.

10.21 Capture Viewer

The capture viewer enables a user to view any of the saved screen captures on the SD card, using the **FX80**. This is handy if a PC isn't available, but the user has a need to review the screen shots captured.

The procedure to capture the last screen displayed is outlined below:

Capturing Screen Shots

DATA TRANSFER	
BACKUP SETUPS	
COPY DATA	
COPY SCREENS	
UPGRADE GAUGE	
CAPTURE TO FILE	ON
CAPTURE VIEWER	
STORAGE	INTERNAL
ABOUT	DEV 3.04K
DATA	UTIL
	XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **XFER** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **CAPTURE VIEWER** is highlighted.

IMAGES	
1.	200.TIF
2.	201.TIF
3.	MAXII#1 .TIF
4.	MAXII#2.TIF
5.	202.TIF
6.	203.TIF
7.	204.TIF
8.	205.TIF
9.	210.TIF
10.	207.TIF
11.	208.TIF
12.	211.TIF

- 3) Press the  key to display the list of images (.tif) currently stored on the internal or external SD card.
- 4) Use the  and  arrow keys multiple times using the left button wheel to scroll through the list of images until the desired image is highlighted.
- 5) Press the  key to display the highlighted image, and the  key to close the image and return to the list of images.
- 6) Repeat steps 4-5 as needed.
- 7) Finally, press the  key to close the **VIEWER** and return the measurement screen.

CHAPTER ELEVEN

DATA STORAGE – SETUP, EDIT, & VIEW FILES

11.1 Introduction to Grid and Sequential file formats

The **FX80** is equipped with two data file format options, **GRID LOG** and **SEQ LOG**. The **GRID** file format is very similar to a spreadsheet format found in popular software programs like Excel. A **GRID** is simply a table of readings. A location in a grid is specified by giving a row and column coordinate. The rows are numbered from 1 to 999 and the columns are labeled from A to ZZ (999 Rows & 52 Columns). The sequential file format can be viewed as a file as a single column of up to 512 possible rows (readings), and a column of corresponding identifiers associated with each individual reading. The identifier can be a combination of up to 10 numeric, alpha, or special characters listed above, while the file name can consist of a combination of up to 20 of the same character set. Note: *The identifier cannot start or end with a special character.* Once a start and end ID are entered into the **FX80** and the log created, the **FX80** will automatically generate all the identifiers within that range.

The following character set listed below are all the allowable characters that will be used for both file formats: **GRID & SEQ LOG**. Any combination of these characters can be used for creating a Name and Note regardless of the selected format. The allowable characters are as follows:

Numeric characters: 0 – 9 **Alpha Characters:** A – Z

Special Characters: ! ' _ # space / . – ()

Multiple grids can be created and stored until the **FX80**'s memory is full. If the user attempts to store a new file in the **FX80** and the size of the file exceeds the capacity of memory, the **FX80** will respond with an error message indicating that the memory is unable to store the new file.

The **FX80** has a very large potential storage capacity, and depending on the configuration of SD card sizes versus data, setups and screen capture images, can store limitless amount of data. The **FX80** has an internal SD of 4 gigabytes, and an external slot reader that has been successfully tested with a 64 gigabyte card. Therefore, available memory will not be an issue.

In the sections that follow, the procedures for creating, using, and editing **GRID's** and **SEQ LOG's** have been combined together for the purpose of similarity in overall functionality and structure. The illustrations below are snapshots of typical **GRID** and **SEQ LOG** file formats:

Grid File Formats

NAME: EX#1				NAME: EX#2			
	A	B	C		D	E	F
1				6			
2				7			
3				8			
4				9			

Sequential Log Formats

NAME: EX#1		NAME: EX#2	
AA		01	
AB		02	
AC		03	
AD		04	
AE		05	

NAME: EX#3		NAME: EX#4	
3A		BCD-4-01	
3B		BCD-4-02	
3C		BCD-4-03	
3D		BCD-4-04	
3E		BCD-4-05	

Important Note: For the duration of this chapter, all references to **GRIDS** and **SEQ LOGS** should be considered synonymous with references to **FILES**.

11.2 Creating a new Grid or Sequential Log (File)

Important Note: This entire section is a step by step guide to successfully create a grid or sequential log. The instructions must be used in the sequential order specified, as follows:

Creating a Name

Grid/Seq Log Name : Can contain a combination of up to 20 numeric, alpha, or special characters listed in the first section of this chapter.



Grid Log



Sequential Log

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the  menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **NEW** is highlighted.

- 3) Press the  and  arrow keys multiple times on the right button wheel to toggle the data formats – **GRID LOG & SEQ LOG**.

NEW GRID LOG	
NAME: BOILER 34	
NOTE:	
TOP LEFT:	A001
LOWER RIGHT	C050
INCR. DIR:	EAST
SAVE GRAPHICS	NO
CREATE GRID?	
GRID SIZE:	150

Grid Log

NEW SEQ LOG	
NAME: BOILER 34	
NOTE: INSP#99	
START:	B001
END ID:	01
DIRECTION:	NONE
SAVE GRAPHICS	NO
CREATE LOG	
LOG SIZE:	0

Sequential Log

- 4) Press the  key to display the new **Grid** or **Seq Edit Box**.
- 5) Use the  and  arrow keys on the left button wheel to scroll through the new **Grid** or **Seq List Items** until **NAME** is highlighted.

LOG NAME
0123456789
! ' _ # / . - ()
A B C D E F G H I J
K L M N O P Q R S T
U V W X Y Z
BOILER 34

OK

ESC

- 6) Press the  key to activate the **Alpha Edit Box**.
- 7) Use the , , , &  arrow keys on the left button wheel to highlight the appropriate alpha characters.

- 8) Press the  key to select a character and advance to the next field of the **Grid** or **Seq Name**.
- 9) Use the  key to backspace if necessary.
- 10) Repeat steps 6 - 9 until the **Grid** or **Seq Name (File Name)** is completed.
- 11) Press the  key to save the **Grid** or **Seq Name** and return to the **Grid** or **Seq List Items** menu, or  to cancel entering the **Grid** or **Seq Name (File Name)**.

Creating a Note

Grid/Seq Log Note: Can contain a combination of up to 20 numeric, alpha, or special characters listed in the first section of this chapter.

NEW GRID LOG	
NAME:	BOILER 34
NOTE:	INSP#99
TOP LEFT:	A001
LOWER RIGHT	A001
INCR. DIR:	NONE
SAVE GRAPHICS	NO
CREATE GRID?	
GRID SIZE:	1

Grid Log

NEW SEQ LOG	
NAME:	BOILER 34
NOTE:	INSP#99
START:	B001
END ID:	01
DIRECTION:	NONE
SAVE GRAPHICS	NO
CREATE LOG	
LOG SIZE:	0

Sequential Log

- 1) Assuming the **Grid** or **Seq** List Items are displayed, use the  and  arrow keys using the left button wheel to scroll through the new **Grid** or **Seq List Items** until **NOTE** is highlighted.

- 2) Press the  key to activate the **Alpha Edit Box**.

LOG NOTE										
0	1	2	3	4	5	6	7	8	9	
!	'	_	#	█	/	.	-	(	)	
A	B	C	D	E	F	G	H	I	J	
K	L	M	N	O	P	Q	R	S	T	
U	V	W	X	Y	Z					
INSP#99 █										

OK

ESC

- 3) Use the , , , &  arrow keys on the left button wheel to highlight the appropriate alpha characters.
- 4) Press the  key to select a character and advance to the next field of the **Grid** or **Seq Note**.
- 5) Use the  key to backspace if necessary.
- 6) Repeat steps 3 through 5 until the **Grid** or **Seq Note** is completed.
- 7) Press the  key to save the **Grid** or **Seq Note** and return to the **Grid** or **Seq List Items** menu, or  to cancel entering the **Grid** or **Seq Note**.

Setting the Coordinates or Start & Stop ID's

Grid: A grid is defined by using coordinates to define the **Top Left** and the **Bottom Right** corners of the grid. Alpha coordinates are horizontal across the

top, and numeric coordinates are vertical down the side. Therefore, to define the top left corner of the grid, there will be an (X,Y) coordinate. Where X is an alpha column location across the top and Y is a numeric row location down the side. Use the same logic when choosing the lower right corner. An individual grid can be up to 999 rows and 52 columns.

Sequential: The sequential file format can be viewed as a file as a single column of up to 512 possible rows (readings), and a column of corresponding identifiers associated with each individual reading. The identifier can be a combination of up to 10 numeric, alpha, or special characters listed above, while the file name can consist of a combination of up to 20 of the same character set. Note: *The identifier cannot start or end with a special character.* Once a start and end ID are entered into the **FX80** and the log created, the **FX80** will automatically generate all the identifiers within that range.

Setting the Top Left(Grid) or Start ID(Seq)

NEW GRID LOG	
NAME:	BOILER 34
NOTE:	INSP#99
TOP LEFT:	A001
LOWER RIGHT	A001
INCR. DIR:	NONE
SAVE GRAPHICS	NO
CREATE GRID?	
GRID SIZE:	1

Grid Log

NEW SEQ LOG	
NAME:	BOILER 34
NOTE:	
START:	B001
END ID:	01
DIRECTION:	NONE
SAVE GRAPHICS	NO
CREATE LOG	
LOG SIZE:	0

Sequential Log

- 1) Use the  and  arrow keys on the left button wheel to scroll through the new **Grid** or **Seq List Items** until **TOP** or **START ID** is highlighted.

- 2) Press the  key to activate the **Coordinate** or **Start ID Edit Box**.




Grid Log



Sequential Log

- 3) **GRID LOG:** Use the ,  arrow keys on the left button wheel to scroll the **Columns**, and the ,  arrow keys on the left button wheel to scroll the **Rows**.

SEQ LOG: Use the , , ,  arrow on the left button wheel keys to highlight the appropriate alpha characters. Press the  key to select character and advance to the next character field, in conjunction with using the  key to backspace if necessary.

- 4) Press the  key to select the coordinate or start ID and return to the **Grid** or **Seq List Items** screen, or  to cancel the selection and return to the **Grid** or **Seq List Items** menu.

Setting the Bottom Right(Grid) or End ID(Seq)

NEW GRID LOG	
NAME:	BOILER 34
NOTE:	INSP#99
TOP LEFT:	A001
LOWER RIGHT	C050
INCR. DIR:	NONE
SAVE GRAPHICS	NO
CREATE GRID?	
GRID SIZE:	150

Grid Log

NEW SEQ LOG	
NAME:	BOILER 34
NOTE:	INSP#99
START:	B001
END ID:	B150
DIRECTION:	NONE
SAVE GRAPHICS	NO
CREATE LOG	
LOG SIZE:	150


Sequential Log

- 1) Use the  and  arrow keys on the left button wheel to scroll through the new **Grid** or **Seq List Items** until **LOWER**  or **END ID** is highlighted.

- 2) Press the  key to activate the **Coordinate** or **End ID Edit Box**.



Grid Log



Sequential Log

- 3) **GRID LOG:** Use the  , &  arrow keys on the left button wheel to scroll the **Columns**, and the  ,  arrow keys to scroll the **Rows**.

SEQ LOG: Use the  ,  ,  , &  arrow keys on the left button wheel to highlight the appropriate alpha characters. Press the  key to select a character and advance to the next character field, in conjunction with using the  key to backspace if necessary.

- 4) Press the  key to select the coordinate or end ID and return to the **Grid** or **Seq List Items** screen, or  to cancel the selection and return to the **Grid** or **Seq List Items** menu.

Note: If there is not enough memory available to create the grid or sequential log, an error message box **"NOT ENOUGH MEMORY"** will be displayed. Press

the  or  key to return to the **Grid** or **Seq List Items** menu. It may be necessary to free some memory in the **FX80** at this time. Refer to page 160 for more information on **Deleting a File**.

Selecting the Auto Increment Direction

The **Auto Increment** feature gives the user the ability to specify which direction to advance the cursor after storing a reading.

NEW GRID LOG	
NAME:	BOILER 34
NOTE:	INSP#99
TOP LEFT:	A001
LOWER RIGHT	C050
INCR. DIR:	EAST
SAVE GRAPHICS	NO
CREATE GRID?	
GRID SIZE:	150

Grid Log

NEW SEQ LOG	
NAME:	BOILER 34
NOTE:	INSP#99
START:	B001
END ID:	B150
DIRECTION:	INC
SAVE GRAPHICS	NO
CREATE LOG	
LOG SIZE:	150

Sequential Log

- 5) Use the  and  arrow keys on the left button wheel to scroll through the new **Grid** or **Seq List Items** until **INCR. DIR** or **DIRECTION** is highlighted.

- 6) Use the  &  arrow keys on the left button wheel to toggle the **Increment** direction **NONE, NORTH, EAST, SOUTH, or WEST** for a grid, or **INC, DEC** for a sequential log.

- 7) When the correct **Increment** direction is displayed, continue on to the next section “**Graphics**”.

Saving a Grid

Once all the parameters are set, the user has the option of saving or canceling the new grid.

NEW GRID LOG	
NAME:	BOILER 34
NOTE:	INSP#99
TOP LEFT:	A001
LOWER RIGHT	C050
INCR. DIR:	EAST
SAVE GRAPHICS	NO
CREATE GRID?	
GRID SIZE:	150

Grid Log

NEW SEQ LOG	
NAME:	BOILER 34
NOTE:	INSP#99
START:	B001
END ID:	B150
DIRECTION:	INC
SAVE GRAPHICS	NO
CREATE LOG	
LOG SIZE:	150

Sequential Log

- 1) Use the  and  arrow keys on the left button wheel to scroll through the new **Grid** or **Seq List Items** until **CREATE GRID** or **LOG?** is highlighted.
- 2) Press the  key to accept the grid or seq log parameters and activate the confirmation screen.



Grid Log



Sequential Log

3) Press the  key to save the **New Grid** or **Seq Log**, or the  key to cancel **the New Grid or Seq Log** setup and return to the menu. 

4) Press the  key to return to the measurement screen and begin storing readings.

11.3 Storing a reading

Now that a grid or sequential log has been created, it's time to make some measurements and store the readings. The following procedures outline this process:

Storing a Reading

Note: *Once the grid or sequential log has been created it will automatically be displayed following the create confirmation screen. It is located at the bottom of the measurement screen, and can be left open for the duration of the inspection process. This section assumes the grid or sequential log was just created.*

Refer to the section on “opening a grid or seq log” if the file was created at another time.

Key Feature: When the **FX80** is displaying a “grid log”, pressing the  key will initiate an advance to row number option. Use the **Left, Right,** , and  arrow keys on the left button wheel to enter the row number. Once the row number is correctly displayed, press the  key to advance directly to that row number in the grid log.

Key Feature: When the **FX80** is displaying a “grid log”, pressing the  key multiple times, will toggle through the display options: **DIGITS, RF, RECT,** and **B-SCAN** views.

NAME: EX#1			
	A	B	C
1			
2			
3			
4			

Grid Log

NAME: EX#2	
01	
02	
03	
04	
05	

Sequential Log

- 1) Press the , , , and  arrow keys on the left button wheel to scroll the target cell cursor to the desired storage location.
- 2) Press the  key to save the current reading in the highlighted cell location. It's as simple as that!
- 3) Press the  key to hide the **GRID/SEQ View Box**, or  to display it as necessary.

Note: Once the file is open, it will remain open until it's closed or another file is opened by the user. If the gauge is powered off, the **FX80** will automatically open the file when powered on. Simply press the  key to display the file from the measurement screen.

11.4 Viewing stored readings

It is sometimes necessary to go back and view the stored readings and B-Scans using the **FX80** without a PC. The following procedures outline this process:

Viewing Stored Readings & A/B Scans

CAPTURE		IN		V: 0.2330	
0.102 DELAY 0.004 RANGE 1.517 GAIN 46.0 THRESHS 3 START -0.183 WIDTH3 OFF HOLD3 OFF B003 STEP: 1.0 GN: 46.0					
NAME: BOILER#34					
A		B		C	
1	0.201				
2	0.399			0.500	
3		0.102			
4					

Grid Log

CAPTURE		IN		V:0.2330	
0.403		0.403		DELAY 0.006 RANGE 1.517 GAIN 46.0 THRESH3 3 START -0.181 WIDTH3 OFF HOLD3 OFF STEP: 1.0 B001 B002 0.303 B003 0.205 B004 0.504 B005	

Sequential Log

- 1) Press the  key once to activate measure menu items. Press the  key multiple times to move right and the  key multiple times to move left until the **LOG** cell is highlighted. Alternatively, press the  and  arrow keys multiple times using the left button wheel.


NAME: GRID LOG			
	A	B	C
1	0.273	0.300	
2	0.523		
3			
4			

- 2) Press the  key to display the **Grid Log Box**.
- 3) Press the , , , and  arrow keys on the left button wheel to scroll the stored readings and corresponding display view. Notice as the cursor is moved to a different cell, the display will be updated with the display view saved with the reading. Readings stored in memory are indicated by displaying a **MEM** in the top left corner of the measurement screen.
- 4) The user may opt to clear a specific reading and save a new one at any time. Press the  key in the appropriate cell location to clear the reading, take a new measurement, and press the  key to save the new reading.
- 5) Abort the **Grid/Seq Log View Box** by pressing the  key at any time.

11.5 Deleting Grids (Files)

Deleting One or All Files from Memory

Deleting One File

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the  menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

STORE DATA	
NEW	SEQ LOG
EDIT	
OPEN	
CLOSE	
DELETE ONE FILE	
DELETE ALL DATA	
DATA	UTIL XFER


- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **DELETE ONE FILE** is highlighted.

DELETE LOG	
1. CH'S	
2. TEST	
3. WILL	
4. E	
5. EFE	
6. EED	
7. EX#1	
8. BOILER 34	
9. BOILER#35	
10. ED	
11. BOILER#34	
12. BOILER#33	


- 3) Press the  key to display the **File List Box**.
- 4) Use the  and  arrow keys on the left button wheel to scroll through the stored **Files** until the target **File** to delete is highlighted.
- 5) Press the  key to delete the **File**.
- 6) Press the  key to return to the measurement screen.

Deleting All Data

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the  menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.



- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **DELETE ALL**  is highlighted.



- 3) Press the  key to activate the confirmation screen.
- 4) Press the  key to delete **All Files** from memory, or the  key to abort.

- 5) Press the  key to return to the measurement screen.

11.6 Editing a Grid (File)

Once a grid has been created and saved to memory, the user can edit the **Name**, **Comments**, or **Increment Direction** at a later time. The following procedures outline this process:

Editing a Grid

EDIT GRID LOG	
NAME:	COILER#34
NOTE:	
TOP LEFT:	A001
LOWER RIGHT	D004
INCR. DIR:	NONE
SAVE GRAPHICS	ON
SAVE CHANGES?	
LOG SIZE	16

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the  menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.
- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **EDIT** is highlighted.
- 3) Press the  key to display the **Edit List Box**.
- 4) Use the  and  arrow keys on the left button wheel to scroll through the **Edit** options until **NAME**, **NOTE** or **INCR. DIR** is highlighted.

Note: If editing the **INCR. DIR**, simply press the  and  arrow keys using the left button wheel to scroll **NONE, NORTH, EAST, SOUTH, WEST** for a Grid, or **INC, DEC** for a Seq Log. **Proceed to step 10.**

LOG NOTE															
0	1	2	3	4	5	6	7	8	9						
!	'	_	#	■	/	.	-	(	)						
A	B	C	D	E	F	G	H	I	J						
K	L	M	N	O	P	Q	R	S	T						
U	V	W	X	Y	Z										
INSP#99■															

OK

ESC

5) Press the  key to activate the **Alpha Edit box** – Only used when editing the **NOTE**.

6) Use the , , , &  arrow keys on the left button wheel to highlight the appropriate alpha characters.

7) Press the  key to select a character and advance to the next field of the **Comments**.

8) Use the  key to backspace if necessary.

9) Repeat steps 6 - 8 until the **Comments** are completed.

EDIT GRID LOG

NAME:	BOILER#34
NOTE:	
TOP LEFT:	A001
LOWER RIGHT:	D004
INCR. DIR:	NONE
SAVE GRAPHICS	ON
SAVE CHANGES?	
LOG SIZE	16

10) Press the  or  arrow key to highlight **SAVE CHANGES**, and the  key to activate the confirmation screen.

DATA LOG

 OVERWRITE
CURRENT
GRID



OK
ESC

11) Press the  key to save the changes or the  key to cancel editing the file parameters.

12) Press the  key to return to the measurement screen.

11.7 Changing the active File - Open

The user may have transferred grid/seq templates from a PC to the **FX80**, or setup grids/seq using the **FX80** at an earlier time. The name of the currently active file is always displayed at the top of the **Grid/Seq Box** in measurement mode (refer to photo below). It's not only important to recognize what file is currently active, but also be able to change the active file at any time. The following procedures outline this process:

Changing the Active File

NAME	CAPTURE	IN	V:0.2330
0.102			
NAME: BOILER#34			
A	B	C	
1	0.201		
2	0.399		0.500
3		0.102	
4			
DELAY 0.004 RANGE 1.517 GAIN 46.0 THRESH3 3 START -0.183 WIDTHS OFF HOLD3 OFF B003 STEP: 1.0 GN: 46.0			

Grid Log

NAME	CAPTURE	IN	V:0.2330
0.403			
NAME: BOILER#33			
B001	0.403		
B002	0.303		
B003	0.205		B001
B004	0.504		
B005			
DELAY 0.006 RANGE 1.517 GAIN 46.0 THRESH3 3 START -0.181 WIDTHS OFF HOLD3 OFF B001 STEP: 1.0 GN: 46.0			

Sequential Log

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the  menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

STORE DATA	
NEW	SEQ LOG
EDIT	
OPEN	
CLOSE	
DELETE ONE FILE	
DELETE ALL DATA	
DATA	UTIL XFER

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **OPEN** is highlighted.

OPEN LOG	
1. CH'S	
2. TEST	
3. WILL	
4. E	
5. EFE	
6. EED	
7. EX#1	
8. BOILER 34	
9. BOILER#35	
10. ED	
11. BOILER#34	
12. BOILER#33	

- 3) Press the  key to display the **Grid/Seq List Box**.
- 4) Use the  and  arrow keys on the left button wheel to scroll through the grids until the target grid is highlighted.

CONFIRM

LOAD DATA FROM
MEMORY?

?

OK
ESC

- 5) Press the  key to activate the confirmation screen.
- 6) Press the  key to load the file from memory.
- 7) Press the  key to return to the measure screen.

11.8 Closing an active File - Close

A user might not have a current requirement to store measurements, but a file is currently open or active and needs to be closed. The following procedures outline how to close an open or active file:

Closing an Active File

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the  menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

STORE DATA	
NEW	SEQ LOG
EDIT	
OPEN	
CLOSE	
DELETE ONE FILE	
DELETE ALL DATA	
DATA	UTIL XFER

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **CLOSE** is highlighted.

STORE DATA	
NEW	SEQ LOG
EDIT	
OPEN	
CLOSE	
DELETE ONE FILE	
DELETE ALL DATA	
DATA	UTIL XFER

- 3) Press the  key to close the active file. **Note:** Following the key press, the **CLOSE** text will be grayed out indicating the file has been closed and is no longer active.

CHAPTER TWELVE

SETUPS – CREATE, STORE, EDIT, & RECALL

12.1 Introduction to Setups

Often times, users are faced with a variety of tasks and applications that are sometimes similar, but often times very different. With a standard thickness gauge, the user would have to recalibrate for each individual application respectively. With all the features of the **FX80**, the number of potential applications also increases based on ability alone. This is primarily in reference to the addition of those very difficult applications, where a standard thickness gauge would not be feasible, or capable of accomplishing the tasks.

The increased number of features and parameters also adds to the overall setup time, or amount of time to set up marginal applications with perfection and understanding. Because of the additional time involved, the **FX80** has been equipped with the ability to save these setups to memory and be recalled at any time. The **FX80** can store up to **64 custom setups**. These setups can be bi-directionally transferred to and from a PC. Therefore, the user can save as many setups as necessary for all their individual applications requirements. This saves a great deal of time and knowledge for future inspections of the same job or project. This feature also eliminates error between two or more users during the setup and calibration process.

12.2 Opening a Setup

The **FX80** is loaded with a number of setups from the factory. These setups can be opened, edited, and saved to any one of **64 setup locations**. If a factory setup is written over, the user can simply reload the default factory setups at anytime using the utility software included with the **FX80**. The factory setups are general setups **Only**. However, they may serve as an excellent starting point, requiring only minor adjustments to work for custom applications. It is recommended that user customized setups be saved to an empty location, and save the factory setups for the purpose of a general starting point. The following procedures outline how to open factory and custom setups:

Opening a Setup

SETUP OPTIONS			
OPEN			
SAVE			
DELETE			
DEFAULT SETUP			
LANGUAGE			ENGLISH
GT1	GT2	GT3	SET

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **SETUP** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **OPEN** is highlighted.

LOAD SETUP	
1.	EXAMPLE OF SETUP
2.	TCG
3.	
4.	
5.	
6.	
7.	
8.	
9.	
10.	
11.	
12.	

- 3) Press the  key to display the **Setup List Box**.
- 4) Use the  and  arrow keys on the left button wheel to scroll through the setups until the target setup is highlighted.

CONFIRM

OVERWRITE STORED
SETTINGS

?

OK
ESC

5) Press the key to activate the confirmation screen.

6) Press the key to load the setup from memory.

7) Press the key to return to the measure screen.

12.3 Saving a Setup

Once the **FX80** parameters and features have been adjusted for an application, the user may elect to save these settings to a specific setup location for future use. This can potentially save time and reduce error between users.

It is sometimes necessary to rename a previously saved setup, or add additional comments about a particular setup. The setup name may have been entered incorrectly, or the user needs to use the setup for a completely different project. An inspector's name or other comments about the project may also be required for additional documentation purposes. The following procedures outline the necessary steps for saving and editing a setup:

Saving a Setup

SETUP OPTIONS

OPEN


SAVE

DELETE

DEFAULT SETUP

LANGUAGE ENGLISH

GT1
GT2
GT3
SET

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **SETUP** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **SAVE** is highlighted.

SAVE SETUP
NAME: EX#1
NOTE:
SAVE SETUP

SAVE SETUP
NAME: EX#1
NOTE: INSP#99
SAVE SETUP

- 3) Press the  key to display the **Save Setup Parameters List Box**.

- 4) Press the  and  arrow keys on the left button wheel to scroll the **Name** and **Note** parameters.

SETUP NAME
0123456789
! ' _ # / . - ()
A B C D E F G H I J
K L M N O P Q R S T
U V W X Y Z
EX#1

OK

ESC

SETUP NOTE
0123456789
! ' _ # / . - ()
A B C D E F G H I J
K L M N O P Q R S T
U V W X Y Z
INSP#99

OK

ESC

- 5) When the parameter to edit is highlighted, press the  key to activate the **Alpha Edit Box**.

- 6) Use the , , , &  arrow keys on the left button wheel to scroll through the characters, the  key to select characters, and the  key to backspace through the characters, until the **Name** or **Note** fields have been edited.

- 7) Press the  key to return to the **Save Setup Parameters List Box**.

- 8) If both parameters will be edited, **repeat steps 4 – 7**.

SAVE SETUP
NAME: EX#1
NOTE: INSP#99
SAVE SETUP

- 9) Use the  and  arrow keys on the left button wheel to scroll to and highlight **SAVE SETUP**.

- 10) Press the  key to activate the **Setup List Box**.

LOAD SETUP
1. EXAMPLE OF SETUP
2. TCG
3.
4.
5.
6.
7.
8.
9.
10.
11.
12.

- 11) Use the  and  arrow keys on the left button wheel to scroll through the setups until the target location to save the **Setup** is highlighted.

CONFIRM	
OVERWRITE STORED SETTINGS	
?	
OK	ESC

- 12) Press the  key to activate the confirmation screen.

- 13) Press the  key to save the **Setup**, or  to cancel saving the **Setup**.

- 14) Finally, press the  key to return to the measurement screen.

Note: The **Name** and **Comments** of the **Setup** can be edited at any time by simply repeating the **Save Setup** routine described above. Therefore, the **Save Setup** function can also be considered an **Edit Function**.


12.4 Deleting a Saved Setup

This option allows a user to delete setup files that were previously saved and no longer needed. It's a simple feature to allow the user to do a bit of "house cleaning".

<u>Deleting a Setup</u>			
SETUP OPTIONS			
OPEN			
SAVE			
DELETE			
DEFAULT SETUP			
LANGUAGE		ENGLISH	
GT1	GT2	GT3	SET

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **SETUP** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **DELETE** is highlighted.



- 3) Press the  key to display the **Setups List**.

- 4) Press the  and  arrow keys on the left button wheel to scroll to the **Setup Name**.

- 5) When the **Setup Name** is highlighted, press the  key to display the confirmation screen.



6) Press the  key to delete the **Setup File**.

7) Finally, press the  key to return to the measurement screen.

12.5 Using the Default Setup

The default setup feature was added to the **FX80** to use, as a last resort, if there are no setups stored in the gauge –factory or otherwise. The only time this might possibly occur is if the setup file in the **FX80** was somehow corrupted, and the user does not have access to a computer to re-load the factory setups back into the **FX80**. This gives the user the ability to load and modify a basic setup as follows:

Note: *The default file contains no probe zero data. Therefore, a zero must be performed after loading. Also, the default setup can be loaded when using the flaw mode feature, to eliminate the probe zero delay value, and start at the initial pulse or zero.*

Using the Default Setup

SETUP OPTIONS			
OPEN			
SAVE			
DELETE			
DEFAULT SETUP			
LANGUAGE		ENGLISH	
GT1	GT2	GT3	SET

1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **SETUP** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) the  and  arrow keys on the left button wheel to scroll through the sub menu items until **DEFAULT SETUP** is highlighted.
- 3) Press the  key to load default **DEFAULT SETUP**.
- 4) Finally, press the  key to return to the measurement screen.

12.6 Selecting a Language

The **FX80** is equipped with a language option. Currently, only a few languages supported. However, be sure to update your gauge firmware often, to check for language additions. The steps to select a language are outlined as follows:

Selecting a Language

SETUP OPTIONS			
OPEN			
SAVE			
DELETE			
DEFAULT SETUP			
LANGUAGE			ENGLISH
GT1	GT2	GT3	SET

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **SETUP** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until **LANGUAGE** is highlighted.

- 3) Press the  and  arrow keys multiple times on the right button wheel to toggle the language options.

- 4) Once the desired language is displayed, press the  key to return to the measurement screen.

CHAPTER THIRTEEN

SOFTWARE, FILE TRANSFER, & UPGRADES

13.1 Computer System Requirements

DakView will run on many different operating systems: Windows XP, Windows 2000 Professional, Windows 2000 Server, Windows 2000, Vista, Windows 7, or Windows 8 Advanced Server operating systems running on Intel or AMD hardware.

A Pentium 166MHz or faster processor with at least 32 megabytes of physical RAM is required. You should have 40 megabytes of free disk space before attempting to install **DakView**.

USB Type1 to Type 2 Cable

If a replacement cable is needed, contact Dakota NDT (pt# N-606-0530).

13.2 Installing DakView

DakView comes on a CD-ROM with an automatic installer program. Place the CD in your computer's CD tray and close the door. Open the CD-ROM by double clicking on the My Computer ICON, then double click on the CD. Finally, double click on the **SETUP** icon to begin the installation. Refer to the help section in **DakView** software for the complete operating manual, setup, and operation.

13.3 Communicating with FX80

DakView will not directly communicate with the **FX80** series gauges. The **FX80** is equipped with USB, acting as a Thumb Drive (external storage device) when connected to a computer and powered on. Therefore, the SD memory card(s) can be opened as a drive with *directory structure, similar to the C: on your computer*. The files stored on the internal SD, or external SD reader, can be simply copied (dragged) into any folder on your PC and opened using **DakView**. The PC software will function on as a file viewer for the **FX80** series gauges.

Refer to the help section in **DakView** software for the complete operating manual, setup, and operation.

13.4 Using the XFER menu (FX80)

The **XFER** menu of the **FX80** will be used in conjunction with the **DakView** PC software. The steps below outline the procedure for accessing the **XFER** menu and basic operation as follows:

Accessing and Using the XFER Menu

DATA TRANSFER	
COPY SETUPS	
COPY DATA	
COPY SCREENS	
UPGRADE GAUGE	
CAPTURE TO FILE	YES
STORAGE	EXTERNAL
ABOUT	DEV 0.05G
DATA	UTIL
	XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right, and the  key multiple times to tab left, until the **XFER** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until the desired option is highlighted.

- 3) Press the  key to activate the option selected.

13.5 Selecting Storage Device

The **FX80** has two storage device options available. The **FX80** is shipped from the factory with a 4 gig internal SD memory card on the board itself, and additionally has an external SD card reader. The SD reader is located above the Li-Ion battery pack, under the battery cover. The **STORAGE** utility simply selects which card is currently being used as the primary storage device. This storage switch is also used in conjunction with all the copy utilities found in the **XFER** menu. For example; if the

storage switch is set to internal as the primary storage device, all the copy routines will copy from the internal to the external reader, or visa versa. The procedure to set the storage device is outlined below:

Selecting Storage Device

DATA TRANSFER	
COPY SETUPS	
COPY DATA	
COPY SCREENS	
UPGRADE GAUGE	
CAPTURE TO FILE	YES
STORAGE	EXTERNAL
ABOUT	DEV 0.03G
DATA	UTIL
XFER	

SET STORAGE TO:
INTERNAL REQUIRES FULL RESTART. SAFELY REMOVE FROM PC. SHUTDOWN NOW
?
OK ESC

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **XFER** menu is highlighted and displaying the submenu items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.
- 2) Use the  and  arrow keys multiple times using the left button wheel to scroll through the sub menu items until **STORAGE** is highlighted.
- 3) Use the  and  arrow keys multiple times on the right button wheel to toggle **STORAGE** internal/external. Note: Capture will be displayed in a toolbar cell on the active display, indicating the feature is enabled.

13.6 Copying Files (Setups, Data, & Screenshots)

The **FX80** can store a number of setup, data and screenshot files to either the internal or external SD memory cards. All the copy routines will copy files from the currently selected storage device to the other. Therefore, if the current storage device is set to 'internal', the copy routines will transfer files directly to the external device. Note: If the **FX80** is powered up without an external SD card inserted in the slot, the copy routines in the **XFER** menu will be inactive. The steps below outline the procedure for copying files from one storage device to the other as follows:

Copying Files Between Storage Devices

DATA TRANSFER	
COPY SETUPS	
COPY DATA	
COPY SCREENS	
UPGRADE GAUGE	
CAPTURE TO FILE	YES
STORAGE	EXTERNAL
ABOUT	DEV 0.03G
DATA UTIL	XFER

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **XFER** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Use the  and  arrow keys on the left button wheel to scroll through the sub menu items until the desired **COPY** option is highlighted.

SCREEN LIST
ALL SCREENS
SELECT A SCREENS

- 3) Press the  key to display the **Setups/Data/Scens List**.
- 4) Use the  and  arrow keys on the left button wheel to highlight the desired **List Box** option.

FILE LIST	
1.	PIC#2
2.	PIC#3
3.	PIC#4
4.	PIC#5

- 5) Press the  key to either transfer **ALL** files, or display the **Individual List** of files.
- 6) Use the  and  arrow keys on the left button wheel to scroll through the list of files and select the specific file to copy.
- 7) Press the  key to complete the **Copy** process, followed by pressing the  key to display the **List Box**.
- 8) Repeat steps **6 & 7** to copying additional individual files.
- 9) Finally, press the  key to return to the measurement screen.


13.7 Upgrading the FX80

The **FX80** can be upgraded to the latest revision of firmware at any time. Simply download the latest version posted on the Dakota NDT website, copy the upgrade file to the main drive directory **FX80**, and use the upgrade utility located in the **XFER** menu. The process is very easy and convenient, allowing our users to stay current with updated feature additions and bug fixes. The procedure to upgrade your **FX80** is outlined below:

Upgrading the Firmware

DATA TRANSFER	
COPY SETUPS	
COPY DATA	
COPY SCREENS	
UPGRADE GAUGE	
CAPTURE TO FILE	YES
STORAGE	EXTERNAL
ABOUT	DEV 0.03G
DATA	UTIL XFER

UPGRADE GAUGE	
LOAD FILE	
DFX8_GAUGE	
TO FLASH	
?	
OK	ESC

- 1) Press the  key once to activate the menu items tab. Press the  key multiple times to tab right and the  key multiple times to tab left until the **XFER** menu is highlighted and displaying the submenu

items. Alternatively, press the  and  arrow keys multiple times using the left button wheel.

- 2) Press the  key to display the upgrade confirmation screen, followed by pressing  key to start the upgrade process. Note: The **FX80** will power down during the upgrade process, and restart when completed.

APPENDIX A - VELOCITY TABLE

Material	sound velocity in/us		sound velocity m/s
Aluminum	0.2510		6375
Beryllium	0.5080		12903
Brass	0.1730		4394
Bronze	0.1390		3531
Cadmium	0.1090		2769
Columbium	0.1940		4928
Copper	0.1830		4648
Glass (plate)	0.2270		5766
Glycerine	0.0760		1930
Gold	0.1280		3251
Inconel	0.2290		5817
Iron	0.2320		5893
Cast Iron	0.1800	(approx)	4572
Lead	0.0850		2159
Magnesium	0.2300		5842
Mercury	0.0570		1448
Molybdenum	0.2460		6248
Monel	0.2110		5359
Nickel	0.2220		5639
Nylon	0.1060	(approx)	2692
Platinum	0.1560		3962
Plexiglas	0.1060		2692
Polystyrene	0.0920		2337
PVC	0.0940		2388
Quartz glass	0.2260		5740
Rubber vulcanized	0.0910		2311
Silver	0.1420		3607
Steel (1020)	0.2320		5893
Steel (4340)	0.2330		5918
Steel Stainless"	0.2230		5664
Teflon	0.0540		1372

Tin	0.1310		3327
Titanium	0.2400		6096
Tungsten	0.2040		5182
Uranium	0.1330		3378
Water	0.0580		1473
Zinc	0.1660		4216
Zirconium	0.1830		4648

APPENDIX B - SETUP LIBRARY

Num	Name	Comment 1	Gn/AGC	Velocity
1	Enter Custom Name			
2	...			
3	...			
4	...			
5	...			
6	...			
...	...			

WARRANTY INFORMATION

• Warranty Statement •

Dakota NDT warrants the **FX80** against defects in materials and workmanship for a period of two years from receipt by the end user. Additionally, Dakota NDT warrants transducers and accessories against such defects for a period of 90 days from receipt by the end user. If Dakota NDT receives notice of such defects during the warranty period, Dakota NDT will either, at its option, repair or replace products that prove to be defective.

Should Dakota NDT be unable to repair or replace the product within a reasonable amount of time, the customer's alternative exclusive remedy shall be refund of the purchase price upon return of the product.

• Exclusions •

The above warranty shall not apply to defects resulting from: improper or inadequate maintenance by the customer; unauthorized modification or misuse, or operation outside the environmental specifications for the product.

Dakota NDT makes no other warranty, either express or implied, with respect to this product. Dakota NDT specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Some states or provinces do not allow limitations on the duration of an implied warranty, so the above limitation or exclusion may not apply to you. However, any implied warranty of merchantability or fitness is limited to the five-year duration of this written warranty.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state or province to province.

• Obtaining Service During Warranty Period •

If your hardware should fail during the warranty period, contact Dakota NDT and arrange for servicing of the product. Retain proof of purchase in order to obtain warranty service.

For products that require servicing, Dakota NDT may use one of the following methods:

- Repair the product
- Replace the product with a re-manufactured unit
- Replace the product with a product of equal or greater performance
- Refund the purchase price.

• After the Warranty Period •

If your hardware should fail after the warranty period, contact Dakota NDT for details of the services available, and to arrange for non-warranty service.