DR-62 CLEANER-REMOVER

Approved Class 2, MIL-I-25135 Rev. E, and AMS-2644



PRODUCT INFORMATION

Description: DR-62 Cleaner-Remover is used in the penetrant process to remove excess penetrants from part surfaces, e.g., Sherwin DP-40 Dye Penetrant (visible red) and Sherwin RC-65 and RC-77 Fluorescent Penetrants. It is a manual "wipe on"

and "wipe off" material and, consequently, recommended for small areas. **DR-62** may also be used for generally cleaning oily, dirty surfaces. **DR-62** is especially suitable for cleaning prior to the application of inspection penetrants.

DR-62 meets low halogen and low sulphur requirements. It is a nonchlorinated material and non-miscible in water. It is relatively volatile and evaporates completely and rapidly. **DR-62** meets MIL-I-25135 and AMS-2644 requirements.

Special Features: DR-62 Cleaner may be used for removing excess surface penetrant during the inspection process. DR-62 Cleaner also is a replacement for DR-61, a chlorinated cleaner, which is widely used for postcleaning in the magnetic inspection process. DR-62 is found widely in machine shops, foundries, and overhaul shops; it is a good, all-purpose cleaner.

Companion Materials: Use DR-62 with all of Sherwin Incorporated's visible and fluorescent penetrants.

Container Sizes:

case of 12 aerosol cans

one-gallon cans

case of 4 one-gallon cans

Basic Instructions: (These instructions describe the basic process. They may need to be amended by the user to comply with applicable specifications and/or inspection criteria provided by the contracting agency.)

- General Cleaning: Spray on dirty surface, saturating the contaminated area. Let stand 10-30 seconds, allowing organic soils to dissolve. Wipe clean with rag or toweling before DR-62 dries completely. Repeat if necessary.
- Penetrant Pre-Cleaning: DR-62 has good pre-cleaning properties and is suitable for penetrant pre-cleaning. Before
 applying penetrant, follow the above instructions for using DR-62 as a general cleaner. Make certain cleaning is sufficient
 to remove flaw-entrapped as well as surface soils. Allow DR-62 to evaporate completely from within any flaws before
 applying the inspection penetrant.
- Penetrant Removal: Use DR-62 sparingly. Remove as much excess penetrant as possible using clean, dry rag or toweling. Remove remaining penetrant film by wiping with rag or toweling that has been slightly moistened with DR-62. Use a minimum of DR-62; avoid flushing penetrant from flaws. Do not spray DR-62 directly on part surface when removing excess penetrant. Rough surfaces require more generous applications of DR-62.

Allow surface to dry completely before applying developer.

Applicable Specifications:

MIL-I-25135 Rev. E AMS-2644 Navships 250-1500 ASME B&P Vessel Code AECL MIL-STD-271 E AMS 2647 ASTM-E-165 RDT Standard MIL-STD 6866 ASTM-E-1417

revised September 2003

PRECAUTIONARY INFORMATION

Flammable Liquid—use with adequate ventilation and away from sparks, fire, or open flame. Avoid prolonged or repeated contact with skin. Do not take internally. Avoid breathing vapor. Do not puncture, heat, or incinerate aerosol cans: store under 120°F and out of direct sun. Empty containers may still contain hazardous vapors or liquids; do not weld, heat, or drill.



5530 Borwick Ave. South Gate, CA 90280 (562) 861-6324 FAX (562) 923-8370