

## CIRCLE SYSTEMS, INC.

479 West Lincoln  
P.O. Box 1228  
Hinckley, IL 60520  
Ph.: 815-286-3271  
Fax: 815-286-3352  
customerservice@circlesafe.com



---

### Technical Bulletin #265 Mi-Glow® 820

Mi-Glow® 106 black particles premixed with liquid Wetting Agent 771 for use in water media. Higher particle concentration provides heavier indication buildup for easy detection. It is designed to be used with visible light for finding discontinuities in finished products. Mi-Glow® 820 can be used with Mi-Glow® WCP.

#### Properties

Particle Color: Black

Specific Gravity: 1.5 g/ml - for the concentrate

Particle Size: Not less than 98% passage through US Standard No. 325 (45 µm) sieve as defined in AMS 3042. The typical range of particle sizes is from 0.5 to 4.0 µm, with an average particle size of 1.5 µm.

Sensitivity: Mi-Glow® 820 shows a minimum of 6 lines on an AISI 01 Ketos tool steel ring (as defined in SAE AS5282), set on a 1-inch diameter copper bar, magnetized with 2500 A of direct current.

Particle Certification: Particles meet or exceed all relevant industry specifications, including but not limited to MIL-STD-1949, AMS 3042, MIL-STD-271, NAVSEA 250-1500-1, NTR-1E, ASTM E 1444. Certification is included with each shipment.

Temperature Limits: 32-120°F (0-49°C)

Shelf Life: One (1) year, when sealed bottles are not subjected to extreme heat or cold. A Certificate of Shelf Life is available upon request.

#### Directions for Use

Preparation: The change-over from a solvent system to a Mi-Glow® 820 system requires a thorough cleaning of the tank and piping. This can be accomplished in most cases by flushing the system twice, using about 1/2 gallon of Cleaner 500 and 10-15 gallons of water. Flushing should be followed by a water rinse.

Mi-Glow® 820 should be used at a dilution of 1 part concentrate with 39 parts of water. This will give a particle concentration of 9.5 grams per liter. The recommended proportion may vary depending on specific applications. Each bottle should be thoroughly mixed before using. If a bottle is emptied, it should be rinsed with water and the contents added to the system.

Lighting: A minimum of 100 foot candles (1000 lux) of visible light at the part surface per ASTM E 709 and ASTM E 1444 is recommended.

**Settling Test:** The settling test, to check particle concentration and contamination, shall be performed upon startup, at each shift thereafter and whenever the bath is changed or adjusted.

**Checking Bath Concentration** - The settling test is essential to check the bath concentration and is accomplished by gravity settling in a graduated pear-shaped centrifuge tube as specified in Guide E709.

1. Run the pump for 30-60 minutes, to agitate the suspension thoroughly and to assure particle distribution.
2. Fill 100 ml sample from the delivery hose into the centrifuge tube.
3. Demagnetize the sample and stand, together.
4. Allow particles to settle for a minimum of 30 minutes or until completely settled.
5. The recommended volume is between 1.2 and 2.4 ml.
6. Adjust bath, either by adding particles or vehicle, if necessary.

**Checking Bath Contamination** - To determine bath contamination, use the same sample that was used for the concentration settling test, and examine the liquid above the settled particles with a black light. The liquid should be clear. If the bath is noticeably fluorescent, the bath must be changed. Next, examine the graduated portion of the tube where the particles have settled, with a black light and visible light for striations or bands of contamination that will be different in color and appearance than the settled particles. These striations or bands represent solid contamination, and if they exceed 30% of the settled particles, the bath should be changed.

**Corrosion Inhibition:** For best results, the system should be run in the pH range of 8.5 - 9.5, as verified by testing with a pH meter or pH paper. A special test for corrosion inhibition, Technical Bulletin 235, is available upon request and should be adapted to the specific part being inspected. This test should be run periodically to monitor the level of corrosion inhibitors present in the bath.

**Evaporation:** If the level of solution in the system has dropped, the following procedure should be used as a guideline. First, replenish the water to the proper bath level. Then check the particle concentration using the concentration test. Make any adjustments by adding Mi-Glow® 820. The final step will be to test the level of corrosion inhibition in the system using the procedure that is outlined in Technical Bulletin 235. Wetting Agent 771 should then be added as necessary.

---

DISCLAIMER: OUR TECHNICAL ADVICE, INFORMATION AND STATEMENTS GIVEN VERBALLY, IN WRITING OR IN THE FORM OF TEST RESULTS, ARE OFFERED FOR YOUR GUIDANCE WITHOUT WARRANTY. NO WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS MADE. IT IS THE USER'S RESPONSIBILITY TO TEST THE SUITABILITY OF EACH PRODUCT FOR HIS INTENDED PROCESS AND APPLICATIONS. OUR GUARANTEE IS LIMITED TO THE CONSISTENT QUALITY OF OUR PRODUCTS.

---