

## CIRCLE SYSTEMS, INC.

479 West Lincoln  
P.O. Box 1228  
Hinckley, IL 60520  
Ph.: 815-286-3271  
Fax: 815-286-3352  
customerservice@circlesafe.com



---

### Technical Bulletin #273 Mi-Glow® 850

Mi-Glow® 600 red particles premixed with powdered Wetting Agent 100 for use in water media. It is designed to be used with visible light for detecting discontinuities found in structural fabrications and weldments. Higher particle concentration provides heavier indication buildup for easy detection. Mi-Glow® 850 can be further enhanced when used with a black light or blue light.

#### Properties

Particle Color: Red

Specific Gravity: 0.6 g/ml

Particle Size: Not less than 98% passage through US Standard No. 325 (45 µm). The typical range of particle sizes is from 5 to 20 µm, with an average particle size of 7 µm.

Particle Certification: Particles meet or exceed all relevant industry specifications, including but not limited to MIL-STD-1949, AMS 3042, MIL-STD-271, NAVSEA 250-1500-1, NTR-1E, ASTM E 1444. Certification is included with each shipment.

Temperature Limits: 32-120°F (0-49°C)

Shelf Life: Four (4) years, when closed containers are stored in a clean, dry environment away from excessive heat and cold. A Certificate of Shelf Life is available upon request.

#### Directions for Use

Preparation: Mi-Glow® 850 should be mixed at the recommended concentration of 3.2oz per one gallon (24.0 grams/liter) of water. For best results, add a small amount of water to the powder and form a slurry prior to adding to the bath. Pour the slurry near the pump inlet.

Settling Test: The settling test, to check particle concentration and contamination, shall be performed upon startup, at each shift thereafter and whenever the bath is changed or adjusted.

*Checking Bath Concentration* - The settling test is essential to check the bath concentration and is accomplished by gravity settling in a graduated pear-shaped centrifuge tube as specified in Guide E709.

1. Run the pump for 30-60 minutes, to agitate the suspension thoroughly and to assure particle distribution.
2. Fill 100 ml sample from the delivery hose into the centrifuge tube.
3. Demagnetize the sample and stand, together.
4. Allow particles to settle for a minimum of 30 minutes or until completely settled.

5. The recommended volume is 2.2 ml.
6. Adjust bath, either by adding particles or vehicle, if necessary.

*Checking Bath Contamination* - To determine bath contamination, use the same sample that was used for the concentration settling test, and examine the liquid above the settled particles with a black light. The liquid should be clear. If the bath is noticeably fluorescent, the bath must be changed. Next, examine the graduated portion of the tube where the particles have settled, with a black light and visible light for striations or bands of contamination that will be different in color and appearance than the settled particles. These striations or bands represent solid contamination, and if they exceed 30% of the settled particles, the bath should be changed.

---

DISCLAIMER: OUR TECHNICAL ADVICE, INFORMATION AND STATEMENTS GIVEN VERBALLY, IN WRITING OR IN THE FORM OF TEST RESULTS, ARE OFFERED FOR YOUR GUIDANCE WITHOUT WARRANTY. NO WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS MADE. IT IS THE USER'S RESPONSIBILITY TO TEST THE SUITABILITY OF EACH PRODUCT FOR HIS INTENDED PROCESS AND APPLICATIONS. OUR GUARANTEE IS LIMITED TO THE CONSISTENT QUALITY OF OUR PRODUCTS.

---